Activities that are not water dependent, such as building facilities, boat cleaning facilities, and parking, in upland locations.

Bottomland occupation has been minimized to protect public trust waters and other riparian rights.

> Placement of only water dependent activities, such as docks for boats, in the water.

Ensuring that the proposed marina structures and slips are appropriate for the waterbody where it is located. For example, marinas on inland lakes and streams should not be designed the same as Great Lakes marinas for many reasons, including the size of boats used on these waterbodies and typical wave and wind action.