Non-JobNet Jobs ID Naming Conventions in PHD

Job Type	Definition	PHD Job ID Naming Convention
Maintenance	Maintenance-funded work **not** let through MDOT (not programmed in JobNet), performed by MDOT or another agency.	Use the prefix "M" followed by the **job number**. Example: **M21550**
TWA	Transportation Work Authorization-funded projects. Usually for projects bid through the county/city. Some TWA project information is available in MDOT's MLAP (Maintenance Local Agency Payments) database. The MLAP database can be accessed from the MDOT MILogin Application Portal.	Use the prefix "TWA" followed by the **TWA number**. The MDOT region financial analyst can provide the number or assign a number if unavailable in the MLAP database. Example: **TWA226101**
Warranty	Work performed under the terms of a project warranty. Some warranty project information is available in the MDOT's SWAD/QUADS database [Statewide Warranty Administration Database (SWAD) and Quality Assurance Database System]. The SWAD/QUADS database can be accessed from the MDOT MILogin Application Portal.	Use the prefix **"W"** followed by the original **5 or 6-digit job number**. Example: **W40542**
Direct Forces Work	Work performed by MDOT employees (maintenance crew facility and/or a maintenance garage) or contract county forces. Direct forces project information is usually tracked by the region (in Excel spreadsheets).	Create a direct force work reference number for PHD use only. Use the following conventions: **DYYYYCNrouteBMP.** 1. The prefix **"D,"** followed by four digits representing the **year**. 2. The two-digit **county number**. 3. The **route name**. Use an alphanumeric with a hyphen as a separator; for example, "US-31" or "US-31BR". 4. The **PR beginning milepoint** (including the decimal point). Example: **D202132M-1388.954** (There is a 20-character limit)
Historic	Projects let and constructed by MDOT prior to the implementation of MDOT's JobNet database and MDOT's Architecture Project (MAP) database.	Use either the **project number from the title sheet** of the historical plans or other available records. Example: **53201**
Permit	Work constructed by others under permit, such as widenings for commercial driveways or utilities work.	Use the prefix **"P"** followed by the **last 10 digits of the permit number**. The TSC permit agent will be able to provide this information. Example: **P0003090010**

If you require assistance accessing this information or require it in an alternative format, contact the Michigan Department of Transportation's (MDOT) Americans with Disabilities Act (ADA) coordinator at Michigan.gov/MDOT-ADA.