

HOW TO FIND APPLICABLE TOTAL MAXIMUM DAILY LOADS (TMDLs) USING MiEnviro Portal


GUIDANCE FOR STORM WATER PERMITTEES

INTRODUCTION


Applicable Total Maximum Daily Loads (TMDLs) are required as part of a stormwater permittee's Stormwater Pollution Prevention Program (SWPPP). The following guidance is provided to assist permittees in locating their applicable TMDLs.

LOCATING SITE APPLICABLE TMDLS IN MIENVIRO.


1. After logging in, select the appropriate site.
2. Click on **Details**.
3. Click on **Site Plan**.
4. Click on the **Layers** tab drop-down and check the box for Stormwater TMDL Review.




5. Click on the Location button under **Site Features**.



6. Click on the **Intersections**. You may need to scroll down the screen to find this option.



7. Click the small arrow to expand the TMDL to see its name. If there are multiple TMDLs for the site, there will be more than one listed.
8. If no TMDLs are listed, no further action is required. If a TMDL(s) is listed, include these in the permittee's Stormwater Pollution Prevention Program.



This publication is intended for guidance only and may be impacted by changes in legislation, rules, policies, and procedures adopted after the date of publication. Although this publication makes every effort to teach users how to meet applicable compliance obligations, use of this publication does not constitute the rendering of legal advice.

EGLE does not discriminate on the basis of race, sex, religion, age, national origin, color, marital status, disability, political beliefs, height, weight, genetic information, or sexual orientation in the administration of any of its programs or activities, and prohibits intimidation and retaliation, as required by applicable laws and regulations.

To request this material in an alternate format, contact EGLE-Accessibility@Michigan.gov or 800-662-9278.