Report

# Tittabawassee River Sediment Dioxin/Furan Concentration Variability

Prepared for

# **Dow Chemical Company**

Midland, MI

March 2005

**CH2MHILL** 

# **Contents**

Contents		i
Acronyms an	nd Abbreviations	ii
Tittabawasse	ee River Sediment Dioxin/Furan Concentration Variability	1
1.0	Introduction	1
2.0	Summary of Field Activities	1
	2.1 Fall 2003 Tittabawassee Sediment Sampling	1
	2.2 Summer 2004 Tittabawassee Sediment Sampling Event	2
3.0	Laboratory Analysis	4
4.0	ValidationValidation	4
	4.1 Fall 2003 Sediment Sampling Event	4
	4.2 Summer 2004 Sediment Sampling Event	4
5.0	Summary of Analytical Data	
	5.1 Fall 2003 Sediment Sampling Event	
	5.2 Summer 2004 Sediment Sampling Event	
6.0	Conclusions	6
7.0	References	
Tables 1 2	TEQs in Sediment, Fall 2003 Sediment Sampling Event TEQs in Sediment, Summer 2004 Sediment Sampling Event	
Figures		
1	Schematic Diagram of Stratified Random Sampling Design	
2	Dioxon TEQ Concentrations from Sediment Variability Sampling	
2A	Dioxin/Furan TEQ Sediment Results Summary	
2B	Dioxin/Furan TEQ Sediment Results Summary	
Appendixes		
A	Sediment Variability Evaluation Station and Sample Summary,	
	Fall 2003 and Summer 2004 Sampling Events	
В	Data Validation Summary Reports	
С	Dioxin/Furan Congener-Specific Sediment Sample Results	
Attachment		
1	Sampling and Analysis Plan	

# **Acronyms and Abbreviations**

CH2M HILL CH2M HILL, Inc.

Dow The Dow Chemical Company

LTI LimnoTech, Inc.

MOCA Midland Offsite Corrective Action

PPE Personal Protective Equipment

ppt part(s) per trillion

QAPP Quality Assurance Project Plan

QC quality control

SAP Sampling and Analysis Plan

TEQ total toxic equivalent

WWTP Wastewater Treatment Plant

# Tittabawassee River Sediment Dioxin/Furan Concentration Variability

# 1.0 Introduction

This document presents the results of two sediment sampling events conducted in support of the Dow Midland Offsite Corrective Actions (MOCA) program; one in the fall of 2003; and one in the summer of 2004. Both sampling events were part of an ongoing effort to characterize Tittabawassee River sediments and evaluate the variability of dioxin/furan concentrations within those sediments.

This report has been developed to document the field activities and report the data collected for these activities. It presents analytical results in such a manner as to provide a preliminary assessment of sediment conditions. The contents of this report include a discussion of:

- Field activities conducted during the two sampling events (Section 2);
- Laboratory analysis of sediment samples (Section 3);
- Summary of the analytical validation (Section 4);
- A discussion of the analytical results (Section 5);
- Detailed tabular information on the sample stations and cores collected (Appendix A);
- Detailed information on the analytical validation (Appendix B); and,
- All dioxin and furan congener-specific results (Appendix C).

# 2.0 Summary of Field Activities

# 2.1 Fall 2003 Tittabawassee Sediment Sampling

#### Sampling Design

In the fall of 2003, an investigation was conducted on the sediments in the Tittabawassee River under the *Preliminary Flow/Solids Monitoring and Sediment Thickness Characterization* (LTI, 2003). The objectives of this study were to improve the understanding of solids deposition and transport through the river system and provide preliminary data supporting an assessment of the stability of river and floodplain sediments. This study included the collection of 23 sediment cores during November and December 2003. The sediment cores were collected from a subset of probe locations that were measured during the Tittabawassee River probing study. The 23 sediment cores were collected at approximately 1-mile intervals, with an even distribution of center, left, and right channel samples to be

1

representative of the length of the river downstream of Dow, and the entire width of the river channel.

#### Summary of Field Activities

Twenty-three sediment cores were collected in November and December 2003. All cores were maintained and frozen in a vertical position. The sediment core stations were assigned a Station ID during the sampling activities. These Station IDs were then aliased Station IDs (and later Sample IDs) following Project protocol that was formalized after the sampling event. During sediment core collection, the depth to water, and the amount sediment recovered were recorded. A summary of these results is presented in Appendix A, Table A-1.

In the spring of 2004, the top 0.3 feet of each core was sectioned from each core using a hacksaw to cut through the frozen core liner. The samples were then placed in appropriate sample containers supplied by a laboratory, and shipped for analysis (refer to Section 3). The Station IDs, location coordinates, Sample IDs, sample depth intervals, and associated analytical batches are summarized in Table A-2.

A total of 23 sediment field samples were collected and sent for analysis during the Sediment Variability sampling. The only quality control (QC) samples collected during this sampling were field duplicates. Since each sediment sample was collected in a separate lexan tube, there was no need for additional QC sample types. Table A-3 of Appendix A summarizes the QC sample type, event frequency, and Quality Assurance Project Plan (QAPP) specified frequency for QC sample collection.

# 2.2 Summer 2004 Tittabawassee Sediment Sampling Event

#### Sampling Design

Two surface sediment samples collected during the fall 2003 event exhibited significantly higher dioxin/furan total toxic equivalent (TEQ) concentrations than the other samples (refer to Section 5 for discussion of the results). These two sample locations (THT-02245 and SHL-02235) became the focal point for design of the summer 2004 sediment sampling event.

The objective of the summer 2004 sampling was to collect sufficient data to evaluate sediment variability in the areas of elevated dioxins/furans measured in the Tittabawassee River sediment collected in 2003. To meet this objective, a stratified random sampling design was used to evaluate the variability of dioxin/furan TEQ concentrations in the immediate vicinity of the elevated dioxin/furan TEQ concentrations identified from the fall 2003 sampling. The stratified component provides information on the dispersion of contaminants, while the random component provides a more robust data set for spatial analysis.

To establish sampling locations according to this design, a center-point was first identified at the location of the original elevated dioxin/furan concentration. Then beginning at the center point, strata were established based on the following criteria:

• Transects were run through the center point both parallel and perpendicular to the river flow direction;

- Longitudinal strata boundaries were established at 22.5 degrees off both directions of each transect;
- Latitudinal strata boundaries were established between the longitudinal boundaries at logarithmically increasing distances from the center point along the transects; in this case, approximately 3, 30, 100, 330, and 980 feet from the center point.

Finally, random sample locations were then generated in each of the five strata, and in up to four directions (depending if the location fell within the river channel). A schematic diagram of the stratified random sampling design is provided in Figure 1. Analysis of samples took place in phases, with the results from the closest proximal samples evaluated prior to determining which (if any) additional samples would be analyzed.

Additionally during the summer 2004 sampling event, three sediment cores were collected in the vicinity of the Saginaw Township Waste Water Treatment Plant (WWTP) outfall to evaluate its potential impact on dioxin/furan concentration in sediments. One core was collected upstream, one adjacent, and one downstream of the outfall. The actual locations of the cores were determined by the field lead based on observed sediment patterns in the area. For more information, refer to the Sampling and Analysis Plan (SAP) for Sediment Variability Sampling (CH2M HILL, 2004). This document is included with this report as Attachment 1.

#### **Summary of Field Activities**

Sampling to evaluate sediment variability in areas of elevated dioxins/furans was performed on July 1 and 2, and July 7 through 9, 2004. This effort included the collection of 35 sediment cores of varying length, but no greater than 5 feet, in accordance with the *Core Sediment Sampling Field SOP* (CH2M HILL, 2004). During sediment core collection, the depth to water, depth of sediment penetrated, and sediment recovered measurements were recorded. A summary of these results is presented in Appendix A, Table A-4.

At the end of each day, all sediment cores were maintained in vertical orientation and transferred to the sampling warehouse in Midland for storage in a sample freezer, also in the vertical orientation. After all of the sediment cores were collected and frozen, the samples planned for initial analysis were processed. This was accomplished using a hacksaw to cut the frozen core liners to separate the top 0.3-foot interval. In total, 13 cores were processed in this manner. This includes the 5 cores collected closest to the centerpoint where each of the 2 elevated concentrations were initially measured and the 3 cores collected near the effluent of the Saginaw Township WWTP. The samples were then extruded from the core tubes into the appropriate sample container. The samples were labeled, packaged, and shipped to Alta Analytical in El Dorado Hills, California in accordance with the Sample Handling and Shipping Custody Procedures Field SOP (CH2M HILL, 2004). The remaining portions of these cores, as well as the cores from which no samples were collected, remain frozen for potential future analysis.

Quality control samples collected as part of the sampling included one equipment blank. There was insufficient sediment volume within the top 0.3 foot of each sediment core to collect field duplicates and matrix spike/matrix spike duplicates. Table A-6 (Appendix A)

summarizes the QC sample type, event frequency, and QAPP specified frequency for QC sample collection.

The remaining portions of the segregated cores that were analyzed, along with the other 24 sediment cores that were not analyzed, are currently located in sample freezers at the sampling warehouse in Midland. The station locations (Station IDs), location coordinates, Sample IDs (where applicable), sample depth intervals, and associated analytical batches are summarized in Appendix A, Table A-5.

#### **Investigation Derived Waste**

Dedicated lexan core tubes were used for the collection of the sediment samples, so no decontamination water was used during the sampling. The excess sediment is currently frozen pending the need for analysis. Personal Protective Equipment (PPE) was containerized in trash bags and discarded in the office dumpster.

# 3.0 Laboratory Analysis

All soil and groundwater samples were prepared for analysis in accordance with SW-846, and analyzed for dioxins and furans by EPA Method 8290. All dioxins/furans analyses were performed at Alta Analytical Laboratory in El Dorado Hills, California. Analyses of samples collected during the summer 2004 sampling event were conducted in accordance with the project QAPP (CH2M HILL, 2004). Analysis of samples collected during fall 2003 were analyzed prior to implementation of the QAPP.

## 4.0 Validation

Analytical data from both sediment sampling events were all validated to Level III by CH2M HILL chemists. The findings of this validation are summarized below, and the full Validation Summaries are provided in Appendix B.

# 4.1 Fall 2003 Sediment Sampling Event

A review of the analytical data submitted for the fall 2003 sediment sampling event has been completed. The overall evaluation of the data indicates that the sample handling, shipment, and analytical procedures have been adequately completed. The validation review demonstrated that the analytical systems were generally in control and the data results can be used. The complete validation summary report is provided in Appendix B.

# 4.2 Summer 2004 Sediment Sampling Event

A review of the analytical data submitted for the summer 2004 sampling event has been completed. The overall evaluation of the data indicates that the sample handling, shipment, and analytical procedures have been adequately completed. The validation review demonstrated that the analytical systems were generally in control and the data results can be used. The complete validation summary report is provided in Appendix B.

# 5.0 Summary of Analytical Data

This section provides a brief summary of all analytical data collected during this investigation. The focus of this section is on the tabular presentation of data and factual observations made through its review. Figure 1 provides an overview of the locations sampled as well as the TEQ values found at each location.

These dioxin/furan data are presented as TEQ, by location for each media. Samples collected during this study were analyzed for all 17 of the 2, 3, 7, 8-substituted dioxin and furan congeners that are necessary to evaluate the TEQ. TEQs are calculated according to World Health Organization methodology (Van den Berg, et al., 1998), using toxicity equivalency factors for mammals. Laboratory non-detect results for individual congeners were factored into the TEQ calculation using a value of one-half the laboratory detection limit. Tables showing analytical results for all 17 congeners are presented in Appendix A, Table A-7 and A-8.

## 5.1 Fall 2003 Sediment Sampling Event

The surface 0.3 ft (10 cm) samples from all cores collected during the Fall 2003 were later analyzed (March 2004) for the purpose of evaluating the concentrations of dioxins/furans in surface sediments along the Tittabawassee River. Sediment dioxin/furan concentrations from this sampling event ranged from 2 to 9,312 parts per trillion (ppt) TEQ.

Two samples from this data set were of particular interest due to reported TEQs that were substantially higher than the other samples. These included samples SHL-02235 and THT-02245, which showed concentrations of 2,864 and 9,312 ppt TEQ, respectively. Sample SHL-02235 was collected approximately 1,000 feet upstream of the Saginaw Township WWTP outfall and THT-02245 was collected in the vicinity of Imerman Park. Note, however, that a second sample collected from the same location as THT-02245, but at a later date, showed a dioxin/furan concentration of 265 ppt TEQ. This location was sampled twice because a 2" diameter Lexan tube was first used for collection on November 12, 2003. It was later resampled on December 4, 2003 using a 2 ½" diameter Lexan tube for consistency with all other cores collected during this effort. All Fall 2003 sampling locations are shown on Figure 2.

# 5.2 Summer 2004 Sediment Sampling Event

The objective of the summer 2004 sampling was to collect sufficient data to evaluate sediment variability in the two sample locations from the fall 2003 study. Five samples were analyzed in the proximity of each of the areas with elevated TEQ. Figures 2A and 2B show the samples collected in the areas around the two elevated TEQ sample locations.

In fall 2003, the sediment sample collected from THT-02245 had a TEQ value of 9,312 ppt. In the samples collected near this location in the summer of 2004, TEQ values ranged from 10 to 71 ppt. TEQ values ranged from 15 to 517 ppt in the area surrounding SHL-02235 in samples collected in 2004. As noted above, the sample collected from location SHL-02235 had a calculated TEQ of 2,864 ppt. The calculated TEQ concentrations from the summer 2004 sampling event are provided in Table 2.

Three samples were analyzed in the vicinity of the Saginaw Township WWTP to evaluate potential impacts of the effluent on sediment dioxin/furan concentrations. Sample SHL-02818 located upstream of the WWTP had a TEQ concentration of 607 ppt, sample SHL-02817 located adjacent to the WWTP had a TEQ concentration of 32 ppt, and sample SHL-02816 located downstream of the WWTP had a TEQ concentration of 40 ppt.

#### 6.0 Conclusions

Tittabawassee River surface sediment dioxin/furan TEQ concentrations appear to be highly variable and difficult to replicate. Sampling results collected in the areas around the elevated TEQ samples SHL-02235 and THT-02245 were at least an order-of-magnitude less than the original samples. Samples collected in the vicinity of the Saginaw Township WWTP were inconclusive in identifying any relationship between sediment TEQ concentrations and the outfall.

# 7.0 References

CH2M HILL. 2004. Core Sediment Sampling Field SOP.

CH2M HILL. 2004a. Quality Assurance Project Plan.

CH2M HILL. 2004b. Sample Handling and Shipping Custody Procedures Field SOP.

CH2M HILL. 2004c. Sampling and Analysis Plan for Sediment Variability Sampling.

LimnoTech, Inc. 2003. *Preliminary Flow/Solids Monitoring and Sediment Thickness Characterization*.


Van den Berg, M.; et al. 1998. Toxic equivalency factors (TEFs) for PCBs, PCDDs, PCDFs for humans and wildlife. *Environmental Health Perspectives*. 106:775-792.


**TABLE 1**TEQs in Sediment, Fall 2003 Sediment Sampling Event Dow MOCA Sediment Variability Evaluation


Location ID	Field Sample ID	TEQ Result	Units
MIC-02251	111703-SED-02251-00.3	11.559	ng/kg
MIC-02252	120903-SED-02252-00.3	5.63519	ng/kg
MIC-02252	120903-SED-02270-00.3-D	7.06984	ng/kg
DOW-02253	111803-SED-02253-00.3	3.86812	ng/kg
DOW-02254	121103-SED-02254-00.3	2.87493	ng/kg
DOW-02254	121103-SED-02271-00.3-D	386.172	ng/kg
FRE-02247	120803-SED-02247-00.3	489.257	ng/kg
FRE-02248	120803-SED-02248-00.3	10.6356	ng/kg
FRE-02249	120903-SED-02249-00.3	11.367	ng/kg
FRE-02250	111403-SED-02250-00.3	15.5078	ng/kg
SHI-02232	112403-SED-02232-00.3	59.7323	ng/kg
SHL-02233	112503-SED-02233-00.3	17.8538	ng/kg
SHL-02234	112603-SED-02234-00.3	6.37545	ng/kg
SHL-02235	112603-SED-02235-00.3	2864.34	ng/kg
SHL-02236	110703-SED-02236-00.3	16.201	ng/kg
SHL-02237	120103-SED-02237-00.3	24.4635	ng/kg
SHL-02238	110703-SED-02238-00.3	37.3039	ng/kg
SHL-02239	120203-SED-02239-00.3	488.561	ng/kg
SHL-02240	120203-SED-02240-00.3	6.34143	ng/kg
SHL-02240	120203-SED-02269-00.3-D	1.47115	ng/kg
THT-02241	120303-SED-02241-00.3	117.341	ng/kg
THT-02242	120303-SED-02242-00.3	44.3601	ng/kg
THT-02243	120403-SED-02243-00.3	8.98756	ng/kg
THT-02244	120403-SED-02244-00.3	265.291	ng/kg
THT-02245	111203-SED-02245-00.3	9311.74	ng/kg
THT-02246	120503-SED-02246-00.3	143.926	ng/kg

**TABLE 2**TEQs in Sediment, Summer 2004 Sediment Sampling Event Dow MOCA Sediment Variability Evaluation


Location ID	Field Sample ID	TEQ Result	Units
SHL-02792	070804-SED-02792-00.3	109.192	ng/kg
SHL-02794	070704-SED-02794-00.3	516.883	ng/kg
SHL-02795	070704-SED-02795-00.3	484.957	ng/kg
SHL-02804	070704-SED-02804-00.3	21.3091	ng/kg
SHL-02816	070904-SED-02816-00.3	39.6688	ng/kg
SHL-02818	070904-SED-02818-00.3	607.256	ng/kg
THT-02775	070204-SED-02775-00.3	34.4805	ng/kg
THT-02776	070104-SED-02776-00.3	24.2967	ng/kg
THT-02777	070104-SED-02777-00.3	26.0669	ng/kg
THT-02779	070104-SED-02779-00.3	10.221	ng/kg
THT-02782	070104-SED-02782-00.3	70.7508	ng/kg
SHL-02793	070704-SED-02793-00.3	15.1562	ng/kg
SHL-02817	070904-SED-02817-00.3	32.3814	ng/kg







Dioxin/Furan TEQ Sediment Results Summary
Tittabawassee River Sediment Dioxin/Furan Concentration Variability Report
Dow Midland Offsite Corrective Actions Program







FIGURE 2A
Dioxin/Furan TEQ Sediment Results Summary
Tittabawassee River Sediment Dioxin/Furan Concentration Variability Report
Dow Midland Offsite Corrective Actions Program





Dioxin/Furan TEQ Sediment Results Summary Tittabawassee River Sediment Dioxin/Furan Concentration Variability Report Dow Midland Offsite Corrective Actions Program

Appendix A Sediment Variability Evaluation Station and Sample Summary, Fall 2003 and Summer 2004 Sampling Events

TABLE A-1 Summary of Field Measurements, Fall 2003 Sediment Sampling Dow MOCA – Sediment Variability Sampling

Station ID	Water Depth (ft)	Sediment Penetrated (ft)	Sediment Recovered (ft)
DOW-02253	3	NR	3.67
DOW-02254	3.75	NR	3
FRE-02247	3	NR	3.5
FRE-02248	5	NR	2.42
FRE-02249	7.5	NR	3
FRE-02250	4	NR	3
MIC-02251	8.5	NR	1.58
MIC-02252	2.5	NR	4
SHI-02232	3	NR	1.8
SHL-02233	7	NR	2.3
SHL-02234	3	NR	3.9
SHL-02235	3.75	NR	3
SHL-02236	0	NR	3.8
SHL-02237	2	NR	3
SHL-02238	3.75	NR	3
SHL-02239	3	NR	3.4
SHL-02240	5.5	NR	0.8
THT-02241	8	NR	4.1
THT-02242	4	NR	2.25
THT-02243	2	NR	1.58
THT-02244	4	NR	2.3
THT-02245	5.5	NR	0.83
THT-02246	7.75	NR	1.3

NR = Not recorded. The sediment penetrated measurement was not recorded during the sampling events. Therefore, the percent recovery for each sediment core could also not be calculated.

TABLE A-2 Sample Station Summary, Fall 2003 Sediment Sampling Event Dow MOCA – Sediment Variability Sampling

Station ID	Easting	Northing	Sample ID	Sample Depth Interval (ft.)	Analytical Batch
DOW-02253	13157192.7342	766520.9442	111803-SED-02253-00.3	0-0.3	24910
DOW-02254	13156296.7449	768859.1208	121103-SED-02254-00.3	0-0.3	24910
DOW-02254	13156296.7449	768859.1208	121103-SED-02271-00.3-D	0-0.3	24910
FRE-02247	13194571.4931	724241.5543	120803-SED-02247-00.3	0-0.3	24910
FRE-02248	13187602.1351	737309.1562	120803-SED-02248-00.3	0-0.3	24910
FRE-02249	13184435.0472	741301.3258	120903-SED-02249-00.3	0-0.3	24910
FRE-02250	13182577.8688	743063.6118	111403-SED-02250-00.3	0-0.3	24910
MIC-02251	13170630.6314	752677.3050	111703-SED-02251-00.3	0-0.3	24910
MIC-02252	13168563.4706	754393.7161	120903-SED-02252-00.3	0-0.3	24910
MIC-02252	13168563.4706	754393.7161	120903-SED-02270-00.3-D	0-0.3	24910
SHI-02232	13223920.7557	688304.6975	112403-SED-02232-00.3	0-0.3	24910
SHL-02233	13216565.9434	690433.6889	112603-SED-02233-00.3	0-0.3	24910
SHL-02234	13213354.3072	692700.0000	110603-SED-02234-00.3	0-0.3	24910
SHL-02235	13212293.1123	693347.1023	112603-SED-02235-00.3	0-0.3	24910
SHL-02236	13208752.6449	695191.5759	110703-SED-02236-00.3	0-0.3	24910
SHL-02237	13208282.3288	697605.9201	120103-SED-02237-00.3	0-0.3	24910
SHL-02238	13209376.1920	700057.8234	110703-SED-02238-00.3	0-0.3	24910
SHL-02239	13207696.6897	702001.3036	120203-SED-02239-00.3	0-0.3	24910
SHL-02240	13208069.3324	704439.9142	111003-SED-02240-00.3	0-0.3	24910
SHL-02240	13208069.3324	704439.9142	111003-SED-02269-00.3-D	0-0.3	24910
THT-02241	13208110.7113	707072.8293	120303-SED-02241-00.3	0-0.3	24910
THT-02242	13203781.9467	708825.7887	120303-SED-02242-00.3	0-0.3	24910
THT-02243	13198629.7319	712652.2814	120403-SED-02243-00.3	0-0.3	24910
THT-02244	13198710.7959	713955.4965	120403-SED-02244-00.3	0-0.3	24910
THT-02245	13198710.7959	713955.4965	111203-SED-02245-00.3	0-0.3	24910
THT-02246	13195597.0078	715954.5185	120503-SED-02246-00.3	0-0.3	24910

TABLE A-3 QC Sample Summary, Fall 2003 Sediment Sampling Event Dow MOCA – Sediment Variability Sampling

QC Sample Type	Number of QC Samples Collected	Actual Event Frequency <sup>1</sup>	MOCA QAPP-Specified Frequency <sup>1</sup>
Trip Blanks	0 <sup>2</sup>	One per cooler containing samples for VOC analysis	One per cooler containing samples for VOC analysis
Matrix Spikes/Matrix Spike Duplicates	0	0%	5.0%
Field Duplicates	3	13%	10%
Field Blanks	03	0%	One per source of water used for decontamination
Equipment Blanks	03	0%	5.0%

<sup>&</sup>lt;sup>1</sup>= Frequency requirements are program wide frequencies and requirements, if not met above, will be met on a program wide basis.

<sup>2</sup> = Samples for VOC analysis were not collected as part of this sampling.

<sup>3</sup> = Not required since no equipment decontamination was performed.

**TABLE A-4**Sediment Location Field Measurements, Summer 2004 Sampling Event *Dow MOCA – Sediment Variability Sampling* 

Station ID	Water Depth (ft)	Sediment Penetrated (ft)	Sediment Recovered (ft)	Percent Recovery
THT-02786	8	-	1.5	-
THT-02785	2	2.5	1.8	72%
THT-02784	-	-	3.55	-
THT-02783	3.4	-	3.15	-
THT-02782	3.75	4.25	3.95	93%
THT-02780	0.7	4	2.3	58%
THT-02777	3.0	5	3.9	78%
THT-02779	3.3	4.7	4	85%
THT-02776	5.0	4	3.45	86%
THT-02778	12.1	1.5	1.25	83%
THT-02781	10.2	1.5	1.2	80%
THT-02775	3.7	3	2.55	85%
THT-02774	2.85	3.5	3.1	89%
THT-02773	4.9	3.5	3.1	89%
THT-02772	6.6	4.5	4	89%
SHL-02801	4.5	3.5	3.25	93%
SHL-02802	3.5	3	2.75	92%
SHL-02797	4.25	3.5	3.6	1.03%
SHL-02798	4.5	3.5	3.25	93%
SHL-02795	4.9	3	3	100%
SHL-02794	5	-	2.7	-
SHL-02804	4.9	-	2.3	-
SHL-02799	6.1	2	1.25	63%
SHL-02800	5.25	5.25	2.4	46%
SHL-02793	5	2	1.5	75%
SHL-02803	4.3	3.75	3.75	100%
SHL-02796	3.5	-	2.5	-
SHL-02792	5.5	2.5	2.3	92%
SHL-02791	5.25	3.25	2.75	85%

**TABLE A-4**Sediment Location Field Measurements, Summer 2004 Sampling Event *Dow MOCA – Sediment Variability Sampling* 

Station ID	Water Depth (ft)	Sediment Penetrated (ft)	Sediment Recovered (ft)	Percent Recovery
SHL-02790	5	2.4	1.5	63%
SHL-02789	3.75	2.5	2	80%
SHL-02788	4	3	2.4	80%
SHL-02816	3.5	3.5	2.75	79%
SHL-02817	3.75	3.7	3	81%
SHL-02818	3.25	4	2.6	65%

TABLE A-5 Sample Station Summary, Summer 2004 Sampling Event Dow MOCA – Sediment Variability Sampling

Station ID	Easting	Northing	Sample ID	Sample Depth Interval (ft.)	Analytical Batch
SHL-02792	693353.12616497	13212285.1116673	070804-SED-02792-00.3	0-0.3	25125
SHL-02793	693357.84976816	13212299.7781498	070704-SED-02793-00.3	0-0.3	25125
SHL-02794	693343.57438604	13212290.4268347	070704-SED-02794-00.3	0-0.3	25125
SHL-02795	693336.76668264	13212307.2078060	070704-SED-02795-00.3	0-0.3	25125
SHL-02804	693346.86397802	13212293.1687503	070704-SED-02804-00.3	0-0.3	25125
THT-02775	713964.58143551	13198706.5813221	070204-SED-02775-00.3	0-0.3	25125
THT-02782	713939.66386607	13198718.3889385	070104-SED-02782-00.3	0-0.3	25125
THT-02777	713953.65192679	13198706.7642292	070104-SED-02777-00.3	0-0.3	25125
THT-02776	713961.83074148	13198721.7422425	070104-SED-02776-00.3	0-0.3	25125
THT-02779	713955.18826071	13198710.7701939	070104-SED-02779-00.3	0-0.3	25125
SHL-02816	692782.35192497	13213073.5298862	070904-SED-02816-00.3	0-0.3	25125
SHL-02817	692830.56134054	13213027.5010524	070904-SED-02817-00.3	0-0.3	25125
SHL-02818	692855.80703634	13212985.3440689	070904-SED-02818-00.3	0-0.3	25125
THT-02772	714151.79946485	13198338.0782178	No Sample Analyzed	-	-
THT-02773	714088.20198408	13198630.4481636	No Sample Analyzed	-	-
THT-02774	713978.03435600	13198693.3207889	No Sample Analyzed	-	-
THT-02778	713981.32467628	13198761.6696794	No Sample Analyzed	-	-
THT-02780	713943.39942298	13198695.1216002	No Sample Analyzed	-	-
THT-02783	713921.28492513	13198726.5621444	No Sample Analyzed	-	-
THT-02784	713800.96526312	13198742.8373075	No Sample Analyzed	-	-
THT-02785	713411.82483985	13198779.0463577	No Sample Analyzed	-	-
THT-02786	712887.96410452	13198662.3657224	No Sample Analyzed	-	-
SHL-02788	693754.91047615	13211495.1837964	No Sample Analyzed	-	-
SHL-02789	693611.97103738	13211850.8296897	No Sample Analyzed	-	-
SHL-02790	693461.33438473	13212161.2881326	No Sample Analyzed	-	-
SHL-02791	693358.73633790	13212267.0742629	No Sample Analyzed	-	-
SHL-02796	693277.93168073	13212251.8192349	No Sample Analyzed	-	-
SHL-02798	693320.19444965	13212336.2538792	No Sample Analyzed	-	-

TABLE A-5 Sample Station Summary, Summer 2004 Sampling Event Dow MOCA – Sediment Variability Sampling

Station ID	Easting	Northing	Sample ID	Sample Depth Interval (ft.)	Analytical Batch
SHL-02799	693414.37502512	13212357.3489450	No Sample Analyzed	-	-
SHL-02800	693393.91413924	13212325.7287350	No Sample Analyzed	-	-
SHL-02801	692739.96895260	13213226.9889408	No Sample Analyzed	-	-
SHL-02802	693041.13002373	13212782.1136012	No Sample Analyzed	-	-
SHL-02803	693329.08892300	13212284.9284230	No Sample Analyzed	-	-
SHL-02796	693277.93168073	13212251.8192349	No Sample Analyzed	-	-


TABLE A-6 QC Sample Summary, Summer 2004 Sediment Sampling Event Dow MOCA – Sediment Variability Sampling

QC Sample Type	Number of QC Samples Collected	Actual Event Frequency <sup>1</sup>	MOCA QAPP-Specified Frequency <sup>1</sup>
Trip Blanks	0 <sup>2</sup>	One per cooler containing samples for VOC analysis	One per cooler containing samples for VOC analysis
Matrix Spikes/Matrix Spike Duplicates	0	0%	5.0%
Field Duplicates	0	0%	10%
Field Blanks	03	0%	One per source of water used for decontamination
Equipment Blanks	1	20%	5.0%

<sup>&</sup>lt;sup>1</sup> = Frequency requirements are program wide frequencies and requirements, if not met above, will be met on a program wide basis.

<sup>2</sup> = Samples for VOC analysis were not collected as part of this sampling.

<sup>3</sup> = A field blank was not collected since equipment decontamination was not performed.



# Appendix B.1

# Data Validation Summary – Fall 2003 Sampling Event

The purpose of this report is to present the results of the data validation process for the samples collected for the Dow Chemical Company LimnoTech Sampling Events at the Dow Chemical Company site in Midland, Michigan. The samples were collected between the dates of November 6, 2003 and March 10, 2004.

The specific samples and analytical fractions reviewed are summarized below in Table 1.

The Quality Control areas that were reviewed and the resulting findings are documented within each subsection that follows. These data were validated for compliance with the analytical method requirements. This process also included a review of the data to assess the accuracy, precision, and completeness based upon procedures described in the guidance documents such as the Environmental Protection Agency (EPA) National Functional Guidelines for Chlorinated Dioxin/Furan Data Review (EPA, 2002), and the Quality Control criteria provided in the Quality Assurance Project Plan (QAPP). Quality assurance/quality control (QA/QC) summary forms and data reports provided by the laboratory were reviewed.

Samples were submitted to Alta Analytical Laboratory, Inc., in El Dorado Hills, California for the dioxin/furan analyses.

Sample results that were not within the acceptance limits were appended with a primary qualifying flag by CH2M HILL, which consisted of a single- or double-letter code that indicated a possible problem with the data. The qualifying flags originated during the data review and validation processes. In addition, secondary "sub-qualifier" flags were also applied. The secondary qualifiers provide the reasoning behind the assignment of a qualifier flag to the data.

Attachment 1 lists the changes in data qualifiers, due to the validation process. It contains columns for the Laboratory Qualifier (Lab Qual) as received from the laboratory, primary qualifiers (Final Qual), and secondary qualifiers (Validation Reasons). The primary and secondary qualifiers are presented and defined below.

The following primary flags were used to qualify the data:

- [=] Detected. The analyte was analyzed for and detected at the concentration shown.
- [J] Estimated. The analyte was present but the reported value may not be accurate or precise.
- [U] Undetected. The analyte was analyzed for but not detected above the method detection limit.
- [UJ] Detection limit estimated. The analyte was analyzed for but qualified as not detected; the result is estimated.
- [R] Rejected. The data is not useable.

The following Secondary Qualifier Codes were used to qualify the data.

Validation Reason	Definition
2SH	Second source calibration verification standard greater than the upper control limit
2SL	Second source calibration verification standard less than the lower control limit
ABH	Ambient blank concentration greater than the RL
ABL	Ambient blank concentration less than the RL
BKD	The result is qualified because the DDT and/or Endrin breakdown was greater than 20%.
CBKD	The result is qualified because the combined DDT/Endrin breakdown is greater than 30%.
ССВН	Continuing calibration blank concentration greater than the RL
CCBL	Continuing calibration blank concentration less than RL
CCC	CCC Failure
CCRRF	Continuing calibration relative response factor below the LCL
CCVF	Continuing Calibration not analyzed at the required frequency
CCVH	Continuing calibration recovery greater than upper control limit
CCVL	Continuing calibration recovery less than lower control limit
CF	Confirmation result
CFP	Confirmation precision exceeded
CO	Compounds were reported combined on one column
DL	Secondary dilution
EBH	Equipment blank concentration greater than the RL
EBL	Equipment blank concentration less than the RL
EMPC	Estimated Maximum Possible Concentration Reported
FBH	Field blank concentration greater than the RL

Validation Reason	Definition
FBL	Field blank concentration less than the RL
FD	Field duplicate exceeds RPD criteria
GPC	The results are qualified due to GPC calibration deficiencies.
HTA	Analytical Holding Time exceeded
HTP	Preparation Holding Time exceeded
IB	Result between the MDL and RL
ICBH	Initial calibration blank concentration greater than the RL
ICBL	Initial calibration blank concentration less than RL
ICR2	Initial calibration exceeded the R2 for first order regression
ICRR	Exceeds RSD criteria and initial calibration exceeded the R2 for first order regression
ICRRF	Initial calibration relative response factor below the LCL
ICRSD	Initial calibration RSD exceeded
ICSP	Single Point Initial Calibration used for Quantitation
ICVSH	Initial calibration verification recovery greater than upper control limit
ICVSL	Initial calibration verification recovery less than lower control limit
ISH	Internal standard response exceeded the UCL criteria
ISL	Internal standard response exceeded the LCL criteria
LBH	Laboratory blank contamination greater than the RL
LBL	Laboratory blank contamination less than the RL
LCSDH	LCSD recovery greater than criteria
LCSDL	LCSD recovery less than the criteria
LCSH	LCS recovery greater than criteria
LCSL	LCS recovery less than the criteria

SED VAR EVAL REPORT-FINAL\_CORRECT TEO.DOC

B-3

Validation Reason	Definition
LCSP	LCS/LCSD RPD criteria exceeded
LDP	Laboratory Duplicate Precision out
LR	Linear range exceeded. Concentration above linear range.
MSA	Quantitated by the method of standard additions
MSALL	Global matrix spike flagging
MSAR2	method of standard additions R2 out
MSDH	Matrix spike duplicate recovery criteria greater than the upper limit
MSDL	Matrix spike duplicate recovery criteria less than the lower limit
MSDP	Matrix Spike Duplicate RPD criteria exceedance
MSH	Matrix spike recovery criteria greater than the upper limit
MSL	Matrix spike recovery criteria less than the lower limit
NMS	Not Site-specific Matrix Spike
PH	Sample pH out. Not properly preserved.
PRM	Result differs from Preliminary Result
PSH	Post spike recovery criteria greater than the upper limit
PSL	Post spike recovery criteria less than the lower limit
RA	Sample was reanalyzed
RE	Sample was re-extracted and reanalyzed
RT	Result is outside the laboratory determined retention time window
SCRN	Screening method and/or data
SDIL	Serial Dilution %D exceeds the upper control limit
SPCC	SPCC Failure
SSH	Surrogate recovery greater than upper limit

SED VAR EVAL REPORT-FINAL\_CORRECT TEO.DOC

B-4

Validation Reason	Definition
SSL	Surrogate recovery less than lower limit
SSR	Surrogate spike recovery <10%
TBH	Trip blank concentration greater than the RL
TBL	Trip blank concentration less than the RL
TD	Total Concentration < Dissolved Concentration
TEMP	Cooler temperature out upon arrival
TIC	Tentatively identified compound
TN	GC/MS tune does not meet criteria
XCC	No Continuing Calibration analyzed in the analytical batch
X-DL	Data not used due to dilution; another value is more appropriate or data was not requested
XIC	No initial calibration analyzed in the analytical batch
XICVS	Initial calibration verification standard was not analyzed
XLCS	No LCS in the analytical batch
XLD	Laboratory Duplicate not reported
XMS	Matrix Spike not reported
XMSD	Matrix Spike Duplicate not reported
X-RE	Data not used due to reanalysis another value is more appropriate or data was not requested

SED VAR EVAL REPORT-FINAL\_CORRECT TEO.DOC

B-5

**TABLE B.1-1**Chemical Analytical Methods – Field and Quality Control Samples *Dow MOCA* 

Matrix	SDG	Lab Sample ID	Sample ID	Sample Alias	Sample Type	Date Collected	Dioxins
Sediment	24910	001	031004-SED-02255-00.0		N	03/10/2004	X
Sediment	24910	002	031004-SED-02260-00.0		N	03/10/2004	Х
Sediment	24910	003	031204-SED-02268-00.0		N	03/12/2004	Х
Sediment	24910	004	031004-SED-02262-00.0		N	03/10/2004	Х
Sediment	24910	005	031204-SED-02267-00.0		N	03/12/2004	X
Sediment	24910	006	031004-SED-02264-00.0		N	03/10/2004	X
Sediment	24910	007	031004-SED-02266-00.0		N	03/10/2004	Х
Sediment	24910	800	031004-SED-02265-00.0		N	03/10/2004	Х
Sediment	24910	009	031004-SED-02263-00.0		N	03/10/2004	Х
Sediment	24910	010	031004-SED-02261-00.0		N	03/10/2004	Х
Sediment	24910	011	031004-SED-02256-00.0		N	03/10/2004	Х
Sediment	24910	012	031004-SED-02258-00.0		N	03/10/2004	Х
Sediment	24910	013	031004-SED-02257-00.0		N	03/10/2004	Х
Sediment	24910	014	031004-SED-02259-00.0		N	03/10/2004	X
Sediment	24910	015	121103-SED-02271-00.3-D		FD	12/11/2003	Х
Sediment	24910	016	110703-SED-02236-00.3		N	11/07/2003	Х
Sediment	24910	017	120503-SED-02246-00.3		N	12/05/2003	Х
Sediment	24910	018	110703-SED-02238-00.3		N	11/07/2003	X
Sediment	24910	019	120403-SED-02243-00.3		N	12/04/2003	Χ
Sediment	24910	020	120803-SED-02248-00.3		N	12/08/2003	Χ
Sediment	24910	021	120303-SED-02241-00.3		N	12/03/2003	Χ
Sediment	24910	022	120103-SED-02237-00.3		N	12/01/2003	Χ
Sediment	24910	023	120903-SED-02252-00.3		N	12/09/2003	Χ
Sediment	24910	024	111003-SED-02269-00.3-D		FD	11/10/2003	Χ
Sediment	24910	025	120903-SED-02270-00.3-D	120904-SED-02270-00.3-D	FD	12/09/2003	Χ
Sediment	24910	026	120903-SED-02249-00.3		N	12/09/2003	Χ
Sediment	24910	027	111703-SED-02251-00.3		N	11/17/2003	Χ
Sediment	24910	028	112603-SED-02233-00.3		N	11/26/2003	X
Sediment	24910	029	111803-SED-02253-00.3		N	11/18/2003	X
Sediment	24910	030	111803-SED-02254-00.3		N	11/18/2003	Χ

TABLE B.1-1 Chemical Analytical Methods – Field and Quality Control Samples Dow MOCA

Matrix	SDG	Lab Sample ID	Sample ID	Sample Alias	Sample Type	Date Collected	Dioxins
Sediment	24910	031	120803-SED-02247-00.3		N	12/08/2003	Х
Sediment	24910	032	120203-SED-02239-00.3		N	12/02/2003	X
Sediment	24910	033	111203-SED-02245-00.3		N	11/12/2003	X
Sediment	24910	034	111403-SED-02250-00.3		N	11/14/2003	Χ
Sediment	24910	035	120303-SED-02242-00.3		N	12/03/2003	Χ
Sediment	24910	036	112603-SED-02235-00.3		N	11/26/2003	Χ
Sediment	24910	037	112403-SED-02232-00.3		N	11/24/2003	X
Sediment	24910	038	111203-SED-02244-00.3		N	11/12/2003	X
Sediment	24910	039	110603-SED-02234-00.3		N	11/06/2003	Χ
Sediment	24910	040	111003-SED-02240-00.3		N	11/10/2003	X
SAMPLE T	YPE COD	E					
N – Native	Sample						
FD – Field	Duplicate						

FD – Field Duplicate

**TABLE B.1-2** Changed Qualifiers

Parameter Class	Analytical Method	Parameter	SDG	Sample ID	Lab Sample ID	Matrix	Lab Result	Lab Qual	Final Result	Final Qual	Units	Reasons
DIOXINS	8290	OCDD	24910	031004-SED-02263-00.3	24910-009	SED	4540	Е	4540	J	pg/G	LR
DIOXINS	8290	1,2,3,4,6,7,8-HpCDD	24910	031004-SED-02258-00.3	24910-012	SED	2590	Е	2590	J	pg/G	LR
DIOXINS	8290	OCDD	24910	031004-SED-02258-00.3	24910-012	SED	23300	Е	23300	J	pg/G	LR
DIOXINS	8290	OCDF	24910	031004-SED-02258-00.3	24910-012	SED	8170	Е	8170	J	pg/G	LR
DIOXINS	8290	Total HpCDD	24910	031004-SED-02258-00.3	24910-012	SED	4140	Е	4140	J	pg/G	LR
DIOXINS	8290	Total TCDF	24910	031004-SED-02258-00.3	24910-012	SED	5350	Е	5350	J	pg/G	LR
DIOXINS	8290	Total TCDF	24910	031004-SED-02259-00.3	24910-014	SED	3400	Е	3400	J	pg/G	LR
DIOXINS	8290	OCDD	24910	121103-SED-02271-00.3-D	24910-015	SED	3790	Е	3790	J	pg/G	LR
DIOXINS	8290	Total TCDF	24910	121103-SED-02271-00.3-D	24910-015	SED	2410	Е	2410	J	pg/G	LR
DIOXINS	8290	Total TCDF	24910	120503-SED-02246-00.3	24910-017	SED	1370	Е	1370	J	pg/G	LR
DIOXINS	8290	OCDD	24910	120303-SED-02241-00.3	24910-021	SED	7640	Е	7640	J	pg/G	LR
DIOXINS	8290	1,2,3,4,6,7,8,-HpCDF	24910	120303-SED-02241-00.3	24910-021	SED	4180	Е	4180	J	pg/G	LR
DIOXINS	8290	1,2,3,7,8,-PeCDF	24910	111203-SED-02245-00.3	24910-033	SED	14200	Е	14200	J	pg/G	LR
DIOXINS	8290	2,3,4,7,8,-PeCDF	24910	111203-SED-02245-00.3	24910-033	SED	10900	Е	10900	J	pg/G	LR
DIOXINS	8290	1,2,3,4,7,8 -HxCDF	24910	111203-SED-02245-00.3	24910-033	SED	8630	Е	8630	J	pg/G	LR
DIOXINS	8290	1,2,3,7,8,-PeCDF	24910	112603-SED-02235-00.3	24910-036	SED	3180	Е	3180	J	pg/G	LR
DIOXINS	8290	2,3,4,7,8,-PeCDF	24910	112603-SED-02235-00.3	24910-036	SED	3350	Е	3350	J	pg/G	LR

## **Dioxin/Furan Parameters**

#### **Quality Control Review**

The following list represents the QA/QC measures that were reviewed during the data quality evaluation procedure for the dioxin/furan data.

- **Holding Times** The holding times are evaluated to verify that samples were extracted and analyzed within holding times.
- **Blank Samples** Method blanks and equipment blanks were provided for this project. Blank samples enable the reviewer to determine if an analyte may be attributed to sampling or laboratory procedures, rather than environmental contamination from site activities.
- Labeled Standard and Cleanup Standard Recoveries Labeled Standard and Cleanup Standard are added to each sample. The recoveries are used to monitor laboratory and method performance, and possible matrix interference.
- Lab Control Sample/Lab Control Sample Duplicate (LCS/LCSD) These samples are a "controlled matrix," in which target compounds have been added prior to extraction/analysis. The recoveries serve as a monitor of the overall performance of each step during the analysis, including sample preparation.
- Matrix Spike/Matrix Spike Duplicate (MS/MSD) Samples Spike recovery is used to
  evaluate potential matrix interferences, as well as accuracy. Precision information is also
  determined by calculating the reproducibility between the recoveries of each spiked
  parameter.
- **Field Duplicate Samples** These samples are collected to determine precision between a native and its duplicate. This information can only be determined when target compounds are detected.
- GC/MS Tuning The mass spectrum of the tuning compound is evaluated for method
  compliance. The criteria are established to verify the proper mass assignment and mass
  resolution. In addition, the column performance check and window defining mix
  summaries are evaluated.
- Initial Calibration The initial calibration ensures that the instrument is capable of
  producing acceptable qualitative and quantitative data for the compounds of interest.
- Continuing Calibration The continuing calibration checks satisfactory performance of the instrument and its predicted response to the target compounds, including retention times and abundance ratios.
- **Internal Standards** The internal standards (retention time and response) are evaluated for method compliance. The internal standards are used in quantitation of the target parameters and monitor the instrument sensitivity and response for stability during each analysis.

• **Second Column Confirmation** – Second column confirmation is evaluated when a secondary analysis is required due to interferences or co-elution.

# Dioxin/Furan Analyses by SW-846 8290

The QA/QC parameters for dioxin/furan analyses by SW-846 8290 for all of the samples were within acceptable control limits, except as noted below:

#### Linear Range

There were selected results in which the sample concentration exceeded the concentration of the calibration curve. However, the laboratory does not dilute and re-analyze dioxin/furan samples unless the signal saturates the instrument detector. The signal did not saturate the detector and linearity was maintained. Therefore, the sample results were qualified "J," as estimated.

The sample results qualified due to linear range exceedances are listed in Attachment 1 with a Validation Note of "LR."

# Rejected Data

No data were rejected based upon the validation process for this sampling event.

#### Conclusion

A review of the analytical data submitted for the LimnoTech Sampling Events, by LimnoTech has been completed. An overall evaluation of the data indicates that the sample handling, shipment, and analytical procedures have been adequately completed. The validation review demonstrated that the analytical systems were generally in control and the data results can be used in the decision making process.

# Appendix B.2

# Data Validation Summary – Summer 2004 Sampling

The purpose of this report is to present the results of the data validation process for the samples collected for the Dow Chemical Company Sediment Variability Study at the Dow Chemical Company site in Midland, Michigan. The samples were collected between the dates of July 1 and July 9, 2004.

The specific samples and analytical fractions reviewed are summarized below in Table 1.

The Quality Control areas that were reviewed and the resulting findings are documented within each subsection that follows. These data were validated for compliance with the analytical method requirements. This process also included a review of the data to assess the accuracy, precision, and completeness based upon procedures described in the guidance documents such as the Environmental Protection Agency (EPA) National Functional Guidelines for Chlorinated Dioxin/Furan Data Review (EPA 2002), and the Quality Control criteria provided in the Quality Assurance Project Plan (QAPP). Quality assurance/quality control (QA/QC) summary forms and data reports provided by the laboratory were reviewed.

Samples were submitted to Alta Analytical Laboratory, Inc., in El Dorado Hills, California for the dioxin/furan analyses.

A primary qualifying flag was appended by CH2M HILL to those sample results that were not within the acceptance limits. The primary qualifying flag consisted of a single- or double-letter code that indicated a possible problem with the data. The need to apply qualifying flags was identified during the data review and validation processes.

In addition to primary qualifying flags, secondary "sub-qualifier" flags were also applied. The secondary qualifiers provide the reasoning behind the assignment of a primary qualifier flag to the data.

Attachment 1 lists the changes in data qualifiers, due to the validation process. It contains columns for the Laboratory Qualifier (Lab Qual) as received from the laboratory, primary qualifiers (Final Qual), and secondary qualifiers (Validation Reasons). The primary and secondary qualifiers are presented and defined below.

The following primary flags were used to qualify the data:

- [=] Detected. The analyte was analyzed for and detected at the concentration shown.
- [J] Estimated. The analyte was present but the reported value may not be accurate or precise.
- [U] Undetected. The analyte was analyzed for but not detected above the method detection limit.
- [UJ] Detection limit estimated. The analyte was analyzed for but qualified as not detected; the result is estimated.
- [R] Rejected. The data is not useable.

The following Secondary Qualifier Codes were used to qualify the data.

Validation Reason	Definition						
2SH	Second source calibration verification standard greater than the upper control limit						
2SL	Second source calibration verification standard less than the lower control limit						
ABH	Ambient blank concentration greater than the RL						
ABL	Ambient blank concentration less than the RL						
BKD	result is qualified because the DDT and/or Endrin breakdown was greater than 20%.						
CBKD	The result is qualified because the combined DDT/Endrin breakdown is greater than 30%.						
ССВН	Continuing calibration blank concentration greater than the RL						
CCBL	Continuing calibration blank concentration less than RL						
ccc	CCC Failure						
CCRRF	Continuing calibration relative response factor below the LCL						
CCVF	Continuing Calibration not analyzed at the required frequency						
ССУН	Continuing calibration recovery greater than upper control limit						
CCVL	Continuing calibration recovery less than lower control limit						
CF	Confirmation result						
CFP	Confirmation precision exceeded						
СО	Compounds were reported combined on one column						
DL	Secondary dilution						
EBH	Equipment blank concentration greater than the RL						
EBL	Equipment blank concentration less than the RL						
EMPC	Estimated Maximum Possible Concentration Reported						
FBH	Field blank concentration greater than the RL						

SED VAR EVAL REPORT-FINAL\_CORRECT TEO.DOC

B-13

Validation Reason	Definition
FBL	Field blank concentration less than the RL
FD	Field duplicate exceeds RPD criteria
GPC	The results are qualified due to GPC calibration deficiencies.
НТА	Analytical Holding Time exceeded
HTP	Preparation Holding Time exceeded
IB	Result between the MDL and RL
ICBH	Initial calibration blank concentration greater than the RL
ICBL	Initial calibration blank concentration less than RL
ICR2	Initial calibration exceeded the R2 for first order regression
ICRR	Exceeds RSD criteria and initial calibration exceeded the R2 for first order regression
ICRRF	Initial calibration relative response factor below the LCL
ICRSD	Initial calibration RSD exceeded
ICSP	Single Point Initial Calibration used for Quantitation
ICVSH	Initial calibration verification recovery greater than upper control limit
ICVSL	Initial calibration verification recovery less than lower control limit
ISH	Internal standard response exceeded the UCL criteria
ISL	Internal standard response exceeded the LCL criteria
LBH	Laboratory blank contamination greater than the RL
LBL	Laboratory blank contamination less than the RL
LCSDH	LCSD recovery greater than criteria
LCSDL	LCSD recovery less than the criteria
LCSH	LCS recovery greater than criteria

SED VAR EVAL REPORT-FINAL\_CORRECT TEO.DOC

B-14

Validation Reason	Definition
LCSL	LCS recovery less than the criteria
LCSP	LCS/LCSD RPD criteria exceeded
LDP	Laboratory Duplicate Precision out
LR	Linear range exceeded. Concentration above linear range.
MSA	Quantitated by the method of standard additions
MSALL	Global matrix spike flagging
MSAR2	method of standard additions R2 out
MSDH	Matrix spike duplicate recovery criteria greater than the upper limit
MSDL	Matrix spike duplicate recovery criteria less than the lower limit
MSDP	Matrix Spike Duplicate RPD criteria exceedance
MSH	Matrix spike recovery criteria greater than the upper limit
MSL	Matrix spike recovery criteria less than the lower limit
NMS	Not Site-specific Matrix Spike
PH	Sample pH out. Not properly preserved.
PRM	Result differs from Preliminary Result
PSH	Post spike recovery criteria greater than the upper limit
PSL	Post spike recovery criteria less than the lower limit
RA	Sample was reanalyzed
RE	Sample was re-extracted and reanalyzed
RT	Result is outside the laboratory determined retention time window
SCRN	Screening method and/or data
SDIL	Serial Dilution %D exceeds the upper control limit

SED VAR EVAL REPORT-FINAL\_CORRECT TEQ.DOC

B-15

Validation Reason	Definition
SPCC	SPCC Failure
SSH	Surrogate recovery greater than upper limit
SSL	Surrogate recovery less than lower limit
SSR	Surrogate spike recovery <10%
ТВН	Trip blank concentration greater than the RL
TBL	Trip blank concentration less than the RL
TD	Total Concentration < Dissolved Concentration
TEMP	Cooler temperature out upon arrival
TIC	Tentatively identified compound
TN	GC/MS tune does not meet criteria
xcc	No Continuing Calibration analyzed in the analytical batch
X-DL	Data not used due to dilution; another value is more appropriate or data was not requested
XIC	No initial calibration analyzed in the analytical batch
XICVS	Initial calibration verification standard was not analyzed
XLCS	No LCS in the analytical batch
XLD	Laboratory Duplicate not reported
XMS	Matrix Spike not reported
XMSD	Matrix Spike Duplicate not reported
X-RE	Data not used due to reanalysis another value is more appropriate or data was not requested

SED VAR EVAL REPORT-FINAL\_CORRECT TEO.DOC

B-16

TABLE B.2-1 Chemical Analytical Methods – Field and Quality Control Samples *Dow MOCA* 

Matrix	SDG	Lab Sample ID	Sample ID	Sample Alias	Sample Type	Date Collected	SW8290 Dioxins
Sediment	25125	001	070204-SED-02775-00.3	THT-02775	N	07/02/2004	X
Sediment	25125	002	070104-SED-02782-00.3	THT-02782	N	07/01/2004	X
Sediment	25125	003	070104-SED-02777-00.3	THT-02777	N	07/01/2004	X
Sediment	25125	004	070104-SED-02776-00.3	THT-02776	N	07/01/2004	X
Sediment	25125	005	070104-SED-02779-00.3	THT-02779	N	07/01/2004	X
Sediment	25125	006	070704-SED-02795-00.3	SHL-02795	N	07/07/2004	X
Sediment	25125	007	070704-SED-02804-00.3	SHL-02804	N	07/07/2004	X
Sediment	25125	800	070704-SED-02794-00.3	SHL-02794	N	07/07/2004	X
Sediment	25125	009	070704-SED-02793-00.3	SHL-02793	N	07/07/2004	X
Sediment	25125	010	070804-SED-02792-00.3	SHL-02792	N	07/08/2004	X
Water	25125	011	070804-QCW-02815-R		EB	07/08/2004	X
Sediment	25125	012	070904-SED-2816-00.3	SHL-2816	N	07/09/2004	X
Sediment	25125	013	070904-SED-2817-00.3	SHL-2817	N	07/09/2004	X
Sediment	25125	014	070904-SED-2818-00.3	SHL-2818	N	07/09/2004	X
SAMPLE 1	YPE CODE						
N – Native	Sample						
EB – Equip	ment Blank						

EB – Equipment Blank

**TABLE B.2-2** Changed Qualifiers

Parameter Class	Analytical Method	Parameter	SDG	Sample ID	Lab Sample ID	Matrix	Lab Result	Lab Qual	Final Result	Final Qual	Units	Reasons
DIOXINS	8290	2,3,7,8-TCDF	25125	070704-SED-02795-00.3	006	SED	1740	Е	1740	J	pg/G	LR
DIOXINS	8290	Total TCDF	25125	070704-SED-02795-00.3	006	SED	3800	Е	3800	J	pg/G	LR
DIOXINS	8290	2,3,7,8-TCDF	25125	070704-SED-02794-00.3	008	SED	1200	Е	1200	J	pg/G	LR
DIOXINS	8290	Total TCDF	25125	070704-SED-02794-00.3	008	SED	3340	Е	3340	J	pg/G	LR
DIOXINS	8290	OCDD	25125	070904-SED-2817-00.3	013	SED	12900	Е	12900	J	pg/G	LR
DIOXINS	8290	2,3,7,8-TCDF	25125	070904-SED-2818-00.3	014	SED	2730	Е	2730	J	pg/G	LR
DIOXINS	8290	Total TCDF	25125	070904-SED-2818-00.3	014	SED	6530	Е	6530	J	pg/G	LR

#### **Dioxin/Furan Parameters**

### **Quality Control Review**

The following list represents the QA/QC measures that were reviewed during the data quality evaluation procedure for the dioxin/furan data.

- **Holding Times** The holding times are evaluated to verify that samples were extracted and analyzed within holding times.
- **Blank Samples** Method blanks and equipment blanks were provided for this project. Blank samples enable the reviewer to determine if an analyte may be attributed to sampling or laboratory procedures, rather than environmental contamination from site activities.
- Labeled Standard and Cleanup Standard Recoveries Labeled Standard and Cleanup Standard are added to each sample. The recoveries are used to monitor laboratory and method performance, and possible matrix interference.
- Lab Control Sample/Lab Control Sample Duplicate (LCS/LCSD) These samples are a "controlled matrix," in which target compounds have been added prior to extraction/analysis. The recoveries serve as a monitor of the overall performance of each step during the analysis, including sample preparation.
- Matrix Spike/Matrix Spike Duplicate (MS/MSD) Samples Spike recovery is used to
  evaluate potential matrix interferences, as well as accuracy. Precision information is also
  determined by calculating the reproducibility between the recoveries of each spiked
  parameter.
- **Field Duplicate Samples** These samples are collected to determine precision between a native and its duplicate. This information can only be determined when target compounds are detected.
- **GC/MS Tuning** The mass spectrum of the tuning compound is evaluated for method compliance. The criteria are established to verify the proper mass assignment and mass resolution. In addition, the column performance check and window defining mix summaries are evaluated.
- **Initial Calibration** The initial calibration ensures that the instrument is capable of producing acceptable qualitative and quantitative data for the compounds of interest.
- Continuing Calibration The continuing calibration checks satisfactory performance of the instrument and its predicted response to the target compounds, including retention times and abundance ratios.
- **Internal Standards** The internal standards (retention time and response) are evaluated for method compliance. The internal standards are used in quantitation of the target parameters and monitor the instrument sensitivity and response for stability during each analysis.

• **Second Column Confirmation** – Second column confirmation is evaluated when a secondary analysis is required due to interferences or co-elution.

# Dioxin/Furan Analyses by SW-846 8290

The QA/QC parameters for dioxin/furan analyses by SW-846 8290 for all of the samples were within acceptable control limits, except as noted below:

#### Linear Range

There were selected results in which the sample concentration exceeded the concentration of the calibration curve. However, the laboratory does not dilute and re-analyze dioxin/furan samples unless the signal saturates the instrument detector. The signal did not saturate the detector and linearity was maintained. Therefore, the sample results were qualified "J," as estimated.

The sample results qualified due to linear range exceedances are listed in Attachment 1 with a Validation Note of "LR."

# Rejected Data

No data were rejected based upon the validation process for this sampling event.

#### Conclusion

A review of the analytical data submitted for the Sediment Variability Study has been completed. An overall evaluation of the data indicates that the sample handling, shipment, and analytical procedures have been adequately completed. The validation review demonstrated that the analytical systems were generally in control and the data results can be used in the decision making process.

Appendix C Dioxin/Furan Congener-Specific Sediment Sample Results

**TABLE C-1**Sample Results for Specific Congeners, Fall 2003 Sediment Sampling Event Dow MOCA Sediment Variability Evaluation

Dow MOCA Sediment Varia				
Sample ID	CAS#	Analyte	Reported Value Units	Qualifier
110703-SED-02236-00.3	1746-01-6	2,3,7,8-TCDD	1.35 pg/g	=
110703-SED-02236-00.3	40321-76-4	1,2,3,7,8-PECDD	0.958 pg/g	=
110703-SED-02236-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	0.811 pg/g	=
110703-SED-02236-00.3	57653-85-7	1,2,3,6,7,8-HXCDD	1.94 pg/g	U
110703-SED-02236-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	0.83 pg/g	=
110703-SED-02236-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD	15 pg/g	=
110703-SED-02236-00.3	3268-87-9	OCDD	116 pg/g	=
110703-SED-02236-00.3	51207-31-9	2,3,7,8-TCDF	44 pg/g	=
110703-SED-02236-00.3	57117-41-6	1,2,3,7,8-PECDF	13.3 pg/g	=
110703-SED-02236-00.3	57117-31-4	2,3,4,7,8-PECDF	13.1 pg/g	=
110703-SED-02236-00.3	70648-26-9	1,2,3,4,7,8-HXCDF	9.48 pg/g	=
110703-SED-02236-00.3	57117-44-9	1,2,3,6,7,8-HXCDF	3.04 pg/g	=
110703-SED-02236-00.3	60851-34-5	2,3,4,6,7,8-HXCDF	1.86 pg/g	=
110703-SED-02236-00.3	72918-21-9	1,2,3,7,8,9-HXCDF	2.34 pg/g	
110703-SED-02236-00.3 110703-SED-02236-00.3				=
	67562-39-4	1,2,3,4,6,7,8-HPCDF	17.1 pg/g	=
110703-SED-02236-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF	1.78 pg/g	U
110703-SED-02236-00.3	39001-02-0	OCDF	33.7 pg/g	=
110703-SED-02238-00.3	1746-01-6	2,3,7,8-TCDD	2.55 pg/g	=
110703-SED-02238-00.3	40321-76-4	1,2,3,7,8-PECDD	1.35 pg/g	=
110703-SED-02238-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	0.431 pg/g	U
110703-SED-02238-00.3	57653-85-7	1,2,3,6,7,8-HXCDD	3 pg/g	=
110703-SED-02238-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	1.05 pg/g	=
110703-SED-02238-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD	39.4 pg/g	=
110703-SED-02238-00.3	3268-87-9	OCDD	296 pg/g	=
110703-SED-02238-00.3	51207-31-9	2,3,7,8-TCDF	105 pg/g	=
110703-SED-02238-00.3	57117-41-6	1,2,3,7,8-PECDF	33.8 pg/g	=
110703-SED-02238-00.3	57117-31-4	2,3,4,7,8-PECDF	32.8 pg/g	=
110703-SED-02238-00.3	70648-26-9	1,2,3,4,7,8-HXCDF	23.1 pg/g	=
110703-SED-02238-00.3	57117-44-9	1,2,3,6,7,8-HXCDF	5.15 pg/g	=
110703-SED-02238-00.3	60851-34-5	2,3,4,6,7,8-HXCDF	3.22 pg/g	=
110703-SED-02238-00.3	72918-21-9	1,2,3,7,8,9-HXCDF	3.68 pg/g	=
110703-SED-02238-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF	40.7 pg/g	=
110703-SED-02238-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF	3.5 pg/g	=
110703-SED-02238-00.3		OCDF		
	39001-02-0		67.5 pg/g	=
111203-SED-02245-00.3	1746-01-6	2,3,7,8-TCDD	6.66 pg/g	=
111203-SED-02245-00.3	40321-76-4	1,2,3,7,8-PECDD	6.09 pg/g	U
111203-SED-02245-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	1.86 pg/g	=
111203-SED-02245-00.3	57653-85-7	1,2,3,6,7,8-HXCDD	6.89 pg/g	=
111203-SED-02245-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	2.02 pg/g	=
111203-SED-02245-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD	47.2 pg/g	=
111203-SED-02245-00.3	3268-87-9	OCDD	311 pg/g	=
111203-SED-02245-00.3	51207-31-9	2,3,7,8-TCDF	17900 pg/g	=
111203-SED-02245-00.3	57117-41-6	1,2,3,7,8-PECDF	14200 pg/g	J
111203-SED-02245-00.3	57117-31-4	2,3,4,7,8-PECDF	10900 pg/g	J
111203-SED-02245-00.3	70648-26-9	1,2,3,4,7,8-HXCDF	8630 pg/g	J
111203-SED-02245-00.3	57117-44-9	1,2,3,6,7,8-HXCDF	1900 pg/g	=
111203-SED-02245-00.3	60851-34-5	2,3,4,6,7,8-HXCDF	977 pg/g	=
111203-SED-02245-00.3	72918-21-9	1,2,3,7,8,9-HXCDF	1860 pg/g	=
111203-SED-02245-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF	961 pg/g	=
111203-SED-02245-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF	412 pg/g	=
111203-SED-02245-00.3	39001-02-0	OCDF	222 pg/g	=
111403-SED-02250-00.3	1746-01-6	2,3,7,8-TCDD	0.891 pg/g	
	40321-76-4			=
111403-SED-02250-00.3		1,2,3,7,8-PECDD	0.526 pg/g	=
111403-SED-02250-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	0.39 pg/g	U
111403-SED-02250-00.3	57653-85-7	1,2,3,6,7,8-HXCDD	1.15 pg/g	=
111403-SED-02250-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	0.609 pg/g	U
111403-SED-02250-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD	15.2 pg/g	=
111403-SED-02250-00.3	3268-87-9	OCDD	119 pg/g	=
111403-SED-02250-00.3	51207-31-9	2,3,7,8-TCDF	44.7 pg/g	=
111403-SED-02250-00.3	57117-41-6	1,2,3,7,8-PECDF	14.9 pg/g	=

**TABLE C-1**Sample Results for Specific Congeners, Fall 2003 Sediment Sampling Event Dow MOCA Sediment Variability Evaluation

Dow MOCA Sediment Vai			lp ,	11.	1 0 ""
Sample ID	CAS #	Analyte	Reported Value		Qualifier
111403-SED-02250-00.3	57117-31-4	2,3,4,7,8-PECDF	12.8		=
111403-SED-02250-00.3	70648-26-9	1,2,3,4,7,8-HXCDF	11.7		=
111403-SED-02250-00.3	57117-44-9	1,2,3,6,7,8-HXCDF	2.74		=
111403-SED-02250-00.3	60851-34-5	2,3,4,6,7,8-HXCDF		pg/g	=
111403-SED-02250-00.3	72918-21-9	1,2,3,7,8,9-HXCDF	2.14		=
111403-SED-02250-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF	28.5		=
111403-SED-02250-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF	2.03		=
111403-SED-02250-00.3	39001-02-0	OCDF	36.8		=
111703-SED-02251-00.3	1746-01-6	2,3,7,8-TCDD	0.37		=
111703-SED-02251-00.3	40321-76-4	1,2,3,7,8-PECDD	0.269		=
111703-SED-02251-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	0.347	pg/g	=
111703-SED-02251-00.3	57653-85-7	1,2,3,6,7,8-HXCDD	0.923	pg/g	=
111703-SED-02251-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	0.369	pg/g	U
111703-SED-02251-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD	11.3		=
111703-SED-02251-00.3	3268-87-9	OCDD		pg/g	=
111703-SED-02251-00.3	51207-31-9	2,3,7,8-TCDF	29.4		=
111703-SED-02251-00.3	57117-41-6	1,2,3,7,8-PECDF	11.5		=
111703-SED-02251-00.3	57117-31-4	2,3,4,7,8-PECDF	11.3		=
111703-SED-02251-00.3	70648-26-9	1,2,3,4,7,8-HXCDF	7.93		=
111703-SED-02251-00.3	57117-44-9	1,2,3,6,7,8-HXCDF	3.18		=
111703-SED-02251-00.3	60851-34-5	2,3,4,6,7,8-HXCDF	1.18		=
111703-SED-02251-00.3	72918-21-9	1,2,3,7,8,9-HXCDF	1.46		-  =
111703-SED-02251-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF	9.54		-  =
111703-SED-02251-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF	1.26		-  =
111703-SED-02251-00.3	39001-02-0	OCDF	22.3		<u> -</u>  =
111803-SED-02253-00.3	1746-01-6	2,3,7,8-TCDD			
111803-SED-02253-00.3	40321-76-4		0.242		U
		1,2,3,7,8-PECDD	0.334		
111803-SED-02253-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	0.315		U
111803-SED-02253-00.3	57653-85-7	1,2,3,6,7,8-HXCDD	0.455		=
111803-SED-02253-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	0.32		U
111803-SED-02253-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD	4.78		=
111803-SED-02253-00.3	3268-87-9	OCDD	35.3		=
111803-SED-02253-00.3	51207-31-9	2,3,7,8-TCDF	3.66		=
111803-SED-02253-00.3	57117-41-6	1,2,3,7,8-PECDF	3.99		=
111803-SED-02253-00.3	57117-31-4	2,3,4,7,8-PECDF	2.18		=
111803-SED-02253-00.3	70648-26-9	1,2,3,4,7,8-HXCDF	12.1	pg/g	=
111803-SED-02253-00.3	57117-44-9	1,2,3,6,7,8-HXCDF	2.07		=
111803-SED-02253-00.3	60851-34-5	2,3,4,6,7,8-HXCDF	0.649		=
111803-SED-02253-00.3	72918-21-9	1,2,3,7,8,9-HXCDF	1.02	pg/g	=
111803-SED-02253-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF	6.25	pg/g	=
111803-SED-02253-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF	2.7	pg/g	=
111803-SED-02253-00.3	39001-02-0	OCDF	16.4	pg/g	=
112403-SED-02232-00.3	1746-01-6	2,3,7,8-TCDD	1.74	pg/g	=
112403-SED-02232-00.3	40321-76-4	1,2,3,7,8-PECDD	1.03	pg/g	=
112403-SED-02232-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	0.514		=
112403-SED-02232-00.3	57653-85-7	1,2,3,6,7,8-HXCDD	1.86		=
112403-SED-02232-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	0.73		=
112403-SED-02232-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD	16.6		=
112403-SED-02232-00.3	3268-87-9	OCDD		pg/g	=
112403-SED-02232-00.3	51207-31-9	2,3,7,8-TCDF		pg/g	=
112403-SED-02232-00.3	57117-41-6	1,2,3,7,8-PECDF	66.7		=
112403-SED-02232-00.3	57117-31-4	2,3,4,7,8-PECDF	60.9		=
112403-SED-02232-00.3	70648-26-9	1,2,3,4,7,8-HXCDF	28.1		<u>-</u>  =
112403-SED-02232-00.3	57117-44-9	1,2,3,6,7,8-HXCDF			
			6.96		=
112403-SED-02232-00.3	60851-34-5	2,3,4,6,7,8-HXCDF	5.06		=
112403-SED-02232-00.3	72918-21-9	1,2,3,7,8,9-HXCDF	5.67		=
112403-SED-02232-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF	18.6		=
112403-SED-02232-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF	2.19		=
112403-SED-02232-00.3	39001-02-0	OCDF	22.9		=
112503-SED-02233-00.3	1746-01-6	2,3,7,8-TCDD	1.09	pg/g	=

Dow MOCA Sediment Varial					
Sample ID	CAS#	Analyte	Reported Value		Qualifier
112503-SED-02233-00.3	40321-76-4	1,2,3,7,8-PECDD	0.648		=
112503-SED-02233-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	0.502		U
112503-SED-02233-00.3	57653-85-7	1,2,3,6,7,8-HXCDD		pg/g	=
112503-SED-02233-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	0.507	pg/g	U
112503-SED-02233-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD		pg/g	=
112503-SED-02233-00.3	3268-87-9	OCDD		pg/g	=
112503-SED-02233-00.3	51207-31-9	2,3,7,8-TCDF		pg/g	=
112503-SED-02233-00.3	57117-41-6	1,2,3,7,8-PECDF		pg/g	=
112503-SED-02233-00.3	57117-31-4	2,3,4,7,8-PECDF		pg/g	=
112503-SED-02233-00.3	70648-26-9	1,2,3,4,7,8-HXCDF		pg/g	=
112503-SED-02233-00.3	57117-44-9	1,2,3,6,7,8-HXCDF		pg/g	=
112503-SED-02233-00.3	60851-34-5	2,3,4,6,7,8-HXCDF		pg/g	=
112503-SED-02233-00.3	72918-21-9	1,2,3,7,8,9-HXCDF		pg/g	=
112503-SED-02233-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF		pg/g	=
112503-SED-02233-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF		pg/g pg/g	U
112503-SED-02233-00.3	39001-02-0	OCDF		pg/g	=
112603-SED-02234-00.3	1746-01-6	2,3,7,8-TCDD	0.552		=
112603-SED-02234-00.3	40321-76-4	1,2,3,7,8-PECDD	0.385		=
112603-SED-02234-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	0.314		U
112603-SED-02234-00.3	57653-85-7	1,2,3,6,7,8-HXCDD	0.613		=
112603-SED-02234-00.3	19408-74-3	1,2,3,7,8,9-HXCDD		pg/g	U
112603-SED-02234-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD		pg/g	=
112603-SED-02234-00.3	3268-87-9	OCDD		pg/g	=
112603-SED-02234-00.3	51207-31-9	2,3,7,8-TCDF		pg/g	=
112603-SED-02234-00.3	57117-41-6	1,2,3,7,8-PECDF		pg/g	=
112603-SED-02234-00.3	57117-31-4	2,3,4,7,8-PECDF		pg/g	=
112603-SED-02234-00.3	70648-26-9	1,2,3,4,7,8-HXCDF		pg/g	=
112603-SED-02234-00.3	57117-44-9	1,2,3,6,7,8-HXCDF		pg/g	=
112603-SED-02234-00.3	60851-34-5	2,3,4,6,7,8-HXCDF	0.738		=
112603-SED-02234-00.3	72918-21-9	1,2,3,7,8,9-HXCDF	0.608		U
112603-SED-02234-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF		pg/g	=
112603-SED-02234-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF	0.814		=
112603-SED-02234-00.3	39001-02-0	OCDF		pg/g	=
112603-SED-02235-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF		pg/g	=
112603-SED-02235-00.3	39001-02-0	OCDF		pg/g	=
112603-SED-02235-00.3	1746-01-6	2,3,7,8-TCDD	7.06	pg/g	=
112603-SED-02235-00.3	40321-76-4	1,2,3,7,8-PECDD		pg/g pg/g	=
112603-SED-02235-00.3	39227-28-6	1,2,3,4,7,8-HXCDD		pg/g pg/g	
112603-SED-02235-00.3 112603-SED-02235-00.3		1,2,3,4,7,8-HXCDD 1,2,3,6,7,8-HXCDD			=
112603-SED-02235-00.3 112603-SED-02235-00.3	57653-85-7 19408-74-3			pg/g	=
		1,2,3,7,8,9-HXCDD		pg/g	=
112603-SED-02235-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD		pg/g	=
112603-SED-02235-00.3	3268-87-9	OCDD	2680		=
112603-SED-02235-00.3	51207-31-9	2,3,7,8-TCDF	7330		J
112603-SED-02235-00.3	57117-41-6	1,2,3,7,8-PECDF	3180		J
112603-SED-02235-00.3	57117-31-4	2,3,4,7,8-PECDF	3350		J
112603-SED-02235-00.3	70648-26-9	1,2,3,4,7,8-HXCDF	1660		=
112603-SED-02235-00.3	57117-44-9	1,2,3,6,7,8-HXCDF		pg/g	=
112603-SED-02235-00.3	60851-34-5	2,3,4,6,7,8-HXCDF		pg/g	=
112603-SED-02235-00.3	72918-21-9	1,2,3,7,8,9-HXCDF		pg/g	=
112603-SED-02235-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF	622	pg/g	=
120103-SED-02237-00.3	57117-44-9	1,2,3,6,7,8-HXCDF		pg/g	=
120103-SED-02237-00.3	60851-34-5	2,3,4,6,7,8-HXCDF		pg/g	=
120103-SED-02237-00.3	72918-21-9	1,2,3,7,8,9-HXCDF		pg/g	=
120103-SED-02237-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF		pg/g	=
120103-SED-02237-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF		pg/g	=
120103-SED-02237-00.3	39001-02-0	OCDF		pg/g	=
120103-SED-02237-00.3	1746-01-6	2,3,7,8-TCDD	0.986		=
120103-SED-02237-00.3	40321-76-4	1,2,3,7,8-PECDD	0.900		=
120103-SED-02237-00.3	39227-28-6	1,2,3,4,7,8-HXCDD		pg/g pg/g	U
120103-SED-02237-00.3 120103-SED-02237-00.3	57653-85-7			pg/g pg/g	
120103-3ED-02237-00.3	J1000-00-1	1,2,3,6,7,8-HXCDD	3.81	P9/9	=

Dow MOCA Sediment Varia		Analyta	Donortod Volum	l loita	Qualifier
Sample ID	CAS #	Analyte	Reported Value		Qualifier U
120103-SED-02237-00.3 120103-SED-02237-00.3	19408-74-3 35822-46-9	1,2,3,7,8,9-HXCDD 1,2,3,4,6,7,8-HPCDD		pg/g	=
				pg/g	
120103-SED-02237-00.3	3268-87-9	OCDD		pg/g	=
120103-SED-02237-00.3	51207-31-9	2,3,7,8-TCDF		pg/g	=
120103-SED-02237-00.3	57117-41-6	1,2,3,7,8-PECDF		pg/g	=
120103-SED-02237-00.3	57117-31-4	2,3,4,7,8-PECDF		pg/g	=
120103-SED-02237-00.3	70648-26-9	1,2,3,4,7,8-HXCDF		pg/g	=
120203-SED-02239-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF		pg/g	=
120203-SED-02239-00.3	39001-02-0	OCDF		pg/g	=
120203-SED-02239-00.3	1746-01-6	2,3,7,8-TCDD		pg/g	=
120203-SED-02239-00.3	40321-76-4	1,2,3,7,8-PECDD	0.621		=
120203-SED-02239-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	0.654		U
120203-SED-02239-00.3	57653-85-7	1,2,3,6,7,8-HXCDD	0.682	pg/g	=
120203-SED-02239-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	0.607		U
120203-SED-02239-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD		pg/g	=
120203-SED-02239-00.3	3268-87-9	OCDD		pg/g	J
120203-SED-02239-00.3	51207-31-9	2,3,7,8-TCDF		pg/g	=
120203-SED-02239-00.3	57117-41-6	1,2,3,7,8-PECDF		pg/g	=
120203-SED-02239-00.3	57117-31-4	2,3,4,7,8-PECDF		pg/g pg/g	=
120203-SED-02239-00.3	70648-26-9	1,2,3,4,7,8-HXCDF		pg/g pg/g	=
120203-SED-02239-00.3	57117-44-9	1,2,3,4,7,8-HXCDF		pg/g pg/g	=
	60851-34-5				
120203-SED-02239-00.3	1	2,3,4,6,7,8-HXCDF		pg/g	=
120203-SED-02239-00.3	72918-21-9	1,2,3,7,8,9-HXCDF		pg/g	=
120203-SED-02239-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF		pg/g	=
120203-SED-02240-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF	0.624	pg/g	=
120203-SED-02240-00.3	39001-02-0	OCDF		pg/g	=
120203-SED-02240-00.3	1746-01-6	2,3,7,8-TCDD	0.782		=
120203-SED-02240-00.3	40321-76-4	1,2,3,7,8-PECDD		pg/g	=
120203-SED-02240-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	0.638		U
120203-SED-02240-00.3	57653-85-7	1,2,3,6,7,8-HXCDD	0.812		=
120203-SED-02240-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	0.636		U
120203-SED-02240-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD		pg/g	=
120203-SED-02240-00.3	3268-87-9	OCDD		pg/g	=
120203-SED-02240-00.3	51207-31-9	2,3,7,8-TCDF		pg/g	=
120203-SED-02240-00.3	57117-41-6	1,2,3,7,8-PECDF	4.17	pg/g	=
120203-SED-02240-00.3	57117-31-4	2,3,4,7,8-PECDF		pg/g	=
120203-SED-02240-00.3	70648-26-9	1,2,3,4,7,8-HXCDF		pg/g	=
120203-SED-02240-00.3	57117-44-9	1,2,3,6,7,8-HXCDF	0.883		=
120203-SED-02240-00.3	60851-34-5	2,3,4,6,7,8-HXCDF	0.687		U
120203-SED-02240-00.3	72918-21-9	1,2,3,7,8,9-HXCDF	0.654		=
120203-SED-02240-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF		pg/g	=
120203-SED-02269-00.3-D	1746-01-6	2,3,7,8-TCDD	0.255		U
120203-SED-02269-00.3-D	40321-76-4	1,2,3,7,8-PECDD	0.172		=
120203-SED-02269-00.3-D	39227-28-6	1,2,3,4,7,8-HXCDD	0.306		U
120203-SED-02269-00.3-D	57653-85-7	1,2,3,6,7,8-HXCDD	0.581		=
120203-SED-02269-00.3-D	19408-74-3	1,2,3,7,8,9-HXCDD	0.361		
120203-SED-02269-00.3-D	35822-46-9	1,2,3,4,6,7,8-HPCDD		pg/g pg/g	=  -
		OCDD			=  -
120203-SED-02269-00.3-D	3268-87-9			pg/g	=
120203-SED-02269-00.3-D	51207-31-9	2,3,7,8-TCDF		pg/g	=
120203-SED-02269-00.3-D	57117-41-6	1,2,3,7,8-PECDF		pg/g	=
120203-SED-02269-00.3-D	57117-31-4	2,3,4,7,8-PECDF		pg/g	=
120203-SED-02269-00.3-D	70648-26-9	1,2,3,4,7,8-HXCDF	0.978		=
120203-SED-02269-00.3-D	57117-44-9	1,2,3,6,7,8-HXCDF	0.758		=
120203-SED-02269-00.3-D	60851-34-5	2,3,4,6,7,8-HXCDF	0.444		=
120203-SED-02269-00.3-D	72918-21-9	1,2,3,7,8,9-HXCDF	0.267		U
120203-SED-02269-00.3-D	67562-39-4	1,2,3,4,6,7,8-HPCDF		pg/g	=
120203-SED-02269-00.3-D	55673-89-7	1,2,3,4,7,8,9-HPCDF	0.257	pg/g	U
120203-SED-02269-00.3-D	39001-02-0	OCDF		pg/g	=
120303-SED-02241-00.3	1746-01-6	2,3,7,8-TCDD	1	pg/g	=
120303-SED-02241-00.3	40321-76-4	1,2,3,7,8-PECDD		pg/g	=
		. , , , , - ===	2.10		

Dow MOCA Sediment Varia					
Sample ID	CAS#	Analyte	Reported Value		Qualifier
120303-SED-02241-00.3	39227-28-6	1,2,3,4,7,8-HXCDD		pg/g	U
120303-SED-02241-00.3	57653-85-7	1,2,3,6,7,8-HXCDD		pg/g	=
120303-SED-02241-00.3	19408-74-3	1,2,3,7,8,9-HXCDD		pg/g	=
120303-SED-02241-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD		pg/g	=
120303-SED-02241-00.3	3268-87-9	OCDD	7640		J
120303-SED-02241-00.3	51207-31-9	2,3,7,8-TCDF	48.6	pg/g	=
120303-SED-02241-00.3	57117-41-6	1,2,3,7,8-PECDF		pg/g	=
120303-SED-02241-00.3	57117-31-4	2,3,4,7,8-PECDF	31.6	pg/g	=
120303-SED-02241-00.3	70648-26-9	1,2,3,4,7,8-HXCDF	73.7	pg/g	=
120303-SED-02241-00.3	57117-44-9	1,2,3,6,7,8-HXCDF		pg/g	=
120303-SED-02241-00.3	60851-34-5	2,3,4,6,7,8-HXCDF	22.2	pg/g	=
120303-SED-02241-00.3	72918-21-9	1,2,3,7,8,9-HXCDF	18.3	pg/g	=
120303-SED-02241-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF	4180	pg/g	J
120303-SED-02241-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF	43.2	pg/g	=
120303-SED-02241-00.3	39001-02-0	OCDF	2900	pg/g	=
120303-SED-02242-00.3	1746-01-6	2,3,7,8-TCDD	2.2	pg/g	=
120303-SED-02242-00.3	40321-76-4	1,2,3,7,8-PECDD		pg/g	=
120303-SED-02242-00.3	39227-28-6	1,2,3,4,7,8-HXCDD		pg/g	=
120303-SED-02242-00.3	57653-85-7	1,2,3,6,7,8-HXCDD		pg/g	=
120303-SED-02242-00.3	19408-74-3	1,2,3,7,8,9-HXCDD		pg/g	=
120303-SED-02242-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD		pg/g	=
120303-SED-02242-00.3	3268-87-9	OCDD	258	pg/g	=
120303-SED-02242-00.3	51207-31-9	2,3,7,8-TCDF	87.3	pg/g	=
120303-SED-02242-00.3	57117-41-6	1,2,3,7,8-PECDF		pg/g	=
120303-SED-02242-00.3	57117-31-4	2,3,4,7,8-PECDF		pg/g	=
120303-SED-02242-00.3	70648-26-9	1,2,3,4,7,8-HXCDF		pg/g	=
120303-SED-02242-00.3	57117-44-9	1,2,3,6,7,8-HXCDF		pg/g	=
120303-SED-02242-00.3	60851-34-5	2,3,4,6,7,8-HXCDF		pg/g	=
120303-SED-02242-00.3	72918-21-9	1,2,3,7,8,9-HXCDF		pg/g	=
120303-SED-02242-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF		pg/g	=
120303 SED 02242 00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF		pg/g	=
120303 SED 02242 00.3	39001-02-0	OCDF		pg/g	-
120403-SED-02243-00.3	1746-01-6	2,3,7,8-TCDD	0.729		=
120403-SED-02243-00.3	40321-76-4	1,2,3,7,8-PECDD	0.435		=
120403-SED-02243-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	0.368		U
120403-SED-02243-00.3	57653-85-7	1,2,3,6,7,8-HXCDD	0.886	pg/g	=
120403-SED-02243-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	0.361		U
120403-SED-02243-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD		pg/g pg/g	=
120403-SED-02243-00.3	3268-87-9	OCDD		pg/g pg/g	=
120403-SED-02243-00.3	51207-31-9	2,3,7,8-TCDF	26.3	pg/g pg/g	=
120403-SED-02243-00.3	57117-41-6	1,2,3,7,8-PECDF	6.66		
120403-SED-02243-00.3	57117-41-6				=
120403-SED-02243-00.3		2,3,4,7,8-PECDF		pg/g	
	70648-26-9	1,2,3,4,7,8-HXCDF		pg/g	<b>=</b>
120403-SED-02243-00.3	57117-44-9	1,2,3,6,7,8-HXCDF		pg/g	=
120403-SED-02243-00.3	60851-34-5	2,3,4,6,7,8-HXCDF	0.916		=
120403-SED-02243-00.3	72918-21-9	1,2,3,7,8,9-HXCDF	0.688		=
120403-SED-02243-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF		pg/g	=
120403-SED-02243-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF	0.716		=
120403-SED-02243-00.3	39001-02-0	OCDF		pg/g	=
120403-SED-02244-00.3	1746-01-6	2,3,7,8-TCDD		pg/g	=
120403-SED-02244-00.3	40321-76-4	1,2,3,7,8-PECDD		pg/g	=
120403-SED-02244-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	0.676		U
120403-SED-02244-00.3	57653-85-7	1,2,3,6,7,8-HXCDD		pg/g	=
120403-SED-02244-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	0.685		U
120403-SED-02244-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD		pg/g	=
120403-SED-02244-00.3	3268-87-9	OCDD		pg/g	J
120403-SED-02244-00.3	51207-31-9	2,3,7,8-TCDF		pg/g	=
120403-SED-02244-00.3	57117-41-6	1,2,3,7,8-PECDF	299	pg/g	=
120403-011-02244-00.3					
120403-SED-02244-00.3	57117-31-4	2,3,4,7,8-PECDF	289	pg/g pg/g	=

Sample ID	CAS#	Analyte	Reported Value		Qualifier
120403-SED-02244-00.3	57117-44-9	1,2,3,6,7,8-HXCDF	34.2		=
20403-SED-02244-00.3	60851-34-5	2,3,4,6,7,8-HXCDF	20.2	pg/g	=
20403-SED-02244-00.3	72918-21-9	1,2,3,7,8,9-HXCDF	37.3	pg/g	=
20403-SED-02244-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF	39.6	pg/g	=
20403-SED-02244-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF	8.82	pg/g	=
20403-SED-02244-00.3	39001-02-0	OCDF	38.6	pg/g	=
20503-SED-02246-00.3	1746-01-6	2,3,7,8-TCDD	0.748		=
20503-SED-02246-00.3	40321-76-4	1,2,3,7,8-PECDD	0.583		=
20503-SED-02246-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	0.303		=
20503-SED-02246-00.3	57653-85-7	1,2,3,6,7,8-HXCDD		pg/g	=
20503-SED-02246-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	0.588		U
20503-SED-02246-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD		pg/g	=
20503-SED-02246-00.3	3268-87-9	OCDD		pg/g	=
20503-SED-02246-00.3	51207-31-9	2,3,7,8-TCDF		pg/g	=
20503-SED-02246-00.3	57117-41-6	1,2,3,7,8-PECDF		pg/g	=
20503-SED-02246-00.3	57117-31-4	2,3,4,7,8-PECDF		pg/g	=
20503-SED-02246-00.3	70648-26-9	1,2,3,4,7,8-HXCDF	52.8	pg/g	=
20503-SED-02246-00.3	57117-44-9	1,2,3,6,7,8-HXCDF	12.3		=
20503-SED-02246-00.3	60851-34-5	2,3,4,6,7,8-HXCDF	8.19		=  =
20503-SED-02246-00.3	72918-21-9	1,2,3,7,8,9-HXCDF		pg/g pg/g	
20503-SED-02246-00.3 20503-SED-02246-00.3	67562-39-4	1,2,3,7,8,9-HXCDF	25.1		=
20503-SED-02246-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF		pg/g pg/g	
					=
20503-SED-02246-00.3	39001-02-0	OCDF	55.5		=
20803-SED-02247-00.3	1746-01-6	2,3,7,8-TCDD		pg/g	=
20803-SED-02247-00.3	40321-76-4	1,2,3,7,8-PECDD	2.55		=
20803-SED-02247-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	1.48		=
20803-SED-02247-00.3	57653-85-7	1,2,3,6,7,8-HXCDD	6.18		=
20803-SED-02247-00.3	19408-74-3	1,2,3,7,8,9-HXCDD		pg/g	=
20803-SED-02247-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD		pg/g	=
20803-SED-02247-00.3	3268-87-9	OCDD		pg/g	J
20803-SED-02247-00.3	51207-31-9	2,3,7,8-TCDF		pg/g	=
20803-SED-02247-00.3	57117-41-6	1,2,3,7,8-PECDF	721	pg/g	=
20803-SED-02247-00.3	57117-31-4	2,3,4,7,8-PECDF	567	pg/g	=
20803-SED-02247-00.3	70648-26-9	1,2,3,4,7,8-HXCDF	464	pg/g	=
20803-SED-02247-00.3	57117-44-9	1,2,3,6,7,8-HXCDF	116	pg/g	=
20803-SED-02247-00.3	60851-34-5	2,3,4,6,7,8-HXCDF	58.5	pg/g	=
20803-SED-02247-00.3	72918-21-9	1,2,3,7,8,9-HXCDF		pg/g	=
20803-SED-02247-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF		pg/g	=
20803-SED-02247-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF		pg/g	=
20803-SED-02247-00.3	39001-02-0	OCDF		pg/g	=
20803-SED-02248-00.3	1746-01-6	2,3,7,8-TCDD	0.973		=
20803-SED-02248-00.3	40321-76-4	1,2,3,7,8-PECDD	0.502		=
20803-SED-02248-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	0.735		U
20803-SED-02248-00.3	57653-85-7	1,2,3,6,7,8-HXCDD		pg/g	=
20803-SED-02248-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	0.667		U
20803-SED-02248-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD		pg/g pg/g	=
20803-SED-02248-00.3	3268-87-9	OCDD		pg/g pg/g	=
20803-SED-02248-00.3	51207-31-9	2,3,7,8-TCDF	24.7		=
20803-SED-02248-00.3	57117-41-6	1,2,3,7,8-PECDF	8.57		=
20803-SED-02248-00.3	57117-41-6	2,3,4,7,8-PECDF			
			8.37		=
20803-SED-02248-00.3	70648-26-9	1,2,3,4,7,8-HXCDF		pg/g	=
20803-SED-02248-00.3	57117-44-9	1,2,3,6,7,8-HXCDF	4.79		=
20803-SED-02248-00.3	60851-34-5	2,3,4,6,7,8-HXCDF		pg/g	=
20803-SED-02248-00.3	72918-21-9	1,2,3,7,8,9-HXCDF		pg/g	U
20803-SED-02248-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF	26.1		=
20803-SED-02248-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF		pg/g	=
20803-SED-02248-00.3	39001-02-0	OCDF	32.6		=
20903-SED-02249-00.3	57117-44-9	1,2,3,6,7,8-HXCDF	3.06	pg/g	=
20903-SED-02249-00.3	60851-34-5	2,3,4,6,7,8-HXCDF		pg/g	=
20903-SED-02249-00.3	72918-21-9	1,2,3,7,8,9-HXCDF	1.62	pg/g	=

**TABLE C-1**Sample Results for Specific Congeners, Fall 2003 Sediment Sampling Event Dow MOCA Sediment Variability Evaluation

Sample ID	CAS #	Analyta	Donortod Value	Lloita	Qualifier
Sample ID 120903-SED-02249-00.3	67562-39-4	Analyte 1,2,3,4,6,7,8-HPCDF	Reported Value 18.8		Qualifier
120903-SED-02249-00.3	55673-89-7	1,2,3,4,6,7,8-HPCDF	2.09	pg/g	=
120903-SED-02249-00.3	39001-02-0	OCDF		pg/g pg/g	
120903-SED-02249-00.3	1746-01-6	2,3,7,8-TCDD	0.757		U
120903-SED-02249-00.3	40321-76-4				
		1,2,3,7,8-PECDD	0.679		=
120903-SED-02249-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	0.477		=
120903-SED-02249-00.3	57653-85-7	1,2,3,6,7,8-HXCDD	1.55		=
120903-SED-02249-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	0.635		=
120903-SED-02249-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD		pg/g	=
120903-SED-02249-00.3	3268-87-9	OCDD		pg/g	=
120903-SED-02249-00.3	51207-31-9	2,3,7,8-TCDF	26.4		=
120903-SED-02249-00.3	57117-41-6	1,2,3,7,8-PECDF	9.82		=
120903-SED-02249-00.3	57117-31-4	2,3,4,7,8-PECDF	9.83		=
120903-SED-02249-00.3	70648-26-9	1,2,3,4,7,8-HXCDF	9.99		=
120903-SED-02252-00.3	1746-01-6	2,3,7,8-TCDD	0.442		=
120903-SED-02252-00.3	40321-76-4	1,2,3,7,8-PECDD	0.505		U
120903-SED-02252-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	0.893		U
120903-SED-02252-00.3	57653-85-7	1,2,3,6,7,8-HXCDD	1.49		=
120903-SED-02252-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	0.727		U
120903-SED-02252-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD	33.1		=
120903-SED-02252-00.3	3268-87-9	OCDD		pg/g	=
120903-SED-02252-00.3	51207-31-9	2,3,7,8-TCDF	8.56		=
120903-SED-02252-00.3	57117-41-6	1,2,3,7,8-PECDF	3.78		=
120903-SED-02252-00.3	57117-31-4	2,3,4,7,8-PECDF	3.23		=
120903-SED-02252-00.3	70648-26-9	1,2,3,4,7,8-HXCDF	5.1	pg/g	=
120903-SED-02252-00.3	57117-44-9	1,2,3,6,7,8-HXCDF	6.34	pg/g	=
120903-SED-02252-00.3	60851-34-5	2,3,4,6,7,8-HXCDF	1.15	pg/g	=
120903-SED-02252-00.3	72918-21-9	1,2,3,7,8,9-HXCDF	0.894	pg/g	=
120903-SED-02252-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF	31	pg/g	=
120903-SED-02252-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF	1.86	pg/g	=
120903-SED-02252-00.3	39001-02-0	OCDF	96.9		=
120903-SED-02270-00.3-D	1746-01-6	2,3,7,8-TCDD	0.718		U
120903-SED-02270-00.3-D	40321-76-4	1,2,3,7,8-PECDD	0.46		=
120903-SED-02270-00.3-D	39227-28-6	1,2,3,4,7,8-HXCDD	0.708		U
120903-SED-02270-00.3-D	57653-85-7	1,2,3,6,7,8-HXCDD	0.98		=
120903-SED-02270-00.3-D	19408-74-3	1,2,3,7,8,9-HXCDD	0.595		U
120903-SED-02270-00.3-D	35822-46-9	1,2,3,4,6,7,8-HPCDD	9.98		=
120903-SED-02270-00.3-D	3268-87-9	OCDD		pg/g	=
120903-SED-02270-00.3-D	51207-31-9	2,3,7,8-TCDF	17.7	pa/a	=
120903-SED-02270-00.3-D	57117-41-6	1,2,3,7,8-PECDF	4.64		=
120903-SED-02270-00.3-D	57117-31-4	2,3,4,7,8-PECDF	5.95		=
120903-SED-02270-00.3-D	70648-26-9	1,2,3,4,7,8-HXCDF	4.11		=
120903-SED-02270-00.3-D	57117-44-9	1,2,3,6,7,8-HXCDF	2.21		=
120903-SED-02270-00.3-D	60851-34-5	2,3,4,6,7,8-HXCDF	1.02		=
120903-SED-02270-00.3-D	72918-21-9	1,2,3,7,8,9-HXCDF	0.861		=
120903-SED-02270-00.3-D	67562-39-4	1,2,3,4,6,7,8-HPCDF	16.4		=
120903-SED-02270-00.3-D	55673-89-7	1,2,3,4,7,8,9-HPCDF	1.33		=
120903-SED-02270-00.3-D	39001-02-0	OCDF	19.9		=
121103-SED-02254-00.3	1746-01-6				U
121103-SED-02254-00.3	40321-76-4	2,3,7,8-TCDD	0.309 0.284		U
	39227-28-6	1,2,3,7,8-PECDD 1,2,3,4,7,8-HXCDD			
121103-SED-02254-00.3 121103-SED-02254-00.3	57653-85-7		0.399		U
		1,2,3,6,7,8-HXCDD	0.783		=
121103-SED-02254-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	0.522		=
121103-SED-02254-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD	12.5		=
121103-SED-02254-00.3	3268-87-9	OCDD	97.2		=
121103-SED-02254-00.3	51207-31-9	2,3,7,8-TCDF	4.65		=
121103-SED-02254-00.3	57117-41-6	1,2,3,7,8-PECDF	2.95		=
121103-SED-02254-00.3	57117-31-4	2,3,4,7,8-PECDF	2.61		=
121103-SED-02254-00.3	70648-26-9	1,2,3,4,7,8-HXCDF	2.04		=
121103-SED-02254-00.3	57117-44-9	1,2,3,6,7,8-HXCDF	0.745	pg/g	=

**TABLE C-1**Sample Results for Specific Congeners, Fall 2003 Sediment Sampling Event Dow MOCA Sediment Variability Evaluation

	,				
Sample ID	CAS#	Analyte	Reported Value	Units	Qualifier
121103-SED-02254-00.3	60851-34-5	2,3,4,6,7,8-HXCDF	0.508	pg/g	U
121103-SED-02254-00.3	72918-21-9	1,2,3,7,8,9-HXCDF	0.366	pg/g	U
121103-SED-02254-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF	5.08	pg/g	=
121103-SED-02254-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF	0.382	pg/g	U
121103-SED-02254-00.3	39001-02-0	OCDF	8.47	pg/g	=
121103-SED-02271-00.3-D	1746-01-6	2,3,7,8-TCDD	3.87	pg/g	=
121103-SED-02271-00.3-D	40321-76-4	1,2,3,7,8-PECDD	3.91	pg/g	=
121103-SED-02271-00.3-D	39227-28-6	1,2,3,4,7,8-HXCDD		pg/g	=
121103-SED-02271-00.3-D	57653-85-7	1,2,3,6,7,8-HXCDD	15.7	pg/g	=
121103-SED-02271-00.3-D	19408-74-3	1,2,3,7,8,9-HXCDD	5.75	pg/g	=
121103-SED-02271-00.3-D	35822-46-9	1,2,3,4,6,7,8-HPCDD	318	pg/g	=
121103-SED-02271-00.3-D	3268-87-9	OCDD	3790		J
121103-SED-02271-00.3-D	51207-31-9	2,3,7,8-TCDF	758	pg/g	=
121103-SED-02271-00.3-D	57117-41-6	1,2,3,7,8-PECDF	501	pg/g	=
121103-SED-02271-00.3-D	57117-31-4	2,3,4,7,8-PECDF	430	pg/g	=
121103-SED-02271-00.3-D	70648-26-9	1,2,3,4,7,8-HXCDF	328	pg/g	=
121103-SED-02271-00.3-D	57117-44-9	1,2,3,6,7,8-HXCDF	71.2	pg/g	=
121103-SED-02271-00.3-D	60851-34-5	2,3,4,6,7,8-HXCDF	42.2	pg/g	=
121103-SED-02271-00.3-D	72918-21-9	1,2,3,7,8,9-HXCDF		pg/g	=
121103-SED-02271-00.3-D	67562-39-4	1,2,3,4,6,7,8-HPCDF	543	pg/g	=
121103-SED-02271-00.3-D	55673-89-7	1,2,3,4,7,8,9-HPCDF	42.7	pg/g	=
121103-SED-02271-00.3-D	39001-02-0	OCDF	1160	pg/g	=

Dow MOCA Sediment Variation	CAS#	Analyte	Reported Value	Units	Qualifier
070104-SED-02776-00.3	1746-01-6	2,3,7,8-TCDD	0.964		=
070104-SED-02776-00.3	40321-76-4	1,2,3,7,8-PECDD	0.49		U
070104-SED-02776-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	0.252		J
070104-SED-02776-00.3	57653-85-7	1,2,3,6,7,8-HXCDD		pg/g	J
070104-SED-02776-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	0.384		J
070104-SED-02776-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD		pg/g	=
070104 SED 02776 00.3	3268-87-9	OCDD	90.7		=
070104-SED-02776-00.3	51207-31-9	2,3,7,8-TCDF	65.5		=
070104 SED 02776 00.3	57117-41-6	1,2,3,7,8-PECDF		pg/g	=
070104-SED-02776-00.3	57117-31-4	2,3,4,7,8-PECDF	24.3		=
070104-SED-02776-00.3	70648-26-9	1,2,3,4,7,8-HXCDF		pg/g pg/g	=
070104-SED-02776-00.3	57117-44-9	1,2,3,6,7,8-HXCDF		pg/g pg/g	=
070104-SED-02776-00.3	60851-34-5	2,3,4,6,7,8-HXCDF		pg/g	J
070104-SED-02776-00.3	72918-21-9	1,2,3,7,8,9-HXCDF		pg/g pg/g	=
070104-SED-02776-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF		pg/g pg/g	=
070104-SED-02776-00.3	55673-89-7				J
		1,2,3,4,7,8,9-HPCDF		pg/g	
070104-SED-02776-00.3 070104-SED-02776-00.3	39001-02-0	OCDF		pg/g	=
	41903-57-5	TOTAL TCDD TOTAL PECDD		pg/g	=
070104-SED-02776-00.3 070104-SED-02776-00.3	36088-22-9	TOTAL PECDD	5.0	pg/g	=
	34465-46-8			pg/g	=
070104-SED-02776-00.3	37871-00-4	TOTAL TODE		pg/g	=
070104-SED-02776-00.3	55722-27-5	TOTAL TCDF		pg/g	=
070104-SED-02776-00.3	30402-15-4	TOTAL PECDF		pg/g	=
070104-SED-02776-00.3	55684-94-1	TOTAL HXCDF		pg/g	=
070104-SED-02776-00.3	38998-75-3	TOTAL HPCDF		pg/g	=
070104-SED-02777-00.3	1746-01-6	2,3,7,8-TCDD		pg/g	=
070104-SED-02777-00.3	40321-76-4	1,2,3,7,8-PECDD	0.552		J
070104-SED-02777-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	0.268		J
070104-SED-02777-00.3	57653-85-7	1,2,3,6,7,8-HXCDD		pg/g	J
070104-SED-02777-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	0.493		J
070104-SED-02777-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD		pg/g	=
070104-SED-02777-00.3	3268-87-9	OCDD		pg/g	=
070104-SED-02777-00.3	51207-31-9	2,3,7,8-TCDF	80.7	pg/g	=
070104-SED-02777-00.3	57117-41-6	1,2,3,7,8-PECDF	23.9	pg/g	=
070104-SED-02777-00.3	57117-31-4	2,3,4,7,8-PECDF		pg/g	=
070104-SED-02777-00.3	70648-26-9	1,2,3,4,7,8-HXCDF		pg/g	=
070104-SED-02777-00.3	57117-44-9	1,2,3,6,7,8-HXCDF		pg/g	=
070104-SED-02777-00.3	60851-34-5	2,3,4,6,7,8-HXCDF		pg/g	J
070104-SED-02777-00.3	72918-21-9	1,2,3,7,8,9-HXCDF	2.47		J
070104-SED-02777-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF		pg/g	=
070104-SED-02777-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF	1.34	pg/g	J
070104-SED-02777-00.3	39001-02-0	OCDF		pg/g	=
070104-SED-02777-00.3	41903-57-5	TOTAL TCDD	10.3	pg/g	=
070104-SED-02777-00.3	36088-22-9	TOTAL PECDD	5.92	pg/g	=
070104-SED-02777-00.3	34465-46-8	TOTAL HXCDD	11.1	pg/g	=
070104-SED-02777-00.3	37871-00-4	TOTAL HPCDD	19.5	pg/g	=
070104-SED-02777-00.3	55722-27-5	TOTAL TCDF	226	pg/g	=
070104-SED-02777-00.3	30402-15-4	TOTAL PECDF		pg/g	=
070104-SED-02777-00.3	55684-94-1	TOTAL HXCDF		pg/g	=
070104-SED-02777-00.3	38998-75-3	TOTAL HPCDF		pg/g	=
070104-SED-02779-00.3	1746-01-6	2,3,7,8-TCDD	0.907		=
070104-SED-02779-00.3	40321-76-4	1,2,3,7,8-PECDD	0.569		J
070104-SED-02779-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	0.249		J
070104-SED-02779-00.3	57653-85-7	1,2,3,6,7,8-HXCDD		pg/g	J
070104-SED-02779-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	0.182		U
070104-SED-02779-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD		pg/g	=

Dow MOCA Sediment Varia					
Sample ID	CAS#	Analyte	Reported Value	Units	Qualifier
070104-SED-02779-00.3	3268-87-9	OCDD	265		=
070104-SED-02779-00.3	51207-31-9	2,3,7,8-TCDF	27.4		=
070104-SED-02779-00.3	57117-41-6	1,2,3,7,8-PECDF	7.58	pg/g	=
070104-SED-02779-00.3	57117-31-4	2,3,4,7,8-PECDF	8.19		=
070104-SED-02779-00.3	70648-26-9	1,2,3,4,7,8-HXCDF	5.53	pg/g	=
070104-SED-02779-00.3	57117-44-9	1,2,3,6,7,8-HXCDF		pg/g	J
070104-SED-02779-00.3	60851-34-5	2,3,4,6,7,8-HXCDF	1.21		J
070104-SED-02779-00.3	72918-21-9	1,2,3,7,8,9-HXCDF	1.02	pg/g	J
070104-SED-02779-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF	18.8	pg/g	=
070104-SED-02779-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF	1.16		J
070104-SED-02779-00.3	39001-02-0	OCDF		pg/g	=
070104-SED-02779-00.3	41903-57-5	TOTAL TCDD	9.48		=
070104-SED-02779-00.3	36088-22-9	TOTAL PECDD	5.82		=
070104-SED-02779-00.3	34465-46-8	TOTAL HXCDD	8.86		=
070104-SED-02779-00.3	37871-00-4	TOTAL HPCDD	36.5	pa/a	=
070104-SED-02779-00.3	55722-27-5	TOTAL TCDF	99.9	pa/a	=
070104-SED-02779-00.3	30402-15-4	TOTAL PECDF	42.1		=
070104-SED-02779-00.3	55684-94-1	TOTAL HXCDF	25.3		=
070104 SED 02775 00.3	38998-75-3	TOTAL HPCDF	53.1		=
070104-SED-02773-00.3	1746-01-6	2,3,7,8-TCDD	3.49		=
070104-SED-02782-00.3	40321-76-4	1,2,3,7,8-PECDD	2.62		=
070104-SED-02782-00.3	39227-28-6	1,2,3,4,7,8-HXCDD			J
070104-SED-02782-00.3	57653-85-7		1.24		
		1,2,3,6,7,8-HXCDD	7.38		=
070104-SED-02782-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	2.29		J
070104-SED-02782-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD	58.1		=
070104-SED-02782-00.3	3268-87-9	OCDD	395		=
070104-SED-02782-00.3	51207-31-9	2,3,7,8-TCDF	229		=
070104-SED-02782-00.3	57117-41-6	1,2,3,7,8-PECDF	51.7		=
070104-SED-02782-00.3	57117-31-4	2,3,4,7,8-PECDF	60.8	pg/g	=
070104-SED-02782-00.3	70648-26-9	1,2,3,4,7,8-HXCDF	34.3		=
070104-SED-02782-00.3	57117-44-9	1,2,3,6,7,8-HXCDF	8.99		=
070104-SED-02782-00.3	60851-34-5	2,3,4,6,7,8-HXCDF		pg/g	=
070104-SED-02782-00.3	72918-21-9	1,2,3,7,8,9-HXCDF	6.54		=
070104-SED-02782-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF	123		=
070104-SED-02782-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF	6.18		=
070104-SED-02782-00.3	39001-02-0	OCDF	95.2	pg/g	=
070104-SED-02782-00.3	41903-57-5	TOTAL TCDD	71.5		=
070104-SED-02782-00.3	36088-22-9	TOTAL PECDD	38.2	pg/g	=
070104-SED-02782-00.3	34465-46-8	TOTAL HXCDD	74.1		=
070104-SED-02782-00.3	37871-00-4	TOTAL HPCDD	116		=
070104-SED-02782-00.3	55722-27-5	TOTAL TCDF	1100	pg/g	=
070104-SED-02782-00.3	30402-15-4	TOTAL PECDF	310		=
070104-SED-02782-00.3	55684-94-1	TOTAL HXCDF	188		=
070104-SED-02782-00.3	38998-75-3	TOTAL HPCDF	258		=
070204-SED-02775-00.3	1746-01-6	2,3,7,8-TCDD	1.45		=
070204-SED-02775-00.3	40321-76-4	1,2,3,7,8-PECDD	0.803		J
070204-SED-02775-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	0.334		J
070204-SED-02775-00.3	57653-85-7	1,2,3,6,7,8-HXCDD	2.21		J
070204-SED-02775-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	0.765		J
070204-SED-02775-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD	20.1		=
070204-SED-02775-00.3	3268-87-9	OCDD	132		=
070204-SED-02775-00.3	51207-31-9	2,3,7,8-TCDF			
			63.4		=
070204-SED-02775-00.3	57117-41-6	1,2,3,7,8-PECDF	39.4		=
070204-SED-02775-00.3	57117-31-4	2,3,4,7,8-PECDF	36.5		=
070204-SED-02775-00.3	70648-26-9	1,2,3,4,7,8-HXCDF	31.5		=
070204-SED-02775-00.3	57117-44-9	1,2,3,6,7,8-HXCDF	6.49	pg/g	=

Sample ID	CAS#	Analyte	Reported Value	Units	Qualifier
070204-SED-02775-00.3	60851-34-5	2,3,4,6,7,8-HXCDF	4.03		=
070204-SED-02775-00.3	72918-21-9	1,2,3,7,8,9-HXCDF	5.81		=
070204-SED-02775-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF	30.3		=
070204-SED-02775-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF	3.22		=
070204-SED-02775-00.3	39001-02-0	OCDF	42.3		=
070204-SED-02775-00.3	41903-57-5	TOTAL TCDD	15.9		=
070204-SED-02775-00.3	36088-22-9	TOTAL PECDD	9.48		=
070204-SED-02775-00.3	34465-46-8	TOTAL HXCDD	19.1		=
070204-SED-02775-00.3	37871-00-4	TOTAL HPCDD	37.2		=
070204-SED-02775-00.3	55722-27-5	TOTAL TCDF		pg/g	=
070204-SED-02775-00.3	30402-15-4	TOTAL PECDF		pg/g	=
070204-SED-02775-00.3	55684-94-1	TOTAL HXCDF	75.9		=
070204-SED-02775-00.3	38998-75-3	TOTAL HPCDF	72.9	na/a	=
070704-SED-02793-00.3	1746-01-6	2,3,7,8-TCDD	1.12		=
070704-SED-02793-00.3	40321-76-4	1,2,3,7,8-PECDD	0.602		J
070704-SED-02793-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	0.243		J
070704-SED-02793-00.3	57653-85-7	1,2,3,6,7,8-HXCDD	1.18		J
070704-SED-02793-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	0.385		J
070704-SED-02793-00.3 070704-SED-02793-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD	13.5		=
070704-SED-02793-00.3					
070704-SED-02793-00.3 070704-SED-02793-00.3	3268-87-9	OCDD 2,3,7,8-TCDF		pg/g	=
	51207-31-9	1 , , ,	50.7		=
070704-SED-02793-00.3	57117-41-6	1,2,3,7,8-PECDF		pg/g	=
070704-SED-02793-00.3	57117-31-4	2,3,4,7,8-PECDF	12.8		=
070704-SED-02793-00.3	70648-26-9	1,2,3,4,7,8-HXCDF	5.69		=
070704-SED-02793-00.3	57117-44-9	1,2,3,6,7,8-HXCDF	1.45		J
070704-SED-02793-00.3	60851-34-5	2,3,4,6,7,8-HXCDF	1.25		J
070704-SED-02793-00.3	72918-21-9	1,2,3,7,8,9-HXCDF	0.966		J
070704-SED-02793-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF	20.5		=
070704-SED-02793-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF	1.04		J
070704-SED-02793-00.3	39001-02-0	OCDF		pg/g	=
070704-SED-02793-00.3	41903-57-5	TOTAL TCDD	12.2		=
070704-SED-02793-00.3	36088-22-9	TOTAL PECDD	3.83		=
070704-SED-02793-00.3	34465-46-8	TOTAL HXCDD	10.3		=
070704-SED-02793-00.3	37871-00-4	TOTAL HPCDD	25.1		=
070704-SED-02793-00.3	55722-27-5	TOTAL TCDF	168	pg/g	=
070704-SED-02793-00.3	30402-15-4	TOTAL PECDF	54.9		=
070704-SED-02793-00.3	55684-94-1	TOTAL HXCDF	23.1		=
070704-SED-02793-00.3	38998-75-3	TOTAL HPCDF	46.2	pg/g	=
070704-SED-02794-00.3	1746-01-6	2,3,7,8-TCDD	4.86	pg/g	=
070704-SED-02794-00.3	40321-76-4	1,2,3,7,8-PECDD	2.69	pg/g	=
070704-SED-02794-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	1.26		J
070704-SED-02794-00.3	57653-85-7	1,2,3,6,7,8-HXCDD		pg/g	=
070704-SED-02794-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	2.03		J
070704-SED-02794-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD	65.4		=
070704-SED-02794-00.3	3268-87-9	OCDD		pg/g	=
070704-SED-02794-00.3	51207-31-9	2,3,7,8-TCDF	1200		J
070704-SED-02794-00.3	57117-41-6	1,2,3,7,8-PECDF		pg/g	=
070704-SED-02794-00.3	57117-31-4	2,3,4,7,8-PECDF		pg/g	=
070704-SED-02794-00.3	70648-26-9	1,2,3,4,7,8-HXCDF		pg/g	=
070704-SED-02794-00.3	57117-44-9	1,2,3,6,7,8-HXCDF	106	pg/g	=
070704-SED-02794-00.3	60851-34-5	2,3,4,6,7,8-HXCDF		pg/g	=
070704-SED-02794-00.3	72918-21-9	1,2,3,7,8,9-HXCDF		pg/g	=
070704-SED-02794-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF		pg/g	=
070704-SED-02794-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF	29.7		=
070704-SED-02794-00.3	39001-02-0	OCDF		pg/g	=
070704-SED-02794-00.3	41903-57-5	TOTAL TCDD	55.5		=
010104-3LD-02134-00.3	H 1800-07-0	TOTAL TODD	55.5	P9/9	_

Dow MOCA Sediment Varia				
Sample ID	CAS#	Analyte	Reported Value Units	
070704-SED-02794-00.3	36088-22-9	TOTAL PECDD	35 pg/g	=
070704-SED-02794-00.3	34465-46-8	TOTAL HXCDD	51.4 pg/g	=
070704-SED-02794-00.3	37871-00-4	TOTAL HPCDD	116 pg/g	=
070704-SED-02794-00.3	55722-27-5	TOTAL TCDF	3340 pg/g	J
070704-SED-02794-00.3	30402-15-4	TOTAL PECDF	2500 pg/g	=
070704-SED-02794-00.3	55684-94-1	TOTAL HXCDF	960 pg/g	=
070704-SED-02794-00.3	38998-75-3	TOTAL HPCDF	508 pg/g	=
070704-SED-02795-00.3	1746-01-6	2,3,7,8-TCDD	1.1 pg/g	=
070704-SED-02795-00.3	40321-76-4	1,2,3,7,8-PECDD	0.688 pg/g	J
070704-SED-02795-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	0.221 pg/g	U
070704-SED-02795-00.3	57653-85-7	1,2,3,6,7,8-HXCDD	1.59 pg/g	J
070704-SED-02795-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	0.465 pg/g	J
070704-SED-02795-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD	16.5 pg/g	=
070704-SED-02795-00.3	3268-87-9	OCDD	126 pg/g	=
070704-SED-02795-00.3	51207-31-9	2,3,7,8-TCDF	1740 pg/g	J
070704-SED-02795-00.3	57117-41-6	1,2,3,7,8-PECDF	436 pg/g	=
070704-SED-02795-00.3	57117-31-4	2,3,4,7,8-PECDF	509 pg/g	=
070704-SED-02795-00.3	70648-26-9	1,2,3,4,7,8-HXCDF	211 pg/g	=
070704-SED-02795-00.3	57117-44-9	1,2,3,6,7,8-HXCDF	41.5 pg/g	=
070704-SED-02795-00.3	60851-34-5	2,3,4,6,7,8-HXCDF	29.3 pg/g	=
070704-SED-02795-00.3	72918-21-9	1,2,3,7,8,9-HXCDF	36.8 pg/g	=
070704-SED-02795-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF	52.5 pg/g	=
070704-SED-02795-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF	8.51 pg/g	=
070704-SED-02795-00.3	39001-02-0	OCDF	46.7 pg/g	=
070704-SED-02795-00.3	41903-57-5	TOTAL TCDD	11 pg/g	=
070704-SED-02795-00.3	36088-22-9	TOTAL PECDD	6.17 pg/g	=
070704-SED-02795-00.3	34465-46-8	TOTAL HXCDD	11.5 pg/g	=
070704-SED-02795-00.3	37871-00-4	TOTAL HPCDD	31.6 pg/g	=
070704-SED-02795-00.3	55722-27-5	TOTAL TCDF	3800 pg/g	J
070704-SED-02795-00.3	30402-15-4	TOTAL PECDF	1670 pg/g	=
070704-SED-02795-00.3	55684-94-1	TOTAL HXCDF	382 pg/g	=
070704-SED-02795-00.3	38998-75-3	TOTAL HPCDF	107 pg/g	
070704-SED-02793-00.3 070704-SED-02804-00.3	1746-01-6	2,3,7,8-TCDD	1.29 pg/g	=
070704-SED-02804-00.3	40321-76-4	1,2,3,7,8-PECDD		J
			0.708 pg/g	U
070704-SED-02804-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	0.254 pg/g	
070704-SED-02804-00.3	57653-85-7	1,2,3,6,7,8-HXCDD	1.36 pg/g	J
070704-SED-02804-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	0.471 pg/g	U
070704-SED-02804-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD	14 pg/g	=
070704-SED-02804-00.3	3268-87-9	OCDD	137 pg/g	=
070704-SED-02804-00.3	51207-31-9	2,3,7,8-TCDF	67.4 pg/g	=
070704-SED-02804-00.3	57117-41-6	1,2,3,7,8-PECDF	19.1 pg/g	=
070704-SED-02804-00.3	57117-31-4	2,3,4,7,8-PECDF	18.1 pg/g	=
070704-SED-02804-00.3	70648-26-9	1,2,3,4,7,8-HXCDF	13.1 pg/g	=
070704-SED-02804-00.3	57117-44-9	1,2,3,6,7,8-HXCDF	2.96 pg/g	=
070704-SED-02804-00.3	60851-34-5	2,3,4,6,7,8-HXCDF	1.91 pg/g	J
070704-SED-02804-00.3	72918-21-9	1,2,3,7,8,9-HXCDF	1.94 pg/g	J
070704-SED-02804-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF	22.6 pg/g	=
070704-SED-02804-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF	2.01 pg/g	J
070704-SED-02804-00.3	39001-02-0	OCDF	30.2 pg/g	=
070704-SED-02804-00.3	41903-57-5	TOTAL TCDD	14.1 pg/g	=
070704-SED-02804-00.3	36088-22-9	TOTAL PECDD	7.83 pg/g	=
070704-SED-02804-00.3	34465-46-8	TOTAL HXCDD	11.6 pg/g	=
070704-SED-02804-00.3	37871-00-4	TOTAL HPCDD	27.2 pg/g	=
070704-SED-02804-00.3	55722-27-5	TOTAL TCDF	210 pg/g	=
070704-SED-02804-00.3	30402-15-4	TOTAL PECDF	82.3 pg/g	=
070704-SED-02804-00.3	55684-94-1	TOTAL HXCDF	38.7 pg/g	=

Sample ID	CAS#	Analyte	Reported Value Units	Qualifier
070704-SED-02804-00.3	38998-75-3	TOTAL HPCDF	51.6 pg/g	=
070804-SED-02792-00.3	1746-01-6	2,3,7,8-TCDD	4.09 pg/g	=
070804-SED-02792-00.3	40321-76-4	1,2,3,7,8-PECDD	13.8 pg/g	=
070804-SED-02792-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	12.1 pg/g	=
070804-SED-02792-00.3	57653-85-7	1,2,3,6,7,8-HXCDD	49.9 pg/g	=
070804-SED-02792-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	25.2 pg/g	=
070804-SED-02792-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD	214 pg/g	=
070804-SED-02792-00.3	3268-87-9	OCDD	1080 pg/g	=
070804-SED-02792-00.3	51207-31-9	2,3,7,8-TCDF	234 pg/g	=
070804-SED-02792-00.3	57117-41-6	1,2,3,7,8-PECDF	71.7 pg/g	=
070804-SED-02792-00.3	57117-31-4	2,3,4,7,8-PECDF	72.6 pg/g	=
070804-SED-02792-00.3	70648-26-9	1,2,3,4,7,8-HXCDF	72 pg/g	=
070804-SED-02792-00.3	57117-44-9	1,2,3,6,7,8-HXCDF	24.5 pg/g	=
070804-SED-02792-00.3	60851-34-5	2,3,4,6,7,8-HXCDF	20.2 pg/g	=
070804-SED-02792-00.3	72918-21-9	1,2,3,7,8,9-HXCDF	37.4 pg/g	=
070804-SED-02792-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF	122 pg/g	=
070804-SED-02792-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF	39.8 pg/g	=
070804-SED-02792-00.3	39001-02-0	OCDF	213 pg/g	=
070804-SED-02792-00.3	41903-57-5	TOTAL TCDD	88.3 pg/g	=
070804-SED-02792-00.3	36088-22-9	TOTAL PECDD	155 pg/g	=
070804-SED-02792-00.3	34465-46-8	TOTAL HXCDD	447 pg/g	=
070804-SED-02792-00.3	37871-00-4	TOTAL HPCDD	403 pg/g	=
070804-SED-02792-00.3	55722-27-5	TOTAL TCDF	685 pg/g	=
070804-SED-02792-00.3	30402-15-4	TOTAL PECDF	356 pg/g	=
070804-SED-02792-00.3	55684-94-1	TOTAL HXCDF	290 pg/g	=
070804-SED-02792-00.3	38998-75-3	TOTAL HPCDF	380 pg/g	=
070904-SED-02816-00.3	1746-01-6	2,3,7,8-TCDD	1.21 pg/g	=
070904-SED-02816-00.3	40321-76-4	1,2,3,7,8-PECDD	0.633 pg/g	J
070904-SED-02816-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	0.539 pg/g	U
070904-SED-02816-00.3	57653-85-7	1,2,3,6,7,8-HXCDD	1.4 pg/g	J
070904-SED-02816-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	0.896 pg/g	U
070904-SED-02816-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD	11.2 pg/g	=
070904-SED-02816-00.3	3268-87-9	OCDD	76.5 pg/g	=
070904-SED-02816-00.3	51207-31-9	2,3,7,8-TCDF	86.9 pg/g	=
070904-SED-02816-00.3	57117-41-6	1,2,3,7,8-PECDF	60.5 pg/g	=
070904-SED-02816-00.3	57117-31-4	2,3,4,7,8-PECDF	41 pg/g	=
070904-SED-02816-00.3	70648-26-9	1,2,3,4,7,8-HXCDF	33.3 pg/g	=
070904-SED-02816-00.3	57117-44-9	1,2,3,6,7,8-HXCDF	7.58 pg/g	=
070904-SED-02816-00.3	60851-34-5	2,3,4,6,7,8-HXCDF	3.99 pg/g	
070904-SED-02816-00.3	72918-21-9	1,2,3,7,8,9-HXCDF	5.82 pg/g	=
070904-SED-02816-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF	18.6 pg/g	=
070904-SED-02816-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF	2.27 pg/g	J
070904-SED-02816-00.3	39001-02-0	OCDF	17.2 pg/g	=
070904-SED-02816-00.3	41903-57-5	TOTAL TCDD	17.2 pg/g 12.4 pg/g	=
070904-SED-02816-00.3	36088-22-9	TOTAL PECDD	7.34 pg/g	=
070904-SED-02816-00.3	34465-46-8	TOTAL HXCDD		
070904-SED-02816-00.3	37871-00-4	TOTAL HPCDD	11.8 pg/g 21.2 pg/g	=
070904-SED-02816-00.3	55722-27-5	TOTAL TCDF	21.2 pg/g 233 pg/g	
				=
070904-SED-02816-00.3	30402-15-4	TOTAL PECDF	175 pg/g	=
070904-SED-02816-00.3	55684-94-1	TOTAL HIDODE	69.2 pg/g	=
070904-SED-02816-00.3	38998-75-3	TOTAL HPCDF	46.4 pg/g	=
070904-SED-02817-00.3	1746-01-6	2,3,7,8-TCDD	0.92 pg/g	=
070904-SED-02817-00.3	40321-76-4	1,2,3,7,8-PECDD	0.569 pg/g	J
070904-SED-02817-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	0.504 pg/g	J
070904-SED-02817-00.3	57653-85-7	1,2,3,6,7,8-HXCDD	27.6 pg/g	=
070904-SED-02817-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	1.53 pg/g	J

Dow MOCA Sediment Variability Evaluation										
Sample ID	CAS#	Analyte	Reported Value		Qualifier					
070904-SED-02817-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD		pg/g	=					
070904-SED-02817-00.3	3268-87-9	OCDD	12900		J					
070904-SED-02817-00.3	51207-31-9	2,3,7,8-TCDF		pg/g	=					
070904-SED-02817-00.3	57117-41-6	1,2,3,7,8-PECDF		pg/g	=					
070904-SED-02817-00.3	57117-31-4	2,3,4,7,8-PECDF	12.8	pg/g	=					
070904-SED-02817-00.3	70648-26-9	1,2,3,4,7,8-HXCDF	17.1	pg/g	=					
070904-SED-02817-00.3	57117-44-9	1,2,3,6,7,8-HXCDF	4.1	pg/g	=					
070904-SED-02817-00.3	60851-34-5	2,3,4,6,7,8-HXCDF	4.65	pg/g	=					
070904-SED-02817-00.3	72918-21-9	1,2,3,7,8,9-HXCDF		pg/g	=					
070904-SED-02817-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF	493	pg/g	=					
070904-SED-02817-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF		pg/g	=					
070904-SED-02817-00.3	39001-02-0	OCDF	2420	pg/g	=					
070904-SED-02817-00.3	41903-57-5	TOTAL TCDD	9.41	pg/g	=					
070904-SED-02817-00.3	36088-22-9	TOTAL PECDD	5.48	pg/g	=					
070904-SED-02817-00.3	34465-46-8	TOTAL HXCDD		pg/g	=					
070904-SED-02817-00.3	37871-00-4	TOTAL HPCDD	1200	pg/g	=					
070904-SED-02817-00.3	55722-27-5	TOTAL TCDF	115	pg/g	=					
070904-SED-02817-00.3	30402-15-4	TOTAL PECDF	62.5	pg/g	=					
070904-SED-02817-00.3	55684-94-1	TOTAL HXCDF	445	pg/g	=					
070904-SED-02817-00.3	38998-75-3	TOTAL HPCDF	2550	pg/g	=					
070904-SED-02818-00.3	1746-01-6	2,3,7,8-TCDD	3.23	pg/g	=					
070904-SED-02818-00.3	40321-76-4	1,2,3,7,8-PECDD		pg/g	J					
070904-SED-02818-00.3	39227-28-6	1,2,3,4,7,8-HXCDD	0.948	pg/g	U					
070904-SED-02818-00.3	57653-85-7	1,2,3,6,7,8-HXCDD	2.5	pg/g	=					
070904-SED-02818-00.3	19408-74-3	1,2,3,7,8,9-HXCDD	0.848		J					
070904-SED-02818-00.3	35822-46-9	1,2,3,4,6,7,8-HPCDD	41.1	pg/g	=					
070904-SED-02818-00.3	3268-87-9	OCDD	585	pg/g	=					
070904-SED-02818-00.3	51207-31-9	2,3,7,8-TCDF	2730	pg/g	J					
070904-SED-02818-00.3	57117-41-6	1,2,3,7,8-PECDF	486	pg/g	=					
070904-SED-02818-00.3	57117-31-4	2,3,4,7,8-PECDF		pg/g	=					
070904-SED-02818-00.3	70648-26-9	1,2,3,4,7,8-HXCDF	154	pg/g	=					
070904-SED-02818-00.3	57117-44-9	1,2,3,6,7,8-HXCDF	38.9	pg/g	=					
070904-SED-02818-00.3	60851-34-5	2,3,4,6,7,8-HXCDF	28.5	pg/g	=					
070904-SED-02818-00.3	72918-21-9	1,2,3,7,8,9-HXCDF	29	pg/g	=					
070904-SED-02818-00.3	67562-39-4	1,2,3,4,6,7,8-HPCDF	40.8	pg/g	=					
070904-SED-02818-00.3	55673-89-7	1,2,3,4,7,8,9-HPCDF	5.92	pg/g	=					
070904-SED-02818-00.3	39001-02-0	OCDF	71.1	pg/g	=					
070904-SED-02818-00.3	41903-57-5	TOTAL TCDD		pg/g	=					
070904-SED-02818-00.3	36088-22-9	TOTAL PECDD	11.4	pg/g	=					
070904-SED-02818-00.3	34465-46-8	TOTAL HXCDD		pg/g	=					
070904-SED-02818-00.3	37871-00-4	TOTAL HPCDD		pg/g	=					
070904-SED-02818-00.3	55722-27-5	TOTAL TCDF	6530		J					
070904-SED-02818-00.3	30402-15-4	TOTAL PECDF	1960		=					
070904-SED-02818-00.3	55684-94-1	TOTAL HXCDF		pg/g	=					
070904-SED-02818-00.3	38998-75-3	TOTAL HPCDF		pg/g	=					

# Sampling and Analysis Plan for Sediment Variability Sampling

Prepared for

The Dow Chemical Company

June 2004

**CH2MHILL** 

# **Contents**

Co	ntent	S	ii
Ab	brevi	ations and Acronyms	, <b>.</b>
1	Intro	oduction	1-1
	1.1	Background	1-1
	1.2	Purpose and Objectives	1-1
	1.3	Scope	1-1
	1.4	Data Quality Objectives	1-1
	1.5	Project Team	1-2
2	Field	d Activities	
	2.1	Access to Sampling Areas	2-1
		2.1.1 Utility Clearances	2-1
	2.2	Sampling Procedures	2-1
		2.2.1 Sediment Sampling	2-1
	2.3	Sample Containers, Preservation, and Holding Times	2-2
	2.4	Field Quality Control	2-2
	2.5	Station/Sample Identification	2-2
	2.6	Sample Handling and Chain of Custody	2-2
	2.7	Equipment Decontamination	2-3
3	Data	Management and Validation	
4	Heal	lth and Safety	<b>4-</b> 1
	4.1	Site Specific HS&E Plan Amendment	4-1
5	Proj	ect Schedule	5 <b>-</b> 1
6	Refe	rences	6-1

## Appendixes

- Station IDs Α
- В
- Target Analyte Lists
  Site Specific HS&E Plan Amendment C
- Sediment Core Log D

Table	s	Page
1-1	Data Quality Objectives	1-3
1-2	Sediment Variability Sampling Project Team	
2-1	Sediment Station Location GPS Coordinates	2-3
2-2	Required Analytical Method, Sample Containers, Preservation,	
	and Holding Times	2-4

#### **Figures**

- 1-1 General Location of Sediment Samples
- 2-1 Locations of Sediment Cores around N9 Station 7 in the Tittabawassee River
- 2-2 Locations of Sediment Cores around N3.25 Station 8 in the Tittabawassee River

# **Abbreviations and Acronyms**

ATV all-terrain vehicle

bgs below ground surface

COC chain of custody

Dow The Dow Chemical Company

DPT direct push technology
DQO data quality objective

Entrix Entrix, Inc.

ERA ecological risk assessment

GIS geographic information system

GPS global positioning system

HS&E Health, Safety, and Environment

HSP health and safety plan

ID identification

JHA job hazard analysis
LTI Limno-Tech Inc.

MDEQ Michigan Department of Environmental Quality

MI-OSHA Michigan Occupational Safety and Health Administration

MOCA Midland Offsite Corrective Actions
MS/MSD matrix spike/matrix spike duplicate
PCOI potential contaminants of interest

ppt part per trillion

QAPP quality assurance project plan

RI remedial investigation

SAP sampling and analysis plan

SOP Standard operating procedure

STAC Safety Task Analysis Card

SWP Safety Work Permit

USEPA United States Environmental Protection Agency

# 1 Introduction

## 1.1 Background

Several previous investigations conducted by the Michigan Department of Environmental Quality (MDEQ) have indicated that dioxins and furans (D&Fs) may be present in sediment and soil in and along the Tittabawassee River. In addition, Limno-Tech, Inc. (LTI) has previously investigated the sediments within the Tittabawassee River as part of the *Preliminary Flow/Solids Monitoring and Sediment Thickness Characterization* (Limno-tech, Inc, 2003). Approximately 22 shallow sediment samples were collected during this event in Fall of 2003. Two locations sampled during this event contained elevated concentrations of D&Fs at 2,870 ppt TEQ and 9,310 ppt TEQ. The sampling activities presented in this sampling and anlytical plan (SAP) are focused on evaluating sediment variability in the vicinity of these samples.

# 1.2 Purpose and Objectives

The purpose of this SAP is to define the procedures and sampling approach to collect sufficient data to evaluate sediment variability in the areas of elevated D&Fs measured in the Tittabawassee River sediment.

# 1.3 Scope

The scope of the field effort described in this SAP includes sediment sample collection at randomized locations in transects extending from two existing sample locations where elevated D&Fs concentrations were detected (Figure 1-1). In addition, several samples will be collected in the vicinity of the Saginaw Township Waste Water Treatment Plant (WWTP) outfall to evaluate sediment variability. All sampling and analysis will be performed in accordance with Field SOPs established for the Dow Midland Off-site Corrective Actions (MOCA) program, and the Dow MOCA *Quality Assurance Project Plan* (QAPP) (CH2M HILL 2004c).

# 1.4 Data Quality Objectives

Data quality objectives (DQOs) are both qualitative and quantitative statements that define the type, quality, and quantity of data necessary to support the decision making process during project activities. The DQO process used for this project follows the USEPA *Guidance for the Data Quality Objectives Process (EPA QA/G-4)* document (USEPA, 2000) and uses the seven-step DQO development process identified in the QAPP. Table 1-1 presents the DQOs associated with the sampling activities.

# 1.5 Project Team

The team members responsible for the effective execution of this SAP are identified by role in Table 1-2. The program management roles are further defined in the Dow MOCA *Program Management Plan* (CH2M HILL, 2004a).

TABLE 1-1 Data Quality Objectives Sediment Variability Sampling Sampling and Analysis Plan

State the Problem	Identify the Decisions	Identify Inputs to the Decisions	Define the Boundaries to the Study	Develop a Decision Rule	Specify Tolerable Limits on Decision Errors	Optimize the Design for Obtaining Data
It is unknown whether elevated dioxin & furan (D&F) concentrations in the Tittabawassee River sediment are the result of isolated detections or are an indication of t of larger contaminated areas.	Can elevated D&F concentrations be verified at the previously sampled locations?  If elevated concentrations are confirmed in previously sampled locations, what is the distribution of elevated concentrations?	- Confirmation D&F sample results at the 2 existing locations - D&F results from sediment samples collected from locations at various distances from the original locations of elevated D&F concentrations	The study is limited to surface sediment (0-0.3 ft) of the Tittabawassee river within the vicinity of the elevated D&F concentrations previously detected at these locations.	If elevated D&F concentrations are not detected at surface sediment (0- 0.3 ft) consistent with the previous levels, then the previously sample results reflect sediment heterogeneity and are not an indication of an area of elevated D&F concentrations.  If elevated concentrations of D&F are detected in surface sediment samples consistent with previous levels, then evaluate results of surface samples collected from locations extending outward from the location where the presence of elevated D&F concentrations have been confirmed.	The purpose for sampling is to confirm the presence of elevated concentrations and the potential lateral extent of elevated concentrations around the initial sample locations.	A sampling design has been established to collect sufficient data in order to determine if previously detected elevated D&Fs are still present and if present, delineate the lateral extent of elevated concentrations of D&Fs.  The approach starts with a central sample near the location of the existing elevated D&Fs and collecting consecutively farther spaced samples along a transect in the direction of river flow and another perpendicular to the direction of flow. Sediment cores will be collected to hand refusal at general distances of 3 ft, 30 ft, 100 ft and 980 ft in each direction.  Samples will be collected from the top 10 cm (0.3 ft) at the confirmation location as well as the cores at the 3 ft transect interval and analyzed for D&Fs. The remaining cores/intervals will be frozen and kept for possible future analyses.

TABLE 1-1 Data Quality Objectives Sediment Variability Sampling Sampling and Analysis Plan

State the Problem	Identify the Decisions	Identify Inputs to the Decisions	Define the Boundaries to the Study	Develop a Decision Rule	Specify Tolerable Limits on Decision Errors	Optimize the Design for Obtaining Data
If an area(s) of elevated D&F concentrations is identified in the Tittabawassee River surficial sediment, are elevated concentrations of D/Fs also present in deeper sediments?	What is the vertical distribution of elevated D&F concentrations in the laterally delineated areas?	D&F concentrations from sediment cores collected during the evaluation of sediment variability.	The study is limited to subsurface sediment (> 0.3 ft) of the Tittabawassee River within the delineated area of elevated surficial D&F sediment concentrations.	If elevated concentrations of D&F are detected in surface sediment samples consistent with previous levels, then evaluate results of surface samples collected from locations extending outward from the location were the presence of elevated D/F concentrations have been confirmed.  A decision(s) rule will be developed during the RI for evaluating the vertical distribution of D&Fs within the Tittabawassee River Sediment.	The purpose for sampling is to confirm potential vertical extent of elevated concentrations.	Sediment cores will be collected as part of the confirmation and lateral extent evaluation. A sediment core segmenting and analytical approach will be identified as part of the RI.
The lateral variability of D&F concentrations surrounding the Saginaw Township WWTP outfall are unknown.	What are the D&F concentrations immediately upstream and downstream of the WWTP?	D&F concentrations from collected sediment cores.	The study is limited to surface sediment (<0.3 ft) in the vicinity of the Saginaw Township WWTP outfall	A set of samples will collected to evaluate the lateral variability of D&F concentrations surrounding the Saginaw Township WWTP.	The purpose for sampling is to determine if D&F are present above and below the Saginaw Township WWTP.	Sediment cores will be collected at upstream and downstream locations adjacent to the Saginaw Township WWTP outfall.

TABLE 1-2 Project Team Sediment Variability Sampling Sampling and Analysis Plan

Responsibility	Individual	Affiliation	Contact Information
Senior Environmental Project Leader	Ben Baker	The Dow Chemical Company	47 Building Midland, MI 48667 (989) 636-0787
Project Manager Leader/ Client Point-of-Contact	Gary Dyke	CH2M HILL	1111 Washington Street Midland, MI 48640 (989) 835-1187
Project Manager	Eric Kroger	CH2M HILL	(937) 228-3180, ext. 207
Field Team Leader	Paul Arps	CH2M HILL	1111 Washington Street Midland, MI 48640 Office: (989) 638-8120 Mobile: (989) 205-0522
Field Lead	Cathy Whiting	Limno-Tech, Inc.	501 Avis Drive Ann Arbor, MI 48108 (734) 332-1200
MOCA Health and Safety Manager	Lisa Martin	CH2M HILL	(816) 224-6311
GIS Manager	Randy Vanslambrouck	CH2M HILL	1111 Washington Street Midland, MI 48640 (989) 638-8117
Data Manager	Lane Ebert	CH2M HILL	(215) 563-4244, ext. 448
Project Chemist	Herb Kelly	CH2M HILL	(352) 335-5877, ext. 2572
Contract Sediment Sampling	Tim Dekker	Limno-Tech, Inc.	(734) 332-1200
Contract Laboratory—Dioxin/ Furan Analysis	Martha Maier	Alta Analytical Laboratories	1104 Windfield Way El Dorado Hills, CA 95762 (916) 933-1640

# 2 Field Activities

The following provides the information necessary for the field team to locate and sample the areas of interest. Refer back to Figure 1-1 for the general location of each area.

Table 2-1 lists the coordinates of the sediment core locations to be collected. Figures 2-1 to 2-2 show the locations of the individual sediment cores to be collected.

# 2.1 Access to Sampling Areas

Access agreements are not necessary for the sediment sampling described in this document, as long as access to the river is via public boat launches and not by private property.

#### 2.1.1 Utility Clearances

Utility clearances will be necessary prior to the collection of sediment cores. The following service is available for identifying and locating underground utilities in Michigan:

Miss Dig System, Inc. 1-800-482-7171

The Miss Dig System should be contacted at least 3 business days prior to beginning this work. If questions arise in the field regarding utility clearances, the numbers of each utility owner are included in the Dow MOCA Program Health, Safety and Environment (HS&E) Plan (CH2M HILL, 2003).

# 2.2 Sampling Procedures

#### 2.2.1 Sediment Sampling

The coordinates of the sediment core locations are located in Table 2-1. A GPS unit with submeter precision will be used to locate each core location.

A confirmation sediment core will first be collected from the previously sampled location. Cores will be collected at intervals increasing logarithmically in four directions. The cores will be spaced at intervals of 3 ft, 30 ft, 100 ft, 330 ft, and 980 ft. The locations of the cores include a random component, providing a more robust data set for spatial analysis. Figures 2-1 & 2-2 show the locations of the sediment cores. A GPS unit will be used to locate the sediment core locations.

In addition, 3 sediment core locations will collected in the vicinity of the Saginaw Township Waste Water Treatment Plant (WWTP) outfall. One core each will be collected upstream, downstream, and adjacent to the outfall. The locations of these sediment cores will be determined by the field lead based on their field observations of sediment patterns in the area.

The sediment cores will be collected until hand refusal is met following procedures identified the "Sampling Procedures for Lexan Tube" section located in the in *Core Sediment Sampling Field* 

SOP (CH2M HILL, 2004b). Based on site conditions, alternative procedures may be used for the collection of the sediment cores which will be consistent with Dow MOCA SOPs. The optimal method of sample collection will be at the discretion of the field lead after evaluating field conditions.

The top 0.3 ft of the central core, the cores from the 3 ft spacing at each area, and the cores collected in the vicinity of the Saginaw Township WWTP outfall will be homogenized and sent to the laboratory for analysis of D&Fs. The remaining cores at these locations will be frozen and kept for potential future analysis pending the results of the initial analyses.

Coordinates will be collected at the time of sampling from each location using a GPS unit with submeter accuracy and recorded in the field logbook (or sediment core log located in Appendix D).

# 2.3 Sample Containers, Preservation, and Holding Times

The sample container and preservation requirements are presented in Table 2-2, below. Additional sample container and preservation requirements are given in the QAPP (CH2M HILL, 2004c). All containers should be requested from the contract laboratories for delivery to Midland before the project begins.

The activities associated with the sampling activities must be documented in field logbooks. The procedures and QC procedures for field logbook entries are located in the *Field SOPs* (CH2M HILL, 2004b) and QAPP (CH2M HILL, 2004c).

# 2.4 Field Quality Control

Field quality control samples will be collected as part of this investigation in accordance with Section 2.5 of the QAPP (CH2M HILL, 2004c). QC samples include the following:

- Field blanks, field duplicates, equipment blanks, and matrix spike/matrix spike duplicates (MS/MSDs) will be collected at a minimum frequency of 1 per 20 samples.
- Field duplicates will be collected at a minimum frequency of 1 per 10 samples.

# 2.5 Station/Sample Identification

Station identification numbers are listed in Appendix A. Sample numbers must be generated following the guidelines in the *Sample Identification Technical Memorandum*, (CH2M HILL, 2004e).

# 2.6 Sample Handling and Chain of Custody

The procedures used for proper packaging, shipping, and documentation of samples being transported from the field to the laboratory for analysis are given in the *Sample Handling and Shipping Custody Procedures Field SOP* (CH2M HILL, 2004b).

After samples are labeled and packaged, those intended for dioxin/furan analysis will be shipped to Alta Analytical Laboratory, Inc., at the following address:

Attn: Sample Receiving Alta Analytical Laboratory, Inc. 1104 Windfield Way El Dorado Hills, CA 95762 (916) 933-1640

# 2.7 Equipment Decontamination

- Personal decontamination procedures will be those given in the Dow MOCA Health, Safety and Environment Plan (HSEP; CH2M HILL, 2003).
- All sediment sampling equipment will be decontaminated in accordance with the *Field Decontamination Procedures Field SOP* (CH2M HILL, 2004b).
- Excess sediment, disposable sampling equipment, and decontamination materials and liquids will be disposed of in accordance to the *Handling and Disposal of Investigative-Derived Waste Field SOP* (CH2M HILL. 2004b).

TABLE 2-1 Sediment Station Location GPS Coordinates Sediment Variability Sampling Sampling and Analysis Plan

Location	Longitude	Latitude	Up- or downstream of original point	Location	Longitude	Latitude	Up- or downstream of original point
N9, STA 7	-84.08277158	43.45871961	-	N3.25, STA 8	-84.03192543	43.40204224	-
1	-84.08417286	43.45926161	U	16	-84.03492182	43.40316976	U
2	-84.08307251	43.45908444	U	17	-84.03358570	43.40277374	U
3	-84.08283711	43.45878161	U	18	-84.03241975	43.40235708	U
4	-84.08278734	43.45874457	U	19	-84.03202323	43.40207444	U
5	-84.08273027	43.45873689	U	20	-84.03195544	43.40205885	U
6	-84.08278679	43.45871459	U	21	-84.03190018	43.40207165	U
7	-84.08257965	43.45879000	D	22	-84.03193558	43.40203259	U
8	-84.08277168	43.45871876	D	23	-84.03187254	43.40201373	D
9	-84.08283077	43.45868657	D	24	-84.03208184	43.40185291	D
10	-84.08243825	43.45879825	D	25	-84.03141018	43.40175676	D
11	-84.08274318	43.45867610	D	26	-84.03176350	43.40196794	D
12	-84.08271263	43.45862560	D	27	-84.03168271	43.40222611	D
13	-84.08265287	43.45829535	D	28	-84.03180200	43.40217032	D
14	-84.08252144	43.45722739	D	29	-84.02842062	43.40036628	D

TABLE 2-1 Sediment Station Location GPS Coordinates Sediment Variability Sampling Sampling and Analysis Plan

Location	Longitude	Latitude	Up- or downstream of original point	Location	Longitude	Latitude	Up- or downstream of original point
15	-84.08296753	43.45579124	D	30	-84.03009002	43.40119743	D
				31	-84.03195649	43.40199291	D
				32	-84.03192522	43.40204159	D

TABLE 2-2 Required Analytical Method, Sample Containers, Preservation, and Holding Times Sediment Variability Sampling Sampling and Analysis Plan

Analyses	Preparatory/ Analytical Method	Sample Matrix <sup>a</sup>	Container <sup>b</sup>	Qty	Preservative <sup>c</sup>	Holding Time <sup>d</sup>
Dioxins/Furans SW-846 8290/EPA Method 1613		W (QC) S	1-L glass 8-oz glass	2	Cool 4°C	45 days <sup>e</sup>

Sample container and volume requirements will be specified by the analytical laboratory performing the tests. Three times the required volume should be collected for samples designated as MS/MSD samples.

EPA = U.S. Environmental Protection Agency

L = Liter oz = Ounce

ASTM = American Society for Testing and Materials NA = Not applicable

<sup>&</sup>lt;sup>a</sup>Sample matrix: S = surface soil, subsurface soil, sediment; W = surface water.

<sup>&</sup>lt;sup>b</sup>All containers will be sealed with Teflon®-lined screw caps.

<sup>&</sup>lt;sup>c</sup>All samples will be stored promptly at 4°C in an insulated chest.

<sup>&</sup>lt;sup>d</sup>Holding times are from the time of sample collection.

<sup>°30</sup> days to extraction for water, 45 days for analysis.

Source: SW-846, third edition, Update III (June 1997).

<sup>°</sup>C = Degrees Centigrade

# 3 Data Management and Validation

All data collected under this field effort will be managed in accordance with the Data Management Plan for Dow MOCA (CH2M HILL, 2004d).

As specified in the QAPP, all analytical data generated to support the Dow MOCA program will be validated. Ten percent of the data packages will be validated to Level IV by a third party subcontractor to CH2M HILL. All other data packages will be validated to Level III by the CH2M HILL project chemist (or designee).

Following validation, data will be entered into a central database. The data will then be accessible for evaluation, interpretation and reporting activities.

# 4 Health and Safety

# 4.1 Site Specific HS&E Plan Amendment

A Site-Specific Amendment to the HS&E Plan has been prepared for this project and has been approved by The Health and Safety Manager (HSM). It is included with this SAP as Appendix C. Prior to beginning field work, Field Team members must read and sign the amendment, and follow its requirements.

# 5 Project Schedule

The soil borings are scheduled for the week of June 21, 2004. Based on that start date, the schedule will be as follows:

Activity	Anticipated Duration	Anticipated Start Date	Anticipated End Date
Work Planning, SAP Development, Contractor Procurement,	2 Weeks	June 7th, 2004	June 18, 2004
Sediment Sampling	5 Days	June 21, 2004	June 25, 2004
Laboratory Analysis	21 Days*	June 28, 2004	July 16, 2004
Data Validation/Data Entry	21 Days	July 19, 2004	August 9, 2004
Sediment Data Available	0 Days	August 9, 2004	NA
Data Interpretation and Reporting	21 Days	August 9, 2004	August 30, 2004
Internal review of Draft Tech Memorandum Summarizing Findings of Lateral Extent	3 Days	August 31 2004	September 2, 2004
Draft Tech Memorandum to Client	0 Days	September 3, 2004	NA

<sup>\*</sup> From date last samples are received.

# 6 References

Caeiro, S., et al. "Spatial sampling design for sediment quality assessment in estuaries." *Environmental Modeling & Software.* 18. 2003. pp. 853-859.

CH2M HILL. 2003. Dow MOCA Health, Safety and Environment Plan.


CH2M HILL. 2004a. Dow MOCA Program Management Plan.

CH2M HILL. 2004b. Field SOPs.

CH2M HILL. 2004c. Quality Assurance Project Plan (QAPP).

CH2M HILL. 2004d. Dow MOCA Data Management Plan.

USEPA. 2000. Guidance for the Data Quality Objectives Process (EPA QA/G-4). EPA guidance document EPA/600/R-96/055. August.






Figure 2-1: Locations of Sediment Cores around N9 Station 7 in the Tittabawassee River




Figure 2-2: Locations of Sediment Cores around N3.25 Station 8 in the Tittabawassee River

Appendix A **Station IDs** 

## Appendix A

Identification of Sediment Core Locations Sediment Variability Sampling Sampling and Analysis Plan Dow Midland Off-site Corrective Actions Program

Core Location	Longitude	Latitude	Station Location
N9, STA 7	-84.08277158	43.45871961	THT-
1	-84.08417286	43.45926161	THT-
2	-84.08307251	43.45908444	THT-
3	-84.08283711	43.45878161	THT-
4	-84.08278734	43.45874457	THT-
5	-84.08273027	43.45873689	THT-
6	-84.08278679	43.45871459	THT-
7	-84.08257965	43.45879	THT-
8	-84.08277168	43.45871876	THT-
9	-84.08283077	43.45868657	THT-
10	-84.08243825	43.45879825	THT-
11	-84.08274318	43.4586761	THT-
12	-84.08271263	43.4586256	THT-
13	-84.08265287	43.45829535	THT-
14	-84.08252144	43.45722739	THT-
15	-84.08296753	43.45579124	THT-
N3.25, STA 8	-84.03192543	43.40204224	SHL-
16	-84.03492182	43.40316976	SHL-
17	-84.0335857	43.40277374	SHL-
18	-84.03241975	43.40235708	SHL-
19	-84.03202323	43.40207444	SHL-
20	-84.03195544	43.40205885	SHL-
21	-84.03190018	43.40207165	SHL-
22	-84.03193558	43.40203259	SHL-
23	-84.03187254	43.40201373	SHL-
24	-84.03208184	43.40185291	SHL-
25	-84.03141018	43.40175676	SHL-
26	-84.0317635	43.40196794	SHL-
27	-84.03168271	43.40222611	SHL-
28	-84.031802	43.40217032	SHL-
29	-84.02842062	43.40036628	SHL-
30	-84.03009002	43.40119743	SHL-
31	-84.03195649	43.40199291	SHL-
32	-84.03192522	43.40204159	SHL-



TABLE B-1 Target Analyte List A for Soils and Sediments—All Selected Analytes Sedeiment Variability Study Sampling and Analysis Plan


		0-:1/0-	allian and
<b>1</b>	A 1.		ediment
Parameter/Method	Analyte	RL	Unit
Dioxins and Furans	2,3,7,8-Tetrachlorodibenzo-p-dioxin (TCDD)	1.0	ng/Kg
SW8290	1,2,3,7,8-Pentachlorodibenzo-p-dioxin (PeCDD)	5.0	ng/Kg
	1,2,3,6,7,8-Hexachlorodibenzo-p-dioxin (HxCDD)	5.0	ng/Kg
	1,2,3,4,7,8-Hexachlorodibenzo-p-dioxin (HxCDD)	5.0	ng/Kg
	1,2,3,7,8,9-Hexachlorodibenzo-p-dioxin (HxCDD)	5.0	ng/Kg
	1,2,3,4,6,7,8-Heptachlorodibenzo-p-dioxin (HpCDD)	5.0	ng/Kg
	1,2,3,4,6,7,8,9-Octachlorodibenzo-p-dioxin (OCDD)	10	ng/Kg
	2,3,7,8-Tetrachlorodibenzofuran (TCDF)	1.0	ng/Kg
	1,2,3,7,8-Pentachlorodibenzofuran (PeCDF)	5.0	ng/Kg
	2,3,4,7,8-Pentachlorodibenzofuran (PeCDF)	5.0	ng/Kg
	1,2,3,6,7,8-Hexachlorodibenzofuran (HxCDF)	5.0	ng/Kg
	1,2,3,7,8,9-Hexachlorodibenzofuran (HxCDF)	5.0	ng/Kg
	1,2,3,4,7,8-Hexachlorodibenzofuran (HxCDF)	5.0	ng/Kg
	2,3,4,6,7,8-Hexachlorodibenzofuran (HxCDF)	5.0	ng/Kg
	1,2,3,4,6,7,8-Heptachlorodibenzofuran (HpCDF)	5.0	ng/Kg
	1,2,3,4,7,8,9-Heptachlorodibenzofuran (HpCDF)	5.0	ng/Kg
	1,2,3,4,6,7,8,9-Octachlorodibenzofuran (OCDF)	10	ng/Kg

MKE/AppdxB\_TAL\_xls Page 1 of 2

TABLE B-2
Target Analyte List for Aqueous Matrix—All Selected Analytes
Sedeiment Variability Study
Sampling and Analysis Plan

		Wa	ater
Parameter/Method	Analyte	RL	Unit
Dioxins and Furans	2,3,7,8-Tetrachlorodibenzo-p-dioxin (TCDD)	0.01	ng/L
SW8290	1,2,3,7,8-Pentachlorodibenzo-p-dioxin (PeCDD)	0.05	ng/L
	1,2,3,6,7,8-Hexachlorodibenzo-p-dioxin (HxCDD)	0.05	ng/L
	1,2,3,4,7,8-Hexachlorodibenzo-p-dioxin (HxCDD)	0.05	ng/L
	1,2,3,7,8,9-Hexachlorodibenzo-p-dioxin (HxCDD)	0.05	ng/L
	1,2,3,4,6,7,8-Heptachlorodibenzo-p-dioxin (HpCDD)	0.05	ng/L
	1,2,3,4,6,7,8,9-Octachlorodibenzo-p-dioxin (OCDD)	0.1	ng/L
	2,3,7,8-Tetrachlorodibenzofuran (TCDF)	0.01	ng/L
	1,2,3,7,8-Pentachlorodibenzofuran (PeCDF)	0.05	ng/L
	2,3,4,7,8-Pentachlorodibenzofuran (PeCDF)	0.05	ng/L
	1,2,3,6,7,8-Hexachlorodibenzofuran (HxCDF)	0.05	ng/L
	1,2,3,7,8,9-Hexachlorodibenzofuran (HxCDF)	0.05	ng/L
	1,2,3,4,7,8-Hexachlorodibenzofuran (HxCDF)	0.05	ng/L
	2,3,4,6,7,8-Hexachlorodibenzofuran (HxCDF)	0.05	ng/L
	1,2,3,4,6,7,8-Heptachlorodibenzofuran (HpCDF)	0.05	ng/L
	1,2,3,4,7,8,9-Heptachlorodibenzofuran (HpCDF)	0.05	ng/L
	1,2,3,4,6,7,8,9-Octachlorodibenzofuran (OCDF)	0.1	ng/L

MKE/AppdxB\_TAL\_.xls Page 2 of 2



# **Dow Program**

# CH2M HILL HEALTH, SAFETY AND ENVIRONMENT PLAN

# Site-Specific Amendment No. 3

This amendment must accompany the Health, Safety and Environment Plan (HS&E Plan) for the **Dow Chemical Company Midland** project approved on **April 1, 2004**. The purpose of the HS&E Plan amendment is to include supplemental information as it becomes available. Supplemental information will be used to specify dates of site work for individual tasks, verify CH2M HILL onsite personnel and responsibilities, list site-specific subcontractors and contractors, and reevaluate hazards associated with the planned activities.

Where the amendment contains information different from the HS&E Plan, the amendment will take precedence for the specified task. The amendment includes new information or revises existing HS&E Plan information. Sections of the HS&E Plan that are not addressed in the amendments do not have changes; therefore, the HS&E Plan will be followed. All employees performing tasks covered by this amendment must read both the HS&E Plan and this amendment and agree to abide by their provisions (see Attachment 1).

# **Project Information and Description**

**PROJECT NO:** 318032.01.VE (Original H&E Plan 188182 and 188194)

CLIENT: The Dow Chemical Company

PROJECT/SITE NAME: Midland

SITE ADDRESS: This HS&E Plan Amendment is intended to cover activities

associated with Offsite Corrective Action fieldwork associated with Dow's Midland Plant, as described under Condition XI.B of Dow's June, 2003 Operating License. Specific areas in which work will occur include: (1) Sediments and floodplain soils of the Tittabawassee River from approximately 1 mile upstream of Dow Midland Plant to approximately 11 miles downstream to the confluence of the Tittabawassee and Saginaw Rivers and also upstream of the Plant along the Chippawa River. Activities covered will

consist of investigation, Interim Response Activities, and

1

corrective actions.

CH2M HILL PROJECT MANAGER: Gary Dyke

CH2M HILL OFFICE: Midland

**DATE HS&E PLAN PREPARED:** 12/29/2003

**DATE AMENDMENT PREPARED:** June 9, 2004

DATE(S) OF SITE WORK: June 28 – July 2, 2004 (Boating and sediment sampling)

# 1.1 Description of Tasks

(Reference Field Project Start-up Form)

Description of Tasks for this Site-Specific Amendment:

**Task 1: SEDIMENT SAMPLING.** Collect sediment samples from 40 locations along the Tittabawassee River, by boat (work will be contracted out). Conditions may exist requiring the samplers to leave the boat during the sampling activities to wade through portions of the river.

# 1.1.1 Hazwoper-Regulated Tasks

- Sediment Sample Collection by boat
- Sediment Sample Collection by wading

# 1.1.2 Non-Hazwoper-Regulated Tasks

TASKS	CONTROLS
GPS Surveying	<ul> <li>Brief on hazards, limits of access, and emergency procedures</li> <li>Post contaminant areas as appropriate (refer to Section 8.2 for details)</li> </ul>
	<ul> <li>Sample and monitor as appropriate (refer to Section 5.0)</li> </ul>

# 2 Control Measures

This section provides safe work practices and control measures used to reduce or eliminate potential hazards and risks.

Each individual must complete a safety task analysis card or STAC (see Attachment 4 of the original HS&E Plan). STACs must be completed daily and updated as site conditions and/or activities change, or potential changes arise.

A Project-Activity Self-Assessment Checklist for "Boating" is contained in Attachment 4 of this amendment. The checklist will be completed at the beginning of boating activities, and once weekly. The self-assessment checklists, including documented corrective actions, should be made part of the permanent project records, and be promptly submitted to the HSM.

Formal observations are not required for the tasks under this amendment since there are fewer than three employees working less than five days onsite for each task; however observations may be done at any time. Interventions are required. Interventions will occur when an unsafe behavior or work condition is observed. Each person conducting 40 or more hours per month of field work must document interventions on the STAC or intervention card at a rate of one per 40 hours worked.

Additionally, as indicated in Section 2.1.1, a Safe Work Permit for "Boating" will be completed on a daily basis for this activity. A Safe Work Permit for "Pressure Washing" will be completed as necessary for decontaminating equipment.

Safe Work Permits are incorporated as Attachment 2 of this HS&E Plan Amendment. Completed Safe Work Permits must be submitted to Jeannie Armstrong/SEA for internal and Dow review.

### 2.1 Project-Specific Control Measures

#### 2.1.1 Boating

The following control measures are excerpted from Section 2.1.2 of the original HS&E Plan, and apply to subcontractor personnel performing boating and sediment sampling. Additionally, a Safe Work Permit for Boating will be completed on a daily basis, and a Safe Work Permit for Pressure Washing will be completed as necessary for decontaminating equipment (both included in Attachment 2 of this HS&E Plan Amendment). A Job Hazard Analysis (JHA) for sediment sampling activities has been prepared by the subcontractor and is incorporated as Attachment 3 of this HS&E Plan Amendment.

- All operations involving boating will be directed by an experienced boater.
- The Safe Boating Checklist found in Attachment 4 of this amendment will be completed at the beginning of boating activities, and once weekly.
- Michigan boating laws must be adhered to when operating a boat during visual surveying activities. Refer to "The Handbook of Michigan Boating Laws and Responsibilities," which is available online at http://boat-ed.com/mi/handbook/pdf/miguide.pdf.
- All staff must wear U.S. Coast Guard (USCG) approved personnel flotation devices (PFDs) when aboard the boat.
- One Type IV USCG-approved PFD (throwable cushions or ring buoys) must be onboard and readily accessible on vessels 16 feet or longer.
- The boating team will include at least one person qualified in First Aid and CPR.
- All personnel shall wear bright colors (for example: hunter orange, yellow, etc.) to enhance their visibility to one another.
- The SC has final authority on operations with regards to weather and water conditions.
- Safe means of boarding or leaving the boat or platform must be provided to prevent slipping and falling.
- Employees should be instructed on safe use of the boat.
- Never exceed the load limit of the boat.
- The boat must be equipped with a Type B fire extinguisher if the boat has permanently installed fuel tanks, portable fuel tanks, or compartments in which flammable or combustible materials are stored. The extinguisher must be mounted in an accessible area, and labeled "Marine Type USCG Approved," followed by the size and type symbols and the approval number. Refer to "The Handbook of Michigan Boating Laws and Responsibilities" for additional fire extinguisher requirements.
- The boat must be equipped with the appropriate navigation lights for the type of boat being used for nighttime and poor visibility conditions (refer to "The Handbook of Michigan Boating Laws and Responsibilities").
- The boat must be equipped with the appropriate sound producing devices for the type of boat being used (refer to "The Handbook of Michigan Boating Laws and Responsibilities").
- The boat must be equipped with an anchor and alternative means of locomotion (extra motor, floatable oars).
- Weather and water conditions must be monitored to determine if it is safe to be out on a water body.

- Work requiring the use of a boat will not take place at night or during inclement weather.
- Shut off engine before refueling. Do not smoke while refueling.
- Remain seated in the boat or canoe whenever possible.
- Never stand on the gunwales of a boat except when needed for embarking or disembarking.

#### 2.1.2 Wading

The following physical hazards may exist on this project including hazards associated with wading in 3 to 4 feet of water, and working from a boat or canoe.

- Although the river and lake areas we will be working in are wadeable in places, there may be deep spots. Care will be taken when wading not to proceed beyond waist deep.
- Wading will not be performed without a buddy nearby.
- U.S. Coast Guard-approved PFD, or life jacket, shall be worn by both the person wading and the buddy.
- Inspect PFDs prior to use. Do not use defective PFDs.
- A minimum of one ring buoy with 90 feet of 3/8-inch solid-braid polypropylene (or equal) rope must be provided for emergency rescue.
- Waders will not be worn when personnel are in the boat.
- The sediments may be soft and there is a possibility of sinking. When wading, team members are cautioned to be careful of footing.

# 3 Project Organization and Personnel

### 3.1 CH2M HILL Employee Medical Surveillance and Training

(Reference CH2M HILL SOPs HSE-01, Medical Surveillance, and HSE-02, Health and Safety Training)

<b>Employee Name</b>	Office	Responsibility	SC/FA-CPR
Paul Arps	MOCA Site	Field Team lead	Level C SSC; FA/CPR
Gary Dyke	MOCA Site	Project Manager Leader	
Eric Kroger	DAY	Project Manager	

#### 3.2 Field Team Chain of Command and Communication Procedures

#### 3.2.1 Client

Contact Name: Dow Chemical Company

Facility Contact Name: Ben Baker

Phone: 989/636-0787

The contact at security to notify for work along the river on Dow property is Jack Johnson (989) 638-1429.

#### 3.2.2 CH2M HILL

Project Manager Leader: Gary Dyke/LSG/MOCA Site

Project Manager: Eric Kroger/DAY

Health and Safety Manager: Lisa Martin/DEN

Environmental Compliance Coordinator: Jessica Raphael/DET

Field Team Leader: Paul Arps/LSG/MOCA Site

Safety Coordinator: Paul Arps/LSG/MOCA Site

The SC is responsible for contacting the Field Team Leader and Project Manager. In general, the Project Manager will contact the client. The Health and Safety Manager should be contacted as appropriate.

#### 3.2.3 CH2M HILL Subcontractors

(Reference CH2M HILL SOP HSE-55, Subcontractor, Contractor, and Owner)

Subcontractor: LimnoTech, Inc.

Subcontractor Contact Name: Tim Dekker

Telephone: (734) 332-1200

Subcontractor Tasks(s): Perform surface sediment sample collection.

# 4 Personal Protective Equipment (PPE)

(Reference CH2M HILL SOP HSE-07, Personal Protective Equipment; HSE-08, Respiratory Protection)

#### PPE Specifications a

Task	Level	Body	Head	Respirator <sup>b</sup>
GPS Surveying	D	Work clothes; steel-toe, leather work boots; work gloves.	Hardhat <sup>c</sup> Safety glasses Ear protection <sup>d</sup>	None required
Sediment sample collection by boat	Modified D	Coveralls: Not required unless work clothes can't be kept reasonably clean, at which time cotton coveralls will be worn  Boots: Steel-toe, leather work boots; for muddy/wet conditions - steel-toe, chemical-resistant boots  Gloves: Nitrile gloves.  Personal Flotation Devices (PFDs) must be worn on the boat.	Hardhat <sup>c</sup> Safety glasses Ear protection <sup>d</sup>	None required.
Sediment sample collection by wading	Modified D	Coveralls: Not required unless work clothes can't be kept reasonably clean, at which time cotton coveralls will be worn  Waders: To be worn only while wading – not while in boat  Gloves: Nitrile gloves.  Personal Flotation Devices (PFDs) must be worn on the boat.	Hardhat <sup>c</sup> Safety glasses Ear protection <sup>d</sup>	None required.

# Reasons for Upgrading or Downgrading Level of Protection

Upgrade <sup>f</sup>	Downgrade
<ul><li>Request from individual performing tasks.</li><li>Change in work tasks that will increase conta</li></ul>	New information indicating that situation is less hazardous than originally thought.
contact with hazardous materials.	<ul> <li>Change in site conditions that decreases the</li> </ul>
<ul> <li>Occurrence or likely occurrence of gas or vap</li> </ul>	or emission. hazard.
Known or suspected presence of dermal haza	rds. • Change in work task that will reduce contact
<ul> <li>Instrument action levels (Section 5) exceeded.</li> </ul>	with hazardous materials.

<sup>&</sup>lt;sup>a</sup> Modifications are as indicated. CH2M HILL will provide PPE only to CH2M HILL employees.

# 5 Air Monitoring/Sampling

(Reference CH2M HILL SOP HSE-06, Air Monitoring)

None Required

<sup>&</sup>lt;sup>b</sup> No facial hair that would interfere with respirator fit is permitted.

<sup>&</sup>lt;sup>c</sup> Hardhat and splash-shield areas are to be determined by the SC.

d Ear protection should be worn when conversations cannot be held at distances of 3 feet or less without shouting.

<sup>&</sup>lt;sup>e</sup> Cartridge change-out schedule is at least every 8 hours (or one work day), except if relative humidity is > 85%, or if organic vapor measurements are > midpoint of Level C range (refer to Section 5)-, then at least every 4 hours. If encountered conditions are different than those anticipated in this HSP, contact the HSM.

<sup>&</sup>lt;sup>f</sup> Performing a task that requires an upgrade to a higher level of protection (e.g., Level D to Level C) is permitted only when the PPE requirements[ have been approved by the HSM, and an SC qualified at that level is present.

# 11 Approval

This site-specific Health, Safety and Environment Plan has been written for use by CH2M HILL only. CH2M HILL claims no responsibility for its use by others unless that use has been specified and defined in project or contract documents. The plan is written for the specific site conditions, purposes, dates, and personnel specified and must be amended if those conditions change.

Written By:	Catherine Geiger/CHI	Date:	11/24/2003
Approved By:	Lux J. Martin	Date:	04/01/2004
_Lisa Martin <sub>_</sub> RHSPM			
_Jessica Raph ECC	ael		
11.2 Rev	isions		
Revisions Ma	de By: Wayne Ekren/ LSG D	ate: June 9	, 2004
	<u> </u>	d controls, pr	ting and sediment sampling roject personnel, subcontractors, PPl
Revisions Ap	proved By: Less D. M.	uti	Date: June 25, 2004
RHSPM			
_	ael		
ECC			

# 12 Attachments

Attachment 1: Employee Signoff Form - Health & Safety Plan

Attachment 2: Safe Work Permits - Boating and Pressure Washing

Attachment 3: Limno-Tech, Inc. Job Hazard Analysis for Sediment Sampling

Attachment 4: HS&E Self-Assessment Checklist - Boating

# Attachment 1 Employee Signoff Form - Health & Safety Plan

## **CH2M**HILL

## **EMPLOYEE SIGNOFF FORM**

# Health and Safety Plan

# Amendment No. 3

The CH2M HILL project employees and subcontractors listed below have been provided with a copy of this HSP, have read and understood it, and agree to abide by its provisions.

<b>Project Name</b> : Dow, Midland, M	<b>ject Number:</b> 318032.01.VE		
EMPLOYEE NAME (Please print)	EMPLOYEE SIGNATURE	COMPANY	DATE

# Attachment 2 Safe Work Permits - Boating and Pressure Washing

11

# Attachment 3 Limno-Tech, Inc. Job Hazard Analysis for Sediment Sampling

# Attachment 4 HS&E Self-Assessment Checklist - Boating

# Health and Safety Self Assessment Checklist - BOATING

This self assessment is only to be used at locations where CH2M HILL controls the work. It is not to be used at locations where others control the work.

Project Name: Project No.:				
Location:	PM:			
Auditor:	Title:	_ Date:		
deficient the "No" box should be be corrected immediately or all of shall be brought to the attention If an item is not applicable, the "	te/correct the "Yes" box should be checked. If an ite be checked. Items that are considered to be imminent exposed personnel must be removed from the hazard of the appropriate party that is responsible for corres "N/A" box should be checked. If an item is applicable, the "N/O" box should be checked.	tly dangerous must rd. All deficiencies ecting the deficiency.		
		Yes No NA N/O		
<ol> <li>Lights, horn, battery, fuel</li> <li>Daily safety briefing/mee</li> <li>Personal Floatation Devic</li> <li>Fire extinguisher available</li> <li>First aid kit available</li> <li>Project Instructions and H</li> <li>Potable water available</li> <li>Sunscreen &amp; Bug Spray at</li> <li>Distress communications</li> <li>An oar is available on boat</li> <li>BOAT TRANSPORT</li> </ol>	per is trained in First Aid/CPR.  I, steering, bilge pump, anchor & propeller chece eting conducted with crew ces (PFD's) inspected daily.  Ie, charged and accessible.  H&S Plan available  vailable available (flare gun, air horn, Cell phone, CB) ard the boat in the event of mechanical failure	cked.		
16. Trailer winch engaged 17. Ball hitch seated and latch 18 Tools and equipment sect 19 Personnel not allowed ric 20. Safe distance is maintaine 21. Backup alarm or spotter to 22. Boat is unhitched on a lev	ghts verified as operable. In trailer and secured in a criss-cross fashion  The pin installed for a prior to boat movement de on boat as it is being towed for a with traveling around power lines for used when backing boat			
BOAT OPERATION  23. Boat holds appropriate si  24. Personnel cleared during  25. Kill switch clearly identifi  26. Personnel wearing appro  27. All personnel wearing PF  28. Boat will not be used for	g boat start-up lied and operational opriate PPE FD's			

Appendix D
Sediment Core Log

Dow: MOCA

Sediment Variability Study Sediment Core Log

Field Personnel:		Date:	Time:		
Weather Conditions:		Area ID:	Station Number:		
Northing		US State Plane 1983, Michigan South 2113, International Feet			
Easting		US State Plane 1983, Michigan South 2113, Internation	al Feet		
Water Depth	Units	Sediment Penetrated		Units	
		ocument i enerated	·		
Sediment Thickness	Units	Sediment Recovered		Units	
Depth Interval (decimal feet)	Sediment Description			Sample ID	
			<del></del> 		
			<del></del> 		
			<u> </u>		
			_		
			_		
Other Comments:					
Carlot Comments.					
Core Logger Signature:					