

INTERIM LABORATORY BIO-SAFETY GUIDELINES FOR HANDLING SARS SPECIMENS

Handling of **any** Clinical specimens →

I. Use Standard Precautions/Universal precautions

- Wear a lab coat and Use disposable gloves

Handling Specimens from a suspected SARS case, if meets CDC guidelines after review by MDCH Bureau of Epidemiology (517-335-8165):

II. Standard Precautions/Universal precautions as in I PLUS Goggles and a face shield or mask

Examples

- a. Blood and Urine Specimens if it does not involve any aerosolization.
- b. Routine examination of bacterial and mycotic cultures.
- c. Routine staining and microscopic analysis of fixed smears.
- d. Final packaging of specimens for transport to diagnostic laboratories for additional testing. Specimens should already be in a sealed, decontaminated primary container.
- e. Molecular analysis of extracted nucleic acid preparations.
- f. Electron microscopic studies with glutaraldehyde-fixed grids.
- g. Pathologic examination and processing of formalin-fixed or otherwise inactivated tissues.

III. II + BSC or respiratory protection* PLUS

Sealed centrifuge rotors or sample cups. Rotors and cups to be loaded in BSC.

Examples

- a. Aliquoting and/or diluting specimens other than blood and urine
- b. Inoculation of bacterial or mycological culture media.
- c. Performing diagnostic tests that don't involve propagation of viral agents in vitro or in vivo.
- d. Nucleic acid extraction procedures involving untreated specimens
- e. Preparation and chemical- or heat-fixing of smears for microscopic analysis.

If these conditions are not available, do the risk assessment and allow minimum number of workers to be present during centrifugation.

IV. BSL 3 facility with BSL-3 work practices

- a. Viral cell culture
- b. Initial characterization of viral agents recovered in cultures of SARS specimens.

v. Animal BSL-3 facilities and Animal BSL-3 work practices

- a. Inoculation of animals for potential recovery of the agent from SARS samples.
- b. Protocols involving animal inoculation for characterization of putative SARS agents

***Acceptable methods of respiratory protection**

- A properly fit tested NIOSH approved filter respirator (N-95 or higher);
- or powered air-purifying respirators (PAPRs) equipped with high efficiency particulate air (HEPA) filters.
- Accurate fit testing is a key component of effective respirator use.
- Personnel who cannot wear fitted respirators because of facial hair or other fit-limitations should wear loose fitting hooded or helmeted PAPRs.

Ref: <http://www.cdc.gov/ncidod/sars/lab.htm>