

Division of Environmental Health

Mercury Quick Reference Guidance Sheet

1,000 nanograms per cubic meter of air (ng/m³) = 1 microgram per cubic meter of air (ug/m³)

When screening a home, school or business:

- ➤ Check floors, and other suspect surfaces with a mercury vapor analyzer. Compare the readings to those taken in the breathing zone (about 4 feet off the floor). Do they match? Higher than breathing zone levels on the suspect surface likely indicates a source of mercury (beads) present.
- ➤ Bag suspect items such as clothing and shoes in a plastic trash bag, leaving enough headspace for any mercury vapor to accumulate. Let the bag sit at room temperature or warmer for a couple of hours.

Occupancy During Clean-up:

➤ 10, 000 ng/m³ in the breathing zone - The level below which occupants may choose to stay in a dwelling for the duration of a clean up of a reasonable length of time, (i.e. days vs. weeks). Values greater than 1 but less than 10 ug/m³ may require a site-specific plan to minimize exposure for sensitive populations. Keep windows open for adequate fresh air exchanges.

Screening Objects:

- > 1,000 ng/m³ and above Porous materials like upholstered furniture, carpeting should be removed and disposed of. Hard surfaces can be cleaned. If valued items are contaminated they can be aired-out outdoors and re-screened several weeks or months afterward.
- > Bagged items should be tested immediately upon opening the bag.

Those measuring 10,000 ng/m³ and greater: Dispose of appropriately.

Less than 1,000 ng/m³: Acceptable to keep

Between 10,000 and 1,000 ng/m³: Consider airing out for weeks in a warm, non-living space and re-test before use.

Post Clean-up Acceptable Air Clearance Values:

- > 1,000 ng/m3 in the breathing zone for <u>residences</u> when all the source mercury and contaminated items has been removed and adequate ventilation has occurred.
- > 3,000 ng/m³ for non-residential settings, i.e., schools, churches, offices, clinics etc., when all the source mercury and contaminated items has been removed and adequate ventilation has occurred.

MDCH Technical Support - 1-800-648-6942. Call anytime.