


EPA Office of Research and Development

HOMELAND SECURITY RESEARCH




EPA COVID-19 Research: Air Treatment and Transit Technologies



**MDOT Tech Talk
March 24, 2022**

*Katherine Ratliff, Ph.D.
Lukas Oudejans, Ph.D.*

ORD's Center for Environmental Solutions and Emergency Response



Overview of EPA Roles

Regulatory

- Pesticide Registration (FIFRA)
- FIFRA Enforcement
- Test Method Development

Response

- Cleanup Guidance
- Technical Support
- Preparedness/Mitigation

Research

- Aerosol Treatment
- Surface Cleaning and Disinfection
- Pesticide Application
- Pesticide Devices
- Residual Antimicrobial Coatings




Research topics were selected because they can result in a critical and rapid impact on the current SARS-CoV-2 response:


- How effective are aerosol treatment technologies and what are appropriate methods to determine effectiveness?
- How effective are alternative disinfection devices, such as UVC?
- Are there ways to disinfect high-touch, public spaces that remain effective for long periods of time?
- *How can real-world surfaces be cleaned and/or disinfected most effectively?*
- *What are effective ways to apply disinfectants?*
- *How can PPE be readily and effectively disinfected and reused?*

- COVID-19 has heightened awareness about airborne transmission of diseases (and indoor air quality issues)
- Increasing focus on **air treatment technologies**
 - *Many technologies are devices, which are not registered (efficacy not verified by EPA)*
- **Challenges:**
 - Social distancing not always feasible when repopulating indoor spaces (schools, offices, restaurants, public transit, events and gatherings, etc.)
 - Many air cleaning technologies on the market, but they often lack independent testing data

How effective are commercially-available aerosol treatment technologies at reducing concentrations of airborne pathogens?



- Ultraviolet-C (UVC) devices: e.g., upper-room germicidal UVC, in-duct UVC
- Chemical products and devices: in-room or in-duct; e.g., low-concentration ozone, low-concentration hydrogen peroxide, low-concentration triethylene glycol, bipolar ionization
- Physical removal: e.g., MERV-13 and specialized filters, portable air cleaners
- Combinations of the above




Focus on air treatment technologies and methods that can be continuously operating in occupied spaces (in-room or in-duct)




Aerosol Treatment: Methods

- Evaluate efficacy of technologies against non-pathogenic virus (MS2)
 - Air sampling
 - Surface sampling
- Utilize specialized Aerosol Test Facility in Research Triangle Park, NC
 - Large air treatment test chamber 10 x 12 x 25 ft (3000 ft³)
 - Controlled temperature / humidity
 - Mock HVAC system designed and installed for testing treatment technologies
- On-site microbiology support
- Particle size & count measurements






Test Chamber & HVAC System



Bipolar Ionization Device

- Bipolar ionization generates charged ions that react with airborne contaminants, including viruses
- Cold plasma bipolar ionization device was evaluated
 - Sized to treat 2000-4000 ft² of living space
- 30 to 90-minute ion buildup times in chamber prior to testing, resulting in ion counts of 1000-6000 ions/cm³




duct location for
technology installation



Bipolar Ionization Device

- Average percent reduction in recoveries of aerosolized MS2 from initial tests range from <0% to 86% throughout test duration
- No additional virus recovered from surfaces
- No surface inactivation observed



Efficacy:

$\text{Log}_{10} \text{ Reduction} = \text{Mean log}_{10} \text{ recovery (Control)} - \text{Mean log}_{10} \text{ recovery (Test Sample)}$


- Metallic catalyst and UVC light convert water vapor from the air into hydrogen peroxide and other reactive oxides and ions
- Two different units with different photocatalytic cell sizes were evaluated
 - 5-inch cell: designed to operate with HVAC blower operating at 250-1200 CFM; powered for 30 minutes prior to MS2 introduction
 - 9-inch cell: designed to operate with HVAC blower operating at 1200-3000 CFM; powered for 5 minutes prior to MS2 introduction





Photocatalytic Device

- Average percent reduction in recoveries during testing ranged from <0% to 73% for the 5-inch cell and from 27% to 93% for the 9-inch cell
- No additional virus recovered from surfaces
- No surface inactivation observed



Efficacy:

$\text{Log}_{10} \text{ Reduction} = \text{Mean log}_{10} \text{ recovery (Control)} - \text{Mean log}_{10} \text{ recovery (Test Sample)}$


- Antimicrobial air treatment product
 - Section 18 Emergency Exemptions for indoor use in GA, MD, NV, PA, TN, TX, VA (*as of 2/9/22*)
- Triethylene glycol (TEG) active ingredient
 - Commonly used in theatrical fog machines
 - Historic publications on air disinfection date to 1940's
 - 1.2 – 1.5 mg/m³ concentration of TEG during testing (NIOSH Method 5523)
- Two different test sequences evaluated:
 - Introduce product into aerosolized MS2
 - Introduce MS2 into product in chamber already at target concentration






Grignard Pure

Product introduced into MS2




MS2 introduced into Product





Grignard Pure

- Higher calculated efficacy when MS2 aerosolized with product present in test chamber
- Surface inactivation observed on inoculated coupons
 - GP into MS2: average \log_{10} reduction 1.6 ± 0.4 PFU/coupon
 - MS2 into GP: average \log_{10} reduction 1.9 ± 0.2 PFU/coupon
- Reduced MS2 recoveries on deposition coupons




* Some replicates at LOD (1.0 log₁₀ PFU/Sample)

3-Stage System and Filters

- 3-Stage Air Filtration and Purification System
 - Electrostatic filter (active charge applied to physical arrest filter)
 - UVC light bulb (254 nm)
 - Bipolar ionization module
 - Blower (~25 air changes per hour)
- Electret MERV-13 filters
 - Made with charged materials (no electricity applied)
 - Utilize blower of 3-Stage system
 - Two manufacturers



3-Stage System and Filters



Efficacy:

$\text{Log}_{10} \text{ Reduction} = \text{Mean log}_{10} \text{ recovery (Control)} - \text{Mean log}_{10} \text{ recovery (Test Sample)}$

ES – Electrostatic Filter

BPI – Bipolar Ionization

UVC – Ultraviolet-C Radiation



Aerosol Treatment Summary

Technology Type	Average Percent Reduction* in Recoveries During Testing
Bipolar Ionization Device	< 0% - 86%
Photocatalytic Device	< 0% - 73% for 5-inch cell 27% - 93% for 9-inch cell
Antimicrobial Air Treatment (Grignard Pure)	93% - 99.5% for product introduced into virus 97% - 99.9% for virus introduced into product
3-Stage Air Filtration and Purification System	95% - 99% for electrostatic filter alone 90% - 99% for electrostatic filter + bipolar ionization 94% - 99% for electrostatic filter + bipolar ionization + UVC 88% - 99% for bipolar ionization + UVC 63% - 99% for bipolar ionization alone
MERV-13 (Electret) Filters	66% - 99%

**Percent reduction from test conditions compared to control conditions*

UVC Disinfection: Problem Definition

- Growing interest in UVC for surface disinfection as a result of pandemic
 - Complement to regular cleaning/disinfection
- Emerging UVC products are being widely marketed
- EPA does not register pesticide (UVC) devices
- Increasing technical support requests for evaluating UVC devices (e.g., from public transit agencies)
 - Not all UVC is equal – wide range of device types and emitted wavelengths
- Feasibility of UVC in complex environments is relatively unknown



*New York Metropolitan Transport Authority
invested \$1 million on devices from Puro
Lighting for their trains and buses*

UVC Problem Research Questions



- What UVC doses are achievable in the field?
- Is UVC effective in inactivating SARS-CoV-2?
- What parameters impact efficacy?
 - Distance & Time => Dose
 - Material
 - Dry / wet droplets
 - Regular media vs saliva
- Can one overcome these limitations in a real world (outside lab) application?





UVC: LA Metro Field Test

- LA Metro field study (August 2020)
 - Evaluate practicality of Pulsed Xenon UVC units
 - Ease of use, setup time, durability, electrical load, functionality, etc.
 - Evaluate dose in field testing
- EPA supplied MS2-inoculated coupons to incorporate in field test
 - Why MS2? Non-enveloped, hardy virus; non-human pathogen; used in UV testing (e.g., water treatment)
- LA Metro measured UV dose for each coupon location / exposure





UVC: LA Metro Field Test Results


- Measured range of doses* in LA Metro tests: $\leq 3.5 \text{ mJ/cm}^2$
- Lowest doses at locations outside of direct line of sight or at large distances
- Highest dose for location at $\sim 60''$ directly in front of light, 30 min exposure time
- High reproducibility in doses between two tests run on different days
- *No significant reduction in MS2 on coupons exposed to UVC in LA Metro test*
 - Laboratory tests needed to understand this lack of virus inactivation



Source: AP

* Dose as measured with ILT SED270C (UV-C only) in metro car


UVC Efficacy Results Pulsed Xenon Light



- High efficacy for smooth materials (ABS plastic and stainless steel)
- Low efficacy for rough, porous surface (bus seat fabric)
 - Virus shielded from UVC light within material fibers
- SARS-CoV-2 in a dried saliva droplet is most difficult to inactivate.
 - Absorption of UVC light in saliva may explain this difference
- LA Metro's highest UVC dose recorded for a surface at 60" distance from a light and a 30 min exposure time was 3.5 mJ/cm²



UVC Efficacy Results LED (275 nm)




- High log reductions for smooth materials (ABS plastic and stainless steel)
- Low log reductions for rough, porous surface (bus seat fabric)
 - Virus shielded from UVC light within material fibers
- SARS-CoV-2 in a dried saliva is most difficult to inactivate
 - Absorption of UVC light in saliva may explain this difference



UVC Summary

- Estimated UVC doses (for two different light sources) needed to achieve various log reductions of SARS-CoV-2 on surfaces
- UVC dose conditions depend on multiple variables
 - *Lack of established methods makes direct comparisons challenging*
- Required doses for 3 log reduction (99.9%) could only be obtained with these tested UVC light sources at relatively short (30" or shorter) distances for operationally feasible exposure times (<60 min)
 - *Implementation of UVC in complex environments requires design and engineering solutions to increase effective doses.*
 - *UVC light is only effective where there is a direct line of sight between the light source and the contaminated surface*

- Antimicrobial Coatings – Questions:
 - Are they effective at killing viruses?
 - How long do they maintain their activity?
 - How durable are they?



- Approach
 - Collaboration with NYC MTA, LA Metro and other stakeholders to gather input
 - 20+ technology agreements with Vendors
 - Collaboration with EPA regulatory to develop an interim method for registration
 - Laboratory evaluation of products with non-pathogenic viruses to determine efficacy and durability
 - Subset of products evaluated against SARS-CoV-2





- Summary
 - Evaluated antiviral efficacy of ~26 antimicrobial coating products
 - Product efficacy against Phi6 ranged from very good to very little
 - Product stability was good, when not abraded
 - Products have low resistance to wetting and abrasion
 - Efficacy against SARS-CoV-2 ranged from 1 to 3 Log Reduction
 - Able to inform transit agencies, on expectation of performance from antimicrobial products and current EPA-registration status





LA Metro Copper Film Study

- Evaluated efficacy of peel-and-stick copper film that had been deployed in LA Metro's buses and railcars for 90 days in high-touch locations
- Both new and deployed copper film were effective against MS2
 - Suggests good durability



Monge, M., Abdel-Hady, A., Aslett, L.D., Calfee, M.W., Williams, B., Ratliff, K., Ryan, S., Oudejans, L. and Touati, A., 2022. Inactivation of MS2 bacteriophage on copper film deployed in high touch areas of a public transport system. *Letters in Applied Microbiology*, 74(3), pp.405-410.

- Aerosol treatment
 - Testing air treatment technologies at a large scale is important for understanding efficacy in real-world settings
 - Efficacy can range widely and depends on technology type
- UVC
 - Effective in laboratory studies, depending upon material types
 - Achieving high efficacy in field (real world) applications may be challenging
- Antimicrobial coatings
 - Demonstrate promise from initial effectiveness and stability
 - Challenge with durability as supplemental coating products



Acknowledgements

- EPA Program Offices
 - Office of Chemical Safety and Pollution Prevention
 - Office of Land and Emergency Management
 - Office of Enforcement and Compliance Assurance
 - Office of Air and Radiation
- EPA Regional Offices
- LA Metro
- NYC MTA
- WMATA
- Jacobs Technology Group (Task Orders 68HERC20F0392 and 68HERC21F0063)
- Battelle (Task Orders 68HERC20F0220, 68HERC20F0231, and 68HERC20F0241)




Points of Contact

Katherine Ratliff, Ratliff.Katherine@epa.gov

Lukas Oudejans, Oudejans.Lukas@epa.gov

ORD/CESER/HSMMD



<https://www.epa.gov/covid19-research>

DISCLAIMER: The United States Environmental Protection Agency (EPA), through its Office of Research and Development, funded and managed the research described. This presentation was peer and administratively reviewed and has been approved for presentation as an Environmental Protection Agency document. It does not necessarily reflect the views of the Environmental Protection Agency. No official endorsement should be inferred. This presentation includes photographs of commercially-available products. The photographs are included for purposes of illustration only and are not intended to imply that EPA approves or endorses the product or its manufacturer. EPA does not endorse the purchase or sale of any commercial products or services.

Data presented herein did not undergo a formal quality assurance review as outlined in “U.S. EPA Office of Research and Development’s Quality Management Plan for Scientific Research”. If these data are included in future EPA reports or other publications, they will be subjected to this review.