

FINAL Work Plan

For Investigation of Potential PFAS Impacts at Detroit Metropolitan Airport

Wayne County Airport Authority

Prepared by:

LimnoTech

501 Avis Dr, Ann Arbor, MI

734-332-1200

August 24, 2020

Blank Page





501 Avis Drive
Ann Arbor, MI 48108
734.332.1200
www.limno.com

FINAL Work Plan for Investigation of Potential PFAS Impacts at Detroit Metropolitan Airport

Blank Page



TABLE OF CONTENTS

1 Introduction.....	1
1.1 Investigation Scope and Objectives.....	1
1.2 Proposed Approach.....	1
2 Background Information.....	3
2.1 AFFF Usage at DTW.....	3
2.2 Stormwater Sampling.....	4
3 Geologic/Hydrogeologic Review.....	5
3.1 Subsurface Conditions.....	5
3.1.1 Geology.....	5
3.1.2 Hydrogeology.....	6
3.2 Additional Investigation.....	6
4 Storm Sewer System Monitoring.....	7
5 Soil and Groundwater Field Investigation and Sampling Plan.....	9
5.1 Health and Safety.....	9
5.2 Investigation Overview.....	9
5.3 Screening Criteria.....	9
5.3.1 Soil Screening Criteria.....	9
5.3.2 Groundwater Screening Criteria.....	10
5.4 Sampling Locations.....	10
5.5 Sampling Methods.....	13
5.5.1 Boring Methods.....	13
5.5.2 Sampling Methods.....	14
5.6 Analytical Method for Soil and Groundwater Samples...14	
5.7 Field Documentation.....	14
5.8 Sample Documentation.....	14
5.8.1 Sample Identification.....	15
5.8.2 Chain of Custody.....	15
5.9 Investigation-Derived Waste.....	15
5.10 Investigation Schedule.....	15
6 Data Quality Objectives.....	17
6.1 Investigation Data Quality Objectives.....	17
6.2 Data Quality Indicators.....	17
6.2.1 Accuracy.....	17
6.2.2 Precision.....	17
6.2.3 Completeness.....	18
6.2.4 Comparability.....	18
7 Quality Assurance/Quality Control.....	19
7.1 Sample Handling and Custody.....	19
7.1.1 Field Sampling Custody.....	19



- 7.1.2 Field Log Books19
- 7.1.3 Chain-of-Custody Forms 20
- 7.2 Quality Control Requirements..... 20
 - 7.2.1 Field Duplicates 20
 - 7.2.2 Field Blanks 20
 - 7.2.3 Equipment Blanks 20
- 7.3 Special Precautions: PFC-Free Equipment, Supplies, Materials and Clothing 20
- 7.4 Data Assessment21
 - 7.4.1 Laboratory Data Review and Validation21
 - 7.4.2 Airport Data Review and Validation21

APPENDIX A DTW PFAS Source Identification Study Plan

APPENDIX B Example Standard Operating Procedures

LIST OF FIGURES

- Figure 2-1. DTW Airport Layout..... 3
- Figure 2-2. DTW Known AFFF Usage Sites. 4
- Figure 4-1. DTW PFAS Source Identification Sampling Locations. 8
- Figure 5-1. Phase 1 FFTA Area Boring Locations. 11
- Figure 5-2. 3L Secondary Pond Area Boring Locations. 11
- Figure 5-3. Old G Concourse Crash Site Area Boring Locations.12
- Figure 5-4. Hangar 516 Area Boring Locations.12
- Figure 5-5. Rental Car Area Boring Locations.....13

LIST OF TABLES

- Table 4-1. DTW PFAS Source Identification Sampling Locations 7
- Table 5-2. Summary of DTW PFAS Sampling Areas..... 10
- Table 5-3. Sample Identification Examples.....15



1 Introduction

This work plan describes investigation activities at Detroit Metropolitan Airport (DTW) in Wayne County, Michigan, planned in response to a \$250,000 award from the Municipal Airports Grant program administered by the Michigan Departments of Transportation (MDOT) and Environment, Great Lakes, and Energy (EGLE). This work plan augments and supersedes the ongoing PFAS Source Identification Study (attached as Appendix A) required by EGLE (*January 21, 2020 DTW PFAS Source Identification Study Plan - Update*, January 2020) prepared in response to the letter dated December 4, 2019 from the Michigan Department of Environment, Great Lakes, and Energy (EGLE) *Compliance Communication Regarding the Use of Per- and Poly-fluoroalkyl Substances (PFAS) at Detroit Metropolitan Airport, Romulus, Michigan*.

This work plan will identify measures the WCAA will undertake at DTW to investigate potential PFAS impacts on- and off-site and assess potential for impact to drinking water wells on-and off-site.

1.1 Investigation Scope and Objectives

Based on the EGLE letter and the information discussed above, the primary objectives of this work plan are:

1. To determine whether past use of aqueous film-forming foam (AFFF) at DTW has resulted in PFAS impacts to soil and/or groundwater.
2. If impacts exceeding Michigan Part 201 criteria are identified, to determine the nature and magnitude of PFAS concentrations in any impacted soil and/or groundwater.
3. If groundwater is found to be impacted in excess of Michigan Part 201 criteria, to determine groundwater flow direction from those impacted areas.
4. To evaluate PFAS in the storm sewer system and identify potential source areas contributing PFOS and PFOA.

1.2 Proposed Approach

The work plan will be implemented as a series of tasks with subsequent tasks to be conducted based on the findings the ongoing investigation noted above and on additional information as it is obtained from this investigation. WCAA will conduct PFAS investigation tasks in a phased approach as guided by the information generated during each phase of the study. The progression of tasks to be conducted as part of this work plan will include:

- Storm sewer network sampling of stormwater
- Direct Push Soil and Groundwater Sampling for PFAS at former AFFF use areas
- Deeper Boring Soil and Groundwater Sampling for PFAS (if indicated as necessary), and;
- If impacted groundwater is identified, hydrogeologic review to further the understanding of local subsurface geologic and hydrogeologic characteristics, develop an initial conceptual model of hydrogeology around the airport, and identify nearby (within one mile) drinking water wells.



Each of the additional follow-up activities are described in the following sections of the work plan.



2 Background Information

Detroit Metropolitan Airport (DTW) is a major international airport and is one of the world's leading air transportation hubs. DTW is operated by the Wayne County Airport Authority (WCAA). The airport encompasses nearly 5,000 acres south of Interstate 94 and east of Interstate 275 in Romulus, Michigan. A map of the airport is shown in Figure 2-1.




Figure 2-1. DTW Airport Layout.

2.1 AFFF Usage at DTW

Per- and Polyfluoroalkyl Substances (PFAS) have historically been used in the manufacture of aqueous film-forming foam (AFFF), used for petroleum fire-fighting. Firefighting materials used at U.S. commercial airports are regulated and specified by the Federal Aviation Administration (FAA) by the Code of Federal Regulations (14 C.F.R. Part 139). This regulation mandates that all airports operating in the United States use AFFF that contains PFAS compounds.

Past fire response activities at many airports have resulted in the release of PFAS through AFFF to the environment. Because of such historical uses, EGLE is requiring WCAA to develop this work plan to investigate potential PFAS contamination.

Airport operations typically involving AFFF include training, certification, and emergency response activities.

DTW has identified five (5) sites where AFFF may have been used on the property. These areas include:

- The former fire training area (FFTA) – AFFF may have been used as part of required training activities
- The 3L Secondary Pond – received runoff from certification testing
- Old G Concourse – AFFF was used in response to an aircraft crash
- Hangar 516 – accidental AFFF release from the building hydrant system; and
- Rental car area – AFFF was used in response to an aircraft crash.

Known AFFF usage sites on DTW property are shown in Figure 2-2.




Figure 2-2. DTW Known AFFF Usage Sites.

2.2 Stormwater Sampling

At these five sites, WCAA will conduct stormwater sampling to identify potential areas contributing PFAS to the storm sewer system and soil/groundwater sampling to evaluate potential PFAS impacts to soil and groundwater. Proposed activities and procedures are described in Sections 4 (storm sewer) and 5 (soil and groundwater).

3 Geologic/Hydrogeologic Review

3.1 Subsurface Conditions

Existing resources and environmental/geotechnical reports were reviewed to understand what is known about subsurface conditions at DTW to support this Work Plan. A summary of information reviewed to date is provided in the following sub sections.

3.1.1 Geology

The regional geology predominately consists of glacial deposits comprised of lacustrine clays and silts, which may be overlain in places with lacustrine sand and gravel¹. In Wayne County, a layer of glacial deposits overlies bedrock in thicknesses ranging from a few feet to over 330 ft². Bedrock in Wayne County consists of late- to middle-Devonian-age sedimentary rocks that include the following formations/groups which sub crop below the glacial deposits from west to east: the Antrim shale formation; the Traverse Group formation (primarily carbonate rocks); the Dundee Limestone and the Detroit River Group (primarily carbonate rocks) (EGLE, 2020). The Michigan GeoWebFace Map indicates the presence of bedrock valleys north and south of DTW as follows (EGLE, 2020):

- North of DTW, there is an east-northeast trending bedrock valley that roughly parallels the south side of M-12, then it trends southwest from approximately Wayne Road to just west of the intersection of 275 and Interstate I-94 to south of the City of Belleville.
- South of DTW, there is a roughly west to east-northeast trending bedrock valley located south of Willis Road and Pennsylvania Road.

The glacial deposits are thinnest near the mouth of the Detroit River and generally thicken gradually towards the west and more rapidly towards the northwest (USDA, 1977). Information from a previous site investigation indicates that bedrock was not encountered in borings drilled to 20 ft below grade, and that the bottom of the native clay was not defined; but that literature and area well logs indicate the clay can be up to 130 feet thick regionally, with the base of the clay largely controlled by the top of bedrock³.

Site geology was characterized during soil investigation and excavation activities conducted in 2014 - 2017 at the airport bulk fuel storage facility (located northwest of the airport, just south of interstate I-94 and east of Vining Road), which showed the following (Barr, 2017):

- Depth to bedrock ranges from 65 ft to 148 ft below grade in nearby Wellogic logs provided in the Barr Engineering Report.
- Surface gravel observed to be between 0 and 1 foot thick (average approximately 6 inches). Native soils beneath the gravel surface cover generally consist of clay and extend to at least 25 feet bgs, based on the soil borings conducted at the site.
- Intermittent sand seams were observed in the clay, varying in thickness from less than an inch to approximately two feet.

¹ Michigan Department of Environment, Great Lakes and Energy (EGLE) GeoWebFace Map: <http://www.deq.state.mi.us/GeoWebFace/>

² United States Department of Agriculture (USDA), November 1977. Soil Survey of Wayne County Area, Michigan.

³ Barr Engineering, April 2017. Spill Response and Investigation Summary Report, DTW Tank Farm – Jet A Fuel Release at Pump Islands PEAS #1-28641366.



- Sand was generally used as backfill where clay was excavated for the construction of utility trenches, or concrete pads. Utility trenches at the site generally extend to approximately 4.5 to 9 feet bgs and are underlain by clay.

3.1.2 Hydrogeology

There are no Well Head Protection Areas (WHPAs) identified in the vicinity of DTW, or throughout Wayne County (EGLE, 2020). Bedrock deposits in Wayne County generally contain highly mineralized groundwater (USDA, 1977).

Per the Barr investigation at the airport bulk fuel storage facility, water levels recorded on area Wellogic logs are approximately 3 to 60 feet below grade, and Wellogic well screen data indicate many of the wells are screened or terminate within the underlying bedrock below the low permeability clay (Barr, 2017). This indicates that while the apparently thick clay unit is likely partially saturated, the deep confined resource aquifer likely has little interaction with shallow perched water and water contained within the overlying clay (Barr, 2017). Other information obtained from the 2014 -2017 site investigations at the airport bulk fuel storage facility shows the following regarding site hydrogeologic conditions (Barr, 2017):

- Groundwater elevation measurements collected in 2016 and 2017 from site monitoring wells identified groundwater at depths averaging from 1.29 to 2.58 feet bgs (636.82 to 636.90 feet above mean sea level). The monitoring wells are screened from 2 ft to 7 ft and 4 ft to 9 ft below grade.
- There is a slight groundwater gradient along the main utility trench towards the southwest at the airport bulk fuel storage facility area.
- Based on site conditions, groundwater is believed to be perched above the clay and concentrated in the utility trenches. Groundwater appears to be limited to the backfill materials and is likely trapped, with little, if any, flow through the native clay, which suggests that trapped groundwater could be classified as “*groundwater not in an aquifer*”.

3.2 Additional Investigation

If the results of the soil and groundwater investigation indicate the presence of PFAS at levels above screening criteria described in Section 4 of this work plan, WCAA will conduct additional review of existing geologic and hydrogeologic information. Information to be reviewed will include boring logs from past on-site construction activities, boring logs from nearby off-site well installations, and other geological information that is readily available. The State of Michigan WellLogic database will be used as the primary information source for off-site well installations within one mile of the airport. Existing information will be compiled, reviewed, and used to generate a site map(s) and geological cross sections. The map(s) and cross sections will be prepared with the intent of identifying areas of permeable soils, potential confining layers, approximate depth to groundwater, and the location of potable wells near the airport.



4 Storm Sewer System Monitoring

WCAA has identified 22 locations as described in the *January 21, 2020 DTW PFAS Source Identification Study Plan - Update* that will be sampled to identify drainage areas for further investigation. Primary sites are shown in red and will be sampled first. As noted in the study plan, if sampling results from these sites show PFOS concentrations less than 12 ng/L and PFOA concentrations less than 12,000 ng/L, no further sampling will be conducted in the associated sub-areas. If the concentration of either compound is above their respective Water Quality Standard, additional sampling will be conducted further up the drainage networks with the goal of identifying potential source areas. The locations are listed in Table 4-1 and shown in Figure 4-1.

Table 4-1. DTW PFAS Source Identification Sampling Locations

Map #	Node #	Site Name	Area Drained
1	1-1	Manhole 362	72" stormsewer draining the southwest portion of the PS1 Drainage Area.
2	1-1-a	Manhole 165	21" stormsewer draining the portion of the Manhole 362 area where AFFF use is suspected during previous airplane crashes.
3	1-2	Manhole 01	42" stormsewer draining former Pumpstations 4 and 5 - former DTW Maintenance Facility and Rental Car Areas.
4	1-2-a	Manhole 56	30" stormsewer draining former Pumpstation 5 - Rental Car Areas.
5	1-2-b	Manhole 9	42" stormsewer draining former Pumpstation 4 - former DTW Maintenance Facility and Rental Car Areas.
6	1-3	Manhole 722	66" stormsewer draining Blue Deck parking lot area, portion of R/W 22L, and former GM Hangar.
7	1-3-a	Manhole AA-1	36" stormsewer draining former GM Hangar.
8	1-3-b	Junction Chamber 812	66" stormsewer draining Blue Deck parking lot area and portion of R/W 22L.
9	2-1	Pumpstation 2 wetwell	Entire North Terminal, Delta Hangar, SkyChefs, and Fire Station 200 area.
10	2-1-a	Manhole 2-1	54" stormsewer draining 22L Deicing Pad (former ARFF Station area), RON spots.
11	2-1-b	Manhole 2-2	84" stormsewer draining North Terminal ramps, Delta Hangars, and Fire Station 200 area.
12	2-2	Pumpstation 13 wetwell	Entire McNamara Terminal ramp, and 3L & 4R Deicing Pads.
13	2-2-a	3L Deicing Pond Discharge	3L Deicing Pad (former AFFF testing area).
14	6-1	Pumpstation 6	R/W 3L and Northline Road Tenant areas.
15	6-1-a	Manhole 902	UPS and former Mesaba hangar areas.
16	6-1-b	Manhole 904	Northline Road tenant facilities.
17	6-2	Pumpstation 6A wetwell	R/W 27L, former fire training area, south portion R/W 3L.
18	6-2-a	Manhole 538	60" stormsewer draining south end of R/W 3L.
19	6-2-b	Drainage Ditch	Ditch draining former fire fighting training area.
20	6-3	Pumpstation 6B wetwell	R/W 4L, Pumpstation 12, and Pumpstation 3 areas.
21	6-3-a	Pumpstation 12 wetwell	McNamara roof, 4R Deicing Pad fringe, and south portion R/W 4R.
22	6-3-b	Pumpstation 3 wetwell	West Service Drive facilities (including DTW Maintenance Facilities).






Figure 4-1. DTW PFAS Source Identification Sampling Locations.

Stormwater sampling procedures are described in the *January 21, 2020 DTW PFAS Source Identification Study Plan - Update*, (January 2020) included with this document as Appendix A. As noted in correspondence related to the Source Identification Plan, sampling results will be submitted to EGLE within 90 days after receipt of results for the initial sampling event.



5 Soil and Groundwater Field Investigation and Sampling Plan

The details of the planned investigation are provided below.

5.1 Health and Safety

A project health and safety plan (HASP) will be prepared for subsurface investigation activities at DTW. A copy of the HASP will be provided to each organization participating in field work, including subcontractors. All field personnel will have reviewed the site-specific HASP prepared for this investigation and will be aware of the chemical and physical hazards specific to this project. The HASP will be reviewed by all field personnel prior to initiating any field activities. In addition, all persons performing field investigative tasks for this project have experience working on similar site investigation projects and have completed OSHA 40-hour HAZWOPER safety training, with 8-hour refresher courses as needed. A copy of the HASP will remain onsite for the duration of field activities.

5.2 Investigation Overview

This investigation will consist of soil borings at each of the five past AFFF use areas. Soil samples will be collected from up to three (3) depths from each boring. The initial investigation is divided into two phases:

- Phase 1 – Direct push soil borings of soils will be performed (up to ten feet below ground surface or until groundwater is encountered, whichever is shallower) to determine the presence or absence of PFAS impacts to soil and, if impacts are detected above the screening criteria discussed in Section 5.3, to provide preliminary data on the horizontal extent of potential impacts in shallow soil. At a minimum, one soil sample will be collected from unsaturated soil just above the elevation of the water table and one groundwater sample will be collected, from each Phase 1 boring.
- Phase 2 – If groundwater samples collected in Phase 1 borings exhibit concentrations in excess of the screening criteria discussed in Section 5.3, three monitoring wells will be installed in each area and groundwater will be resampled to verify the Phase 1 findings. Groundwater elevations will be measured in these monitoring wells to determine local groundwater flow direction.

Sampling locations are described in Section 5.4 and sampling methods are described in Section 5.5.

5.3 Screening Criteria

The State of Michigan has developed soil cleanup criteria for soil and groundwater under Part 201 of the Natural Resources and Environmental Protection Act (1994 PA 451, as amended). PFAS criteria have been developed for perfluorooctanoic acid (PFOA) and perfluorooctane sulfonic acid (PFOS). These criteria will be used to evaluate sample results, as described below.

5.3.1 Soil Screening Criteria

Soil sample results will be screened by comparing them to the Michigan Part 201 screening levels for PFOA and PFOS. Those screening levels are listed below:

- PFOA: soil screening level = 10,000 ppb



- PFOS: soil screening level = 0.24 ppb

5.3.2 Groundwater Screening Criteria

Groundwater sample results will be screened by comparing them to the Part 201 groundwater criteria for drinking water protection, 8 ppt for PFOA and 16 ppt for PFOS .

5.4 Sampling Locations

The planned boring locations under phase 1 are shown in Figures 5-1 through 5-5. The locations are subject to adjustment depending on field conditions. Table 5-2 summarizes the planned soil sampling for the investigation. Boring locations may vary from the planned locations depending on utility locations, accessibility, and other conditions encountered in the field. If it appears that a boring location needs to be changed, the decision will be made jointly between the field team leader and the project manager. The boring locations were chosen based on available information and limitations of accessibility due to site constraints (grade, surface cover, etc.). All boring locations will be marked in the field using a hand-held global positioning system (GPS) device with sub-meter accuracy.

Table 5-1. Summary of DTW PFAS Sampling Areas.

Investigation Area	Bore Type	Samples	Targeted Total Depth (ft. below grade)	# Phase 1 Locations	# Phase 2 Locations
FFTA	Shallow (Direct Push)	Up to three (3) soil samples and one (1) groundwater (if present) sample in each boring.	<10	5	t.b.d.
3L Secondary Pond	Shallow (Direct Push)	Up to three (3) soil samples and one (1) groundwater (if present) sample in each boring.	<10	3	t.b.d.
Old G Concourse Crash Site	Shallow (Direct Push)	Up to three (3) soil samples and one (1) groundwater (if present) sample in each boring.	<10	3	t.b.d.
Hangar 516	Shallow (Direct Push)	Up to three (3) soil samples and one (1) groundwater (if present) sample in each boring.	<10	3	t.b.d.
Rental Car Area	Shallow (Direct Push)	Up to three (3) soil samples and one (1) groundwater (if present) sample in each boring.	<10	3	t.b.d.





Figure 5-1. Phase 1 FFTA Area Boring Locations.



Figure 5-2. 3L Secondary Pond Area Boring Locations.



Figure 5-3. Old G Concourse Crash Site Area Boring Locations.



Figure 5-4. Hangar 516 Area Boring Locations.





Figure 5-5. Rental Car Area Boring Locations.

Additional sampling locations may be determined based on the data generated by existing and ongoing investigations, including the DTW PFAS Source Identification Study.

5.5 Sampling Methods

5.5.1 Boring Methods

Borings will be conducted using direct-push (e.g. Geoprobe) methods. Borings will be advanced in five-foot increments and extracted for inspection. Field personnel will observe the soil removed from the boreholes and collect samples as described in Section 5.5.2. Soil types encountered in each boring will be logged in the field by an experienced scientist or engineer. Methods for conducting soil borings are described below.

5.5.1.a Phase 1 Soil Borings

Phase 1 borings will be advanced using direct-push (e.g. Geoprobe) methods, up to ten (10) feet deep or until the water table is encountered, whichever occurs first. Soil types encountered in each boring will be logged in the field by an experienced scientist or engineer. Up to three (3) soil and one (1) groundwater (if encountered) sample will be collected from these borings in accordance with the methods described in Section 5.5.2.

5.5.1.b Phase 2 Monitoring Wells

If Phase 2 sampling is implemented, monitoring wells will be installed using direct-push (e.g. Geoprobe) methods. Soil types encountered in each boring will be logged in the field by an experienced scientist or engineer. These borings will be advanced five feet beneath the water table elevation at the time of drilling

and well screens will be set at an elevation to account for the potential variability in water table fluctuations.

5.5.2 Sampling Methods

The methods and procedures for groundwater and soil sampling are described below.

5.5.2.a Soil Sampling – Geoprobe Borings

Up to three (3) soil samples will be collected from each direct push boring. One sample will be collected near surface (upper 1' of soil). The second sample will be collected near the bottom of the boring if shallow groundwater is not encountered, but more likely will be collected immediately above the depth at which soil saturation is observed.

All soil samples will be collected by the geologist or engineer observing the boring. Samples will be collected from the extracted soil cores at the appropriate depths. The depths of all soil samples will be recorded in the field notes after the sample core is removed from the borehole at each location. The soil sample will be transferred from the sampling device into clean sampling jars. Extracted core sections with obvious odors will be targeted for analysis. Soil sampling will be conducted in accordance with SOPs for soil sampling, modified as necessary and appropriate for PFAS sampling.

5.5.2.b Groundwater Sampling

Up to three (3) groundwater monitoring wells will be installed using the direct-push (Geoprobe) equipment at each location where Phase 2 investigation activities are conducted. Each monitoring well will be installed with a screened interval that is approximately centered on the observed saturated zone at each location. One (1) groundwater sample will be collected from each well in accordance with SOPs for groundwater sampling, as well as other SOPs as appropriate. All Phase 2 monitoring wells will be temporary (i.e., no protective covers installed) until the groundwater sample results are reviewed.

5.6 Analytical Method for Soil and Groundwater Samples

All soil and groundwater samples will be analyzed for the State of Michigan minimum PFAS analyte list (https://www.michigan.gov/pfasresponse/0,9038,7-365-88059_95747---,00.html) by Paragon Laboratories, using ASTM 7979 and 7979 Mod. At the request of EGLE staff, Perfluoro-4-ethylcyclohexanesulfonates (PFECCHS, CAS#646-83-3) is also being added to the parameter list, pending method development by Paragon.

5.7 Field Documentation

All field activities will be documented by field personnel designated by the field team leader, using the procedures described in the example SOP for field documentation (attached in Appendix B), as modified for PFAS sampling. Upon completion of investigation activities, field documentation will be retained with other project files. Further detail on field documentation is contained in Section 7.1.2.

5.8 Sample Documentation

Sample documentation includes assignment of a unique sample identification number at the time of sampling, which is subsequently used through the chain of custody to the final laboratory report.



5.8.1 Sample Identification

Samples will be designated with a unique identification that includes the boring or monitoring well identification number and, in the case of soil samples, the depth interval (in feet below ground surface) from which the sample is collected. The letters “MB” will be used to designate manual soil borings, the letter “B” will designate soil borings installed using direct-push equipment and the letters “MW” will be used to designate monitoring wells. Example sample identification codes are given below:

Table 5-2. Sample Identification Examples

Sample Description	Sample Identification Number
Soil sample collected between 2 to 3 feet below ground surface from manual boring #2	MB2(2-3)
Soil sample collected between 9 to 10 feet below ground surface from Geoprobe boring #7	B7(9-10)
Groundwater sample collected from monitoring well #13	MW13

This identification system will reduce the potential for confusion between sample results.

5.8.2 Chain of Custody

At the time of sampling, field sampling personnel will initiate a chain of custody (COC) using the COC form provided by the analytical laboratory. The COC is discussed in more detail in Section 7.1.

5.9 Investigation-Derived Waste

The investigation activities in this work plan are expected to generate the following types of investigation-derived waste (IDW):

- Used expendable materials related to sampling (e.g., nitrile gloves)
- Excess groundwater pumped during groundwater sampling
- Equipment decontamination water (municipal supply)
- Excess soil material generated during soil borings

Used expendable materials will be placed in sealed trash bags for disposal at a licensed solid waste facility. Environmental media (groundwater and soil) and decontamination water will be stored in drums at a secure location until they can be properly characterized for disposal.

5.10 Investigation Schedule

WCAA expects to initiate work upon approval of this work plan by EGLE. Initial stormwater sampling will be conducted within two weeks of approval and authorization to proceed. Phase 1 borings will also be initiated within two weeks of approval and authorization to proceed. Subsequent activities will be conducted following review of initial stormwater and phase 1 boring results. In accordance with MDOT grant funding requirements, all activities under this work plan will be completed within 18 months of State approval.



Blank Page



6 Data Quality Objectives

Data quality objectives (DQOs) are quantitative and qualitative criteria intended to ensure that the data collected during the investigation are of an adequate level of quality for their intended uses.

6.1 Investigation Data Quality Objectives

The following specific DQOs have been identified for this Phase 2 investigation:

1. Analytical results for groundwater and soil samples must accurately represent actual groundwater and soil chemical quality.
2. Analytical results for groundwater and soil samples should be of sufficient quality to inform the conceptual site model and for comparison to regulatory criteria.
3. Analytical results must meet quality control requirements for accuracy, precision, completeness and comparability.

6.2 Data Quality Indicators

Data quality indicators (DQIs) are measures that are used to assess data quality and to verify that DQOs are met. The four DQIs (accuracy, precision, completeness and comparability) are discussed below.

6.2.1 Accuracy

Accuracy reflects the degree of bias in a measurement. To determine accuracy, a laboratory or field value is compared to a known or true concentration. Accuracy is determined by such QC indicators as: matrix spikes, surrogate spikes, laboratory control samples (blank spikes) and performance samples. Accuracy will be assessed using percent recovery, calculate as follows:

$$\%R = 100 \times (A-B)/C$$

Where:

%R = percent recovery

A = analyte concentration from spiked sample

B = analyte concentration from unspiked sample

C = analyte concentration of spike added

For this investigation, acceptable %R will be 80% - 120%.

6.2.2 Precision

Precision is a measure of the reproducibility of data measurements under similar conditions and is typically assessed by measuring the degree of mutual agreement between or among independent measurements of the same sample. The common measure of precision is the relative percent difference (RPD), calculated as follows:

$$RPD = 100 \times (X_1 - X_2) / [(X_1 + X_2) / 2]$$

Where: X_1 = original sample value

X_2 = duplicate sample value.



RPD relates to the analysis of duplicate laboratory or field samples. Typically, field precision is assessed by co-located samples, field duplicates, or field splits and laboratory precision is assessed using laboratory duplicates, matrix spike duplicates, or laboratory control sample duplicates.

For this investigation target RPD limits will be 40%. RPDs will not be calculated if the observed concentration is less than five times the reporting limit in either the sample or field duplicate.

6.2.3 Completeness

Completeness measures the quantity of valid data obtained during the investigation, compared to the quantity of valid data expected. For this investigation, it is expected that all data will be valid.

Completeness is calculated as follows:

$$\text{Completeness} = 100 \times (\text{number of valid samples obtained}) / (\text{number of samples collected})$$

The completeness goal for this investigation is 95%.

6.2.4 Comparability

Comparability expresses the confidence with which one data set can be compared to another. For this investigation, comparability will be assessed by documenting conformance to the SAP and noting any significant deviations. The data quality assurance review will also be considered in assessing data comparability. It should be noted that the current lack of a standardized methodology for the analysis of PFAS in soil and groundwater matrices must be considered when comparing data generated from different analytical laboratories.



7 Quality Assurance/Quality Control

This section outlines the quality assurance/quality control (QA/QC) measures that will be used during field investigation activities.

7.1 Sample Handling and Custody

7.1.1 Field Sampling Custody

The objective of field sample custody is to assure that samples are traceable and are not compromised between sample collection and receipt by the analytical laboratory. A person will have custody of a sample when the samples are:

- In their physical possession
- In their view after being in their possession
- In their personal possession and secured to prevent tampering (such as in a locked office or vehicle); and
- In a restricted area accessible only to authorized personnel and the person is one of the authorized personnel

Chain of custody documentation will consist of chain of custody forms. One copy of the COC will be retained by the field sampling personnel and subsequently placed on file along with other documentation of field activities. The remaining copies of the COC will be placed inside the sample cooler. Each time the samples change custody (with the exception of commercial delivery services) the COC will be signed by both the new and former responsible parties.

7.1.2 Field Log Books

Field log-books serve as a daily record of events, observations, and measurements during field activities. All information pertinent to monitoring activities is recorded in the log-books, and will include:

- Name and title of author
- Name(s) of field crew personnel
- Name of site and project code
- Description of sample location
- Number and volume of samples taken
- Date and time of collection
- Sample identification numbers
- Sampling method
- Preservatives used
- Field measurements (temperature, dissolved oxygen)
- Field observations (weather conditions, flow appearance, etc.)



7.1.3 Chain-of-Custody Forms

Completed chain-of-custody forms will be required for all samples to be analyzed. Chain-of-custody forms will be prepared by the field sampling crew during the daily sample collection events. The chain-of-custody form will contain the following information:

- Unique sample identification number
- Sample location
- Sample date and time
- Sample description
- Sample type
- Sample preservation
- Analyses required

The original chain-of-custody form will accompany the samples to the laboratory. The chain-of-custody forms will always remain with the samples and will be signed by a representative of the laboratory upon receipt of the samples.

7.2 Quality Control Requirements

7.2.1 Field Duplicates

Field duplicates (splits) will be collected and analyzed to check the precision or reproducibility of sampling and analytical procedures. Field duplicates are defined as two separate samples collected at a single location and time, labeled with separate identification codes so the laboratory cannot identify the samples as duplicates. Duplicate samples will be collected at the rate of approximately 10 percent. The duplicate samples will be handled and analyzed by the laboratory the same as all other samples.

7.2.2 Field Blanks

Field blanks will be analyzed to check for chemical constituent infiltration and sample bottle contamination originating from sample transport and storage. A field blank will consist of analyte-free water (supplied by the laboratory) poured into a sample bottle at the sample site and preserved according to the parameters to be analyzed. Field blanks will be collected at the rate of approximately 10 percent.

7.2.3 Equipment Blanks

Equipment blanks will be collected and analyzed to check for cross-contamination potential between samples or from sampling equipment. An equipment blank will consist of analyte-free water (supplied by the laboratory) poured over a sampling device or drawn through sample tubing and into a sample bottle at the sample site and preserved according to the parameters to be analyzed. At least one equipment blank will be collected for each sampling device type used during the investigation.

7.3 Special Precautions: PFC-Free Equipment, Supplies, Materials and Clothing

Special precautions shall be employed to minimize the possibility of sample cross-contamination related to the low PFAS detection limits and the widespread use of PFAS in consumer products and industrial processes, including:



- Conduct sampling beginning in areas of known or suspected lowest concentrations and progressing to areas of highest concentrations
- Water used for equipment cleaning/rinsing will be sampled periodically to evaluate potential PFAS content
- Drilling and sampling equipment and materials should be free of polytetrafluorethylene (PTFE), ethylene tetrafluoroethylene (ETFE), and fluorocarbon-based products whenever feasible (e.g., field filters, sample tubing, pumps, lubricants, O-rings, pipe-thread pastes, tapes, sealants); and
- Personal protective equipment, clothing, and hygiene products should be free of PFAS (e.g., fluoropolymer linings used on Tyvek, Nomex, and Viton materials, GoreTex linings, water resistant/waterproof/stain resistant treatments, sunblock, insect repellants, cosmetics/hand creams, food packaging protective of water and grease. All equipment, materials, supplies and clothing used during field activities must be PFC-free in accordance with the guidelines presented below.

A standard operating procedure for PFAS sampling is contained in Appendix B.

7.4 Data Assessment

QA review of all data will be conducted and documented before the data are used for any decisions or published in any way other than the original laboratory reports.

7.4.1 Laboratory Data Review and Validation

Laboratory QA review will be conducted in accordance with the laboratory Quality Assurance Plan (QAP). Upon receipt of the laboratory report for each sample batch, the project QA reviewer will verify that internal laboratory QA was conducted.

7.4.2 Airport Data Review and Validation

When data are received from the analytical laboratory, they will be evaluated by the project QA reviewer to determine if they meet project requirements. Specific items to be reviewed during data validation are:

- Chain of custody completeness
- Holding times
- Duplicate analyses data
- Field and equipment blank data
- Precision and accuracy data
- Matrix spike and matrix spike duplicate data
- Surrogate standards (where applicable)
- Overall data assessment

The project QA reviewer will document the QA review of each data set in writing.



Blank Page



APPENDIX A

DTW PFAS Source Identification Study Plan



Blank Page



DETROIT METROPOLITAN AIRPORT

PFAS Source Identification Study Plan (Updated)

Prepared for the Michigan Department of Environment,
Great Lakes, and Energy

January 21, 2020

Table of Contents

1	Background.....	1
2	Proposed Sampling Locations	1
3	Sample Collection, Handling, Quality Control, and Quantification Levels.....	1
3.1	Sampling Procedures / Quantification Levels.....	1
3.2	Quality Assurance / Quality Control - Field	2
3.2.1	Field Sampling Custody	2
3.2.2	Field Data Forms	2
3.2.3	Chain-of-Custody Forms.....	2
3.2.4	Quality Control Requirements	3
3.2.5	Special Precautions: PFC-Free Equipment, Supplies, Materials and Clothing	3

1 Background

EGLE requested the DTW PFAS Source Identification Study Plan prepared on August 31, 2010 be updated. This updated plan was therefore prepared.

2 Proposed Sampling Locations

The sampling locations proposed for the Updated PFAS SISP will be based on conducting initial sampling at stormwater pumpstations that discharge to each DTW stormwater detention pond and then working upstream into the stormsewer network that flows to each pumpstation. The table below and the attached map indicates sites that are proposed for sampling.

The Updated SISP will be a dynamic exercise with the primary sites shown in red being sampled first. If these primary sites yield PFOS concentrations of less than 12 ng/L and PFOA concentrations of less than 12,000 ng/L, no further sampling will be conducted in the associated sub-areas. If either of these compounds is above the two Water Quality Standards noted, additional "upstream" sampling will be conducted.

Map #	Node #	Site Name	Area Drained
1	1-1	Manhole 362	72" stormsewer draining the southwest portion of the PS1 Drainage Area.
2	1-1-a	Manhole 165	21" stormsewer draining the portion of the Manhole 362 area where AFFF use is suspected during previous airplane crashes.
3	1-2	Manhole 01	42" stormsewer draining former Pumpstations 4 and 5 - former DTW Maintenance Facility and Rental Car Areas.
4	1-2-a	Manhole 56	30" stormsewer draining former Pumpstation 5 - Rental Car Areas.
5	1-2-b	Manhole 9	42" stormsewer draining former Pumpstation 4 - former DTW Maintenance Facility and Rental Car Areas.
6	1-3	Manhole 722	66" stormsewer draining Blue Deck parking lot area, portion of R/W 22L, and former GM Hangar.
7	1-3-a	Manhole AA-1	36" stormsewer draining former GM Hangar.
8	1-3-b	Junction Chamber 812	66" stormsewer draining Blue Deck parking lot area and portion of R/W 22L.
9	2-1	Pumpstation 2 wetwell	Entire North Terminal, Delta Hangar, SkyChefs, and Fire Station 200 area.
10	2-1-a	Manhole 2-1	54" stormsewer draining 22L Deicing Pad (former ARFF Station area), RON spots.
11	2-1-b	Manhole 2-2	84" stormsewer draining North Terminal ramps, Delta Hangars, and Fire Station 200 area.
12	2-2	Pumpstation 13 wetwell	Entire McNamara Terminal ramp, and 3L & 4R Deicing Pads.
13	2-2-a	3L Deicing Pond Discharge	3L Deicing Pad (former AFFF testing area).
14	6-1	Pumpstation 6	R/W 3L and Northline Road Tenant areas.
15	6-1-a	Manhole 902	UPS and former Mesaba hangar areas.
16	6-1-b	Manhole 904	Northline Road tenant facilities.
17	6-2	Pumpstation 6A wetwell	R/W 27L, former fire training area, south portion R/W 3L.
18	6-2-a	Manhole 538	60" stormsewer draining south end of R/W 3L.
19	6-2-b	Drainage Ditch	Ditch draining former fire fighting training area.
20	6-3	Pumpstation 6B wetwell	R/W 4L, Pumpstation 12, and Pumpstation 3 areas.
21	6-3-a	Pumpstation 12 wetwell	McNamara roof, 4R Deicing Pad fringe, and south portion R/W 4R.
22	6-3-b	Pumpstation 3 wetwell	West Service Drive facilities (including DTW Maintenance Facilities).

3 Sample Collection, Handling, Quality Control, and Quantification Levels

3.1 Sampling Procedures / Quantification Levels

Paragon Laboratories, Inc. will conduct all collection, handling, and analysis of samples collected for this Updated SISP using ASTM Method D 7979_{mod}. Quantification limits of 2 ng/L will be achieved for PFOS and PFOA. The sampling collection and handling methods used by Paragon are attached to this document.

Sampling will be conducted by staff from Paragon Laboratories. Procedures will be consistent with Paragon's Standard Operating Procedures (Appendix A), and with EGLE's General PFAS Sampling Guidance (MDEQ, 2018). Samples will be collected via manual grab sampling methods, and procedures used will be documented in field notes. Proper decontamination procedures and minimizing disturbance of the sample site will minimize the potential for cross-contamination and collection of non-representative samples.

Sampling will be conducted by trained staff familiar with sampling procedures. Staff will wear clean nitrile gloves and other appropriate personal protective equipment. Samples will be collected as described in Appendix A, using disposable beakers and pipets. Trip blanks and field blanks will be included for quality assurance.

3.2 Quality Assurance / Quality Control - Field

This section outlines the quality assurance/quality control (QA/QC) measures that will be used during field monitoring activities.

3.2.1 Field Sampling Custody

The objective of field sample custody is to assure that samples are traceable and are not tampered with between sample collection and receipt by the analytical laboratory. A person will have custody of a sample when the samples are:

- In their physical possession;
- In their view after being in their possession;
- In their personal possession and secured to prevent tampering; and
- In a restricted area accessible only to authorized personnel and the person is one of the authorized personnel.

Field custody documentation will consist of both field log books and chain of custody forms.

3.2.2 Field Data Forms

Field log books serve as a record of sampling events, observations, and measurements during field activities. All information pertinent to monitoring activities is recorded on the data forms, and will include:

- Name(s) of field crew personnel;
- Name of site;
- Description of sample location;
- Number and volume of samples taken;
- Date and time of collection;
- Sample identification numbers;
- Sampling method;
- Preservatives used;
- Field measurements (temperature, pH, etc.);
- Field observations (weather conditions, flow appearance, etc.).

3.2.3 Chain-of-Custody Forms

Completed chain-of-custody forms will be required for all samples to be analyzed. Chain-of-custody forms will be prepared by the field sampling crew during the daily sample collection events. The chain-of-custody form will contain the following information:

- Unique sample identification number;
- Sample location;
- Sample date and time;
- Sample description;
- Sample type;
- Sample preservation;
- Analyses required.

The original chain-of-custody form will accompany the samples to the laboratory. The chain-of-custody forms will remain with the samples at all times and will be signed by a representative of the laboratory upon receipt of the samples.

3.2.4 Quality Control Requirements

Field Measurements

The accuracy of field measurements will be maintained through calibration of the field instruments according to manufacturer's specifications. Accuracy will be checked prior to the sampling event and following the sampling event and recorded in the field log book.

Field Duplicates

Field duplicates (splits) will be collected and analyzed to check the precision or reproducibility of sampling and analytical procedures. Field duplicates are defined as two separate samples collected at a single location and time, labeled with separate identification codes so the laboratory cannot identify the samples as duplicates. Duplicate samples will be collected at the rate of approximately 50 percent. The duplicate samples will be handled and analyzed by the laboratory the same as all other samples.

Field Blanks

Field blanks will be analyzed to check for chemical constituent infiltration and sample bottle contamination originating from sample transport and storage. A field blank will consist of analyte-free water poured into a sample bottle at the sample site and preserved according to the parameters to be analyzed. Field blanks will be collected at the rate of one per event.

3.2.5 Special Precautions: PFC-Free Equipment, Supplies, Materials and Clothing

Special precautions will be employed to minimize the possibility of sample cross-contamination related to the low PFAS detection limits and the widespread use of PFAS in consumer products and industrial processes, including:

- Conduct sampling beginning in areas of known or suspected lowest concentrations and progressing to areas of highest concentrations;
- Water used for equipment cleaning/rinsing will be sampled periodically to evaluate potential PFAS content;
- Sampling equipment and materials should be free of polytetrafluorethylene (PTFE), ethylene tetrafluoroethylene (ETFE), and fluorocarbon-based products (e.g., field filters, sample tubing, etc.); and
- Personal protective equipment, clothing, and hygiene products should be free of PFAS (e.g., fluoropolymer linings used on Tyvek, Nomex, and Viton materials, GoreTex linings, water resistant/waterproof/stain resistant treatments, sunblock, insect repellants, cosmetics/hand creams, food packaging protective of water and grease. All equipment, materials, supplies and clothing used during field activities must be PFC-free in accordance with the guidelines presented below.

Paragon's standard operating procedure for PFAS sampling is included as Appendix A.

Sampling Wastewater and Sludges for Per- and Polyfluoroalkyl Substances (PFAS) Using ASTM 7979 and 7979 Mod.

Please read and understand this entire procedure prior to beginning any sampling.

BEFORE YOU BEGIN

- (1) Become familiarized with ASTM 7979 and 7979 Mod. sampling procedures. These procedures and guidelines MUST be followed when sampling for PFAS. A sampling guideline from MDEQ is also available at https://www.michigan.gov/documents/pfasresponse/Wastewater_PFAS_Sampling_Guidance_636791_7.pdf
- (2) Be aware of possible contaminants such as fast food wrappers, cosmetics, and certain clothing and avoid contamination.
- (3) Wash hands thoroughly before the sampling event.
- (4) Gather and wear appropriate PPE such as nitrile gloves, safety glasses, etc.
- (5) Each PFAS kit includes a minimum of five (5) 15-mL conical tubes, and one 250-mL bottle for a Total Suspended Solids (TSS) collection. The Trip Blank (TB) is custody sealed and is also included in each kit. A Field Blank (FB) is provided with four blank 15-mL conical tubes. (Additional bottles are available upon request for additional uses including non-compliance samples, and/or additional blank types).
- (6) Each 15-mL tube is accompanied by two resealable bags. The samples shall be returned to the same resealable bags in which each was sent.
- (7) A disposable 250-mL beaker and disposable transfer pipet is also included with each kit.

[NOTE: One kit is utilized per sampling site to avoid contamination.]

SAMPLING PROCEDURE

- (1) Gather and wear appropriate PPE. Ensure a new clean pair of nitrile gloves are worn for each sampling event.
- (2) Remove the FB from the bags and slowly open the tube to expose the contents to the sampling environment. The FB is to remain open and uncapped during the entire sampling process.
- (3) Using the provided 250-mL disposable beaker, collect the water sample ensuring the water to be tested has only contacted the beaker.
- (4) Unbag and **fill each 15-mL tube with EXACTLY 5 mL of sample** with the provided disposable pipet. Upon receipt **samples greater or less than 5 mL will NOT be accepted**. Properly label each sample with the information requested on each bottle label. Place tubes back into bags in which they were received.
- (5) Fill and label the 250-mL TSS bottle with sample.
- (6) Upon completing the sampling recap, label and re-bag the FB.

FINAL STEPS



- (1) Record the sample location, date and time on the Chain-Of-Custody Record (COC) FORM-N0013A. Ensure this information matches that of the bottle labels.
- (2) Return the bottles and bags back to the cooler in which they were sent. Pack the cooler gently with doubled, resealable bags containing natural ice to preserve the samples between 0 °C and 6 °C. Place custody seal on cooler. Return the samples promptly to the lab.

**Field Data Form for PFAS Sampling of Wastewater, Surface Water,
and Sludge with <2% Solids for Testing by ASTM D7979**

Sampling Date		Sampled By	
Customer Name			
Sample Site Name			
Sample Site Address and/or GPS Coordinates			
Sample Point Name and/or GPS Coordinates			
Sample Point Description			
Is the sample point inside or outside?			
If outside, describe the weather.			
Describe the sampling technique.			
SAMPLE TYPE	CHECK IF COLLECTED	NOTES	
Trip Blank			
Field Blank			
Equipment Blank			
Sample			
Sample Duplicate			
Matrix Spike			
Matrix Spike Duplicate			
Total Solids Verification Sample			
Was there a concern that the samples may be ≥2% Solids, and if so, was a second set of samples collected using the techniques for testing by ASTM D7968?			
Were the samples taken from a single aliquot of the source water or separate aliquots?			
At what approximate depth were the samples taken?			
Were the samples immediately labeled, custody sealed, bagged, and packed on ice for transport?			
Was all non-disposable CAT1 equipment decontaminated after the sampling event?			
Describe any deviations from the guidelines provided in SOP-N0187 with explanation for why deviations occurred. Alternatively, or additionally, describe any concerns regarding the sampling event which may affect sample results.			


January 21, 2020 PFAS Source Identification Study Plan (Updated) SITE MAP (DTW)

4/26/2019 9:23 AM
HRC_QW.dwg
V:\201601\20160112\20160123_DTW_SS_MAP.dwg
Paredes Eduardo



HRC
HUBBELL, ROTH & CLARK, INC
 CONSULTING ENGINEERS SINCE 1915
 555 HULEY DRIVE P.O. BOX 824
 BLOOMFIELD HILLS, MICH. 48303 - 0824
 PHONE: (248) 454-8300
 FAX (1st. Floor): (248) 454-8312
 FAX (2nd. Floor): (248) 538-2552
 WEB SITE: <http://www.hrc-engr.com>

DATE	ADDITIONS AND/OR REVISIONS
4/26/2019	WCAA REVIEW
1/29/2018	WCAA REVIEW
1/23/2018	WCAA REVIEW
1/15/2018	WCAA REVIEW
1/5/2018	WCAA REVIEW
12/7/2017	WCAA REVIEW
9/7/2017	WCAA REVIEW
5/16/2016	WCAA REVIEW



LEGEND

- LOW CONCENTRATION GLYCOL
- HIGH CONCENTRATION GLYCOL
- DWSG GLYCOL FORCE MAIN
- PUMP STATION NO. 1 DRAINAGE
- PUMP STATION NO. 2 DRAINAGE
- PUMP STATION NO. 3 DRAINAGE
- PUMP STATION NO. 6 DRAINAGE
- PUMP STATION NO. 6A DRAINAGE
- PUMP STATION NO. 6B DRAINAGE
- PUMP STATION NO. 11 DRAINAGE
- PUMP STATION NOS. 10, 12, & 14 DRAINAGE
- PUMP STATION NO. 13 DRAINAGE
- OFFSITE DRAINAGE
- SANITARY DIVERSION
- STORM WATER ENHANCEMENT FEATURES

WAYNE COUNTY AIRPORT AUTHORITY
DETROIT METRO AIRPORT STORM SEWER MAP

STORM SEWER LAYOUT

HRC JOB NO. 20160112	SCALE 1" = 800'
DATE 5/16/2016	SHEET NO. OF

© 2016 Hubbell, Roth & Clark, Inc. All Rights Reserved

APPENDIX B

Example Standard Operating Procedures



Blank Page



I. INTRODUCTION

This standard operating procedure (SOP) is applicable to the collection of representative samples for analysis of per- and polyfluoroalkyl substances (PFAS; also referred to as and subsets of perfluorinated chemicals (PFCs)). The procedures described are intended to be applicable to most environmental media and sampling methods, although they were developed with an emphasis on water samples (e.g., drinking water, ground water, surface water). These typically applicable procedures have been adapted from a number of sources and may be varied or changed as required, dependent upon site conditions or equipment and procedural limitations, as long as the goal of collecting representative samples is maintained. The actual procedures used should be documented in the field notes, especially if changes are made. This SOP is designed to be used in conjunction with another SOP that describes the specific sampling methods for a specific environmental medium.

PFAS are a large group of chemicals used in many consumer, commercial, and industrial products and processes, and include water-, stain-, and oil-repelling coatings and fire-fighting foams. Some chemicals in this group (e.g., perfluorooctane sulfonate (PFOS) and perfluorooctanoic acid (PFOA)) have been identified as persistent, bioaccumulative, and toxic chemicals. PFOS, PFOA, and their known precursors were largely phased out in the United States in the mid-2000s and early 2010s. Sample analytical reporting for PFAS analytes is usually at very low concentrations (parts per trillion, ppt), which can exacerbate problems with cross-contamination of samples.

There are two primary interferences or potential problems with representative sampling. These include cross

contamination of samples and improper sample collection. Following proper decontamination procedures and minimizing disturbance of the sample site will minimize these problems as follows:

- ◆ Cross contamination problems can be eliminated or minimized through the use of dedicated sampling equipment for each location. If this is not possible or practical, then decontamination of sampling equipment is necessary. Refer to the Equipment Cleaning SOP.
- ◆ Conduct sampling beginning in areas of known or suspected lowest concentrations and progressing to areas of highest concentrations.
- ◆ Improper sample collection can involve using contaminated equipment, disturbance of stream or impoundment substrate, and sampling in an obviously disturbed area.

To collect a representative sample, the hydrology and morphometrics of a stream or impoundment should be determined prior to sampling. This will aid in determining the presence of phases or layers in lagoons or impoundments, flow patterns in streams, and appropriate sampling locations and depths. In addition, water quality indicator data may be collected, if necessary, in water bodies to determine if stratification is present. Measurements such as dissolved oxygen, pH, temperature, and redox potential can indicate if strata exist which would affect analytical results.

II. MATERIALS

A wide range of products commonly used in site investigations are known or suspected to contain PFAS. It is critical that the sampling program design consider as many sources of PFAS contamination as practicable to minimize cross contamination during a sampling event. All field equipment,

supplies, materials and personnel clothing used during sampling operations shall be PFAS free as noted below and in Tables 1 and 2.

- ◆ All sampling, monitoring and drilling equipment (e.g., field filters, tubing, pumps, lubricants, packers, transducers, liners, O-rings, pipe-thread pastes, tapes, sealants, valves, and wiring) must be constructed of materials that are free from the following:
 - a) Polytetrafluorethylene (PTFE), trademark Teflon[®];
 - b) Ethylene tetrafluoroethylene (ETFE), trademark Tefzel[®];
 - c) Polyvinylidene fluoride (PVDF), trademark Kynar[®];
 - d) Fluorinated ethylene propylene (FEP), trademark Neoflon[®].
- ◆ Personal protective equipment, clothing, and hygiene products should be free of PFAS (e.g., fluoropolymer linings used on Tyvek, Nomex, and Viton materials, GoreTex linings, water resistant/waterproof/stain resistant treatments, sunblock, insect repellants, cosmetics/hand creams, food packaging protective of water and grease).
- ◆ Sample containers should be polypropylene or HDPE and/or as specified/provided by the laboratory; do not use glass to avoid analyte adsorption.
- ◆ Sample transfer to the laboratory should be conducted at 4°C ± 2°C or as specified by the laboratory using ice in double-bagged polyethylene plastic; do not use chemical- or gel-based cooling products.
- ◆ Use only laboratory-supplied PFAS-free water for preparation of field reagent blanks and equipment blanks.
- ◆ Water from any other sources, including public water supplies, used for any other

purposes must be pre-determined to be PFAS-free.

- ◆ Deionized (DI) water will not be used to clean equipment due to the possible contamination from polytetrafluoroethylene material used in the DI water purification system.

III. PREPARATIONS

- ◆ Determine the extent of the sampling effort, the sampling methods to be employed, and the types and amounts of equipment and supplies needed.
- ◆ Obtain the necessary sampling and monitoring equipment to suit the task. Consider sample volume, depth, deployment circumstances (shore, wading, boat, currents), type of sample, sampler composition materials, and analyses to be conducted.
- ◆ Decontaminate or pre-clean equipment and ensure that it is in working order.
- ◆ Prepare scheduling and coordinate with staff, clients, and regulatory agency, if appropriate.
- ◆ Perform a general site survey prior to site entry, in accordance with the site specific Health and Safety Plan.
- ◆ Use stakes, flagging, or buoys to identify and mark all sampling locations. If required, the proposed locations may be adjusted based on site access, property boundaries, and surface obstructions.
- ◆ If collecting sediment or near-shore soil samples, develop procedures that will eliminate interferences with collection of representative water samples.
- ◆ The field team leader will work with field personnel to assure compliance with PFAS-free guidelines (see Table 1) prior to commencement of field activities. Table 2 provides a list of prohibited and acceptable items for a

PFAS field investigation. Daily compliance inspections will be conducted prior to beginning field activities. Corrective action will include removal of noncompliance items or workers from the site until in compliance.

IV. GENERAL SAMPLE COLLECTION PROCEDURES

1. Record pertinent data on the field log (see attached Surface Water Sampling Field Log, or equivalent).
2. Label all sample containers with the date, time, well number, site location, sampling personnel, and other requested information.
3. Don appropriate personal protective equipment (as required by the Health and Safety Plan).
 - ◆ Do not sample without powderless nitrile gloves.
4. Clean all sampling equipment prior to sample collection according to the procedures described in Section V.
5. Sample collection (see Tables 1 and 2 for complete lists of acceptable and unacceptable attire, materials, etc.):
 - ◆ The sample cap should never be placed directly on the ground during sampling.
 - ◆ Markers (Sharpie® or otherwise) are to be avoided.
 - ◆ Bottles should only be opened immediately prior to sampling.
 - ◆ Dust and fibers must be kept out of sample bottles.
 - ◆ Ballpoint pens may be used to label sample containers.
6. For samples requiring field filtering, use the appropriate PFAS-free equipment and, if possible, collect the sample directly into the sample container.
7. If field preservation is required (see SAP and/or QAPP), place appropriate preservative into the sample container prior to sample collection. Note the preservative used on the sample container and sampling log.
8. Quality control samples are normally specified and described (i.e., collection procedures, frequencies) in the work plans (SAP and/or QAPP), and for PFAS sampling they may include trip blanks, field reagent blanks, field equipment blanks, field duplicate samples, and matrix spike/matrix spike duplicate samples. These samples should be collected in the following manner:
 - ◆ Samples should be double-bagged using resealable low density polyethylene (LDPE) bags (e.g. Ziploc®).
 - ◆ If possible, collect PFAS samples prior to collecting samples for other, non-PFAS analytes (e.g., VOCs) or field parameters (temperature, pH, etc.).
 - ◆ Trip blanks should be prepared by the laboratory using PFAS-free water at the time sample bottleware is prepared for delivery to the field. Trip blank containers shall be of the same type of sample container as those used for investigative samples collected for PFAS analysis. A laboratory-supplied trip blank (comprised of the same sample containers, containing the same reagents, preservatives and other consumables used for investigative PFAS analysis) shall be placed in the

environmental sample cooler immediately after the first sample collected for PFAS analysis is placed in the cooler. Trip blank samples shall be given a sample date and time of when the trip blank is placed in the environmental sample cooler. Trip blank samples shall accompany investigatory sample containers collected for PFAS analysis from collection, during the duration of the sample event, and during shipment to the laboratory. At no time after preparation and prior to arriving at the laboratory shall trip blanks be opened.

- ◆ Field reagent blanks should be collected using two appropriate laboratory-supplied containers (one containing PFAS-free water and the other empty). During the sampling event, field personnel transfer the preserved PFAS-free water from one container into the other container, screw on the laboratory-supplied caps, and place the sample containers into the cooler for submittal with the samples collected that day.
- ◆ Field equipment or rinse blanks should be collected by pouring PFAS-free water through/over the decontaminated sampling device into the sample container in the field, preserved and shipped to the laboratory with the field samples. Generally, equipment blanks are only collected if reusable sampling equipment is employed.
- ◆ Field duplicate samples should be collected into two distinct sample containers at the same time or immediately following one another in accordance with procedures described in the SAP or QAPP. Each sample of a field duplicate pair

employs the same type of sample container, preservatives and other additives used. If blind duplicate samples are specified, one of the duplicate samples should be labelled so that it does not identify the other sample of the duplicate pair to the laboratory. For example, one sample of the duplicate pair would be labelled following the normal protocol, while the second would be labelled with a sample ID of “DUPLICATE” and a blank line placed in the location, date and time boxes of the sample label. It is important that the duplicate pair samples are identified separately in the field notes with information including location, sample ID (as entered on the sample container label and COC), sample date and time so that analytical results can be paired after received from the laboratory.

- ◆ Matrix spike (MS) and matrix spike duplicate (MSD) samples include two additional volumes of sample material collected in the field at the same time as an investigative sample (similar to field duplicate sampling), or may be collected by the laboratory from an existing investigative sample submitted from the field.
9. Record sample collection information on the field log and store the samples in an iced cooler according to the PFAS-free guidelines described herein and in the Standard Operating Procedure for the Shipping and Handling of Samples.
 10. Handle, pack, and ship samples according to the PFAS-free guidelines described herein and in Standard Operating Procedure for the Shipping and Handling of Samples.
 - ◆ Do not use chemical or blue ice.

- ◆ Refresh with regular ice double bagged in Ziploc® bags
- ◆ Chain of Custody should be bagged in Ziploc® storage bags and taped to the inside of the cooler lid.
- ◆ The cooler should be taped closed with a custody seal and shipped by overnight courier.

V. EQUIPMENT DECONTAMINATION

Field sampling equipment used multiple times can become contaminated with PFAS. Decontamination procedures should be implemented to prevent cross-contamination.

The following procedures must be followed:

- ◆ Do not use Decon 90®
- ◆ Laboratory supplied PFAS-free water is preferred for decontamination.
- ◆ Water from any other sources, including public water supplies, used for any other purposes must be pre-determined to be PFAS-free.
- ◆ Deionized (DI) water will not be used to clean equipment due to the possible contamination from polytetrafluoroethylene material used in the DI water purification system.
- ◆ Alconox®, Liquinox® and Citranox® can be used for equipment decontamination.
- ◆ Sampling equipment can be scrubbed using a polyethylene or PVC brush to remove particulates.
- ◆ Decontaminated sampling equipment should be triple rinsed using PFAS-free water.

VI. EQUIPMENT-SPECIFIC SAMPLE COLLECTION PROCEDURES

See appropriate equipment- and medium-specific sample collection SOP and/or sampling equipment operation manual, as specified in the SAP or QAPP.

Table 1. PFAS-Free Guidelines.

PFAS-Free Guidelines (source: USEPA, DoD and ITRC)
Field Clothing and PPE: (see reference at bottom for acceptable products)
No clothing or boots containing Gore-Tex™
All safety boots made from polyurethane and PVC
No materials containing Tyvek®
Field crew has not used fabric softener on clothing
Field crew has not used cosmetics, moisturizers, hand cream, or other related products this morning
Field crew has not applied unauthorized sunscreen or insect repellent
Field Equipment:
No Teflon® or LDPE containing materials on-site
All sample materials made from stainless steel, HDPE, acetate, silicon, or polypropylene
No waterproof field books on-site
No plastic clipboards, binders, or spiral hard cover notebooks on-site
No adhesives (Post-It Notes) on-site
No Sharpies and permanent markers allowed; regular ball point pens are acceptable
No aluminum foil allowed
Keep PFAS samples in separate cooler, away from sampling containers that may contain PFAS
Coolers filled with regular ice only. No chemical (blue) ice packs in possession
Sample Containers:
All sample containers made of HDPE or polypropylene
Caps are unlined and made of HDPE or polypropylene
Wet Weather Gear:
Wet weather gear made of polyurethane and PVC only
Equipment Decontamination:
“PFC-free” water on-site for decontamination of sample equipment. No other water sources to be used.
Only Alconox and Liquinox to be used as decontamination materials
Food Considerations:
No food or drink on-site with exception of bottled water and/or hydration drinks (e.g., Gatorade, Powerade) that is available for consumption only in the staging area
Reference-NHDES https://www.des.nh.gov/organization/divisions/waste/hwrb/documents/pfc-stakeholder-notification-20161122.pdf

Table 2. Prohibited and Acceptable Items for Perfluorinated Compound (PFC) Field Investigations.

PPE, Clothing, Hygiene Products	PFC Concerns	Approved Alternative
Steel-toed boots	Boots may not contain Gore-Tex. Many waterproof boots are lined with Gore-Tex and are prohibited.	Steel-toed boots made with polyurethane and polyvinyl chloride (PVC)
Clothing	Water resistant, waterproof, or stain-treated clothing should be avoided. (EDQW 2016)	Clothing made of synthetic or natural fibers should be worn. Non-new cotton is preferred. Field gear should be laundered a minimum of six times prior to use, avoiding use of fabric softeners. Cotton overalls may be provided for use.
Rain Gear	Most rain gear is coated with a Gore-Tex lining and contains fluoropolymers.	Rain gear made from polyurethane and wax-coated materials may be worn (U.S. Navy 2015; EDWQ 2016).
Gloves	Nitrile gloves are specified for use in EPA Method 537.	Only nitrile gloves should be used. These should be changed often as outlined in EDQW 2016. Recommended powderless nitrile gloves.
Protective clothing	Fluoropolymer linings are used on Tyvek, Nomex, and Viton materials (U.S. Navy 2015; EDWQ 2016)	Avoid these materials. Select alternative protective clothing that does not contain fluoropolymers.
Sunblock and insect repellent	Many manufactured sunblocks and repellents contain PFCs.	Avoid use. If necessary, use of a 100% natural ingredient product may be used upon approval.
Cosmetics, moisturizers, hand creams, etc.	Many of these products contain surfactants and represent a potential source for PFCs.	Use of these products should be avoided prior to a sampling event. Acceptable products may include: Sunscreens - Alba Organics Natural Sunscreen, Yes To Cucumbers, Aubrey Organics, Jason Natural Sun Block, Kiss my face, Baby sunscreens that are "free" or "natural" Insect Repellents - Jason Natural Quit Bugging Me, Repel Lemon Eucalyptus Insect repellent, Herbal Armor, California Baby Natural Bug Spray, BabyGanics Sunscreen and insect repellent - Avon Skin So Soft Bug Guard Plus – SPF 30 Lotion
Food and drink	Food packaging often contains PFCs as a protectant from water and grease.	No food or drink shall be brought on-site, except for bottled water and hydration drinks. No blue ice packs should be used. Additionally, hands should be thoroughly washed following consumption of any wrapped fast food or pizza.

General Sampling Equipment and Field Supplies	Approved Alternative
Standard decontamination water or municipal water	Water from a known source that has been analyzed for PFCs and has been determined to be acceptable for the specific sampling program.
Decon 90 detergent	Alconox and Liquinox are the only detergents approved for decontamination (EDQW 2016)
Glass or Teflon-lined sampling bottles and lids	Polypropylene or high-density polyethylene (HDPE) sample bottles with an unlined polypropylene HDPE screw cap
Fluoropolymer tubing, valves, and other parts in pumps	HDPE and silicon materials (EDQW 2016)
Teflon tubing, bailers, tape, and plumbing paste	HDPE and silicon materials or disposable equipment
Pumps, packers, transducers, tubing, liners, valves, and wiring with polytetrafluorethylene or ethylene tetrafluoroethylene	Alternative materials
LDPE HydraSleeves	HDPE HydraSleeves (EDQW 2016)
Aluminum foil	Thin HDPE sheeting
Markers and waterproof pens	Non-waterproof pens (EDQW 2016)
Rite-in-the-rain paper, binders, and plastic clipboards	All field paperwork should be printed on standard paper and placed in a non-water-resistant folder or aluminum clipboard (EDQW 2016)
Post-It Notes	No Post-It Notes should be brought to the site
Chemical (blue) ice packs	Only regular ice should be used for refrigeration on site (EDQW 2016)

Table 2 References

Source Document - Groundwater and PFAS: State of Knowledge and Practice, Section 5: Field Sampling and Analysis, National Groundwater Association Press, 2017 – Draft Copy Not NGWA Board-approved, Not for circulation.

EDQW 2016. Bottle Selection and Other Sampling Considerations When Sampling for Per- and Poly-Fluoroalkyl Substances (PFAS). Revision 1.1.

U.S. Navy 2015a. Perfluorinated Compounds (PFCs) Interim Guidance/Frequently Asked Questions (FAQs). Memorandum from Commander, Naval Facilities Engineering Command, January 29, 2015.

U.S. Navy 2015b. Bureau of Medicine and Surgery, 2015. Testing for Perfluorochemicals (PFCs) in Drinking Water. Memorandum for Commander, Navy Medicine East.

I. INTRODUCTION

Equipment cleaning areas will be located within or adjacent to a specific work area or as specified in the Health and Safety Plan. The equipment cleaning procedures described in this document include pre-field, in-field, and post-field cleaning of sampling equipment. The sampling equipment consists of soil sampling devices, well construction materials, ground-water sampling devices, water testing instruments, and other activity-specific sampling equipment. All non-disposable sampling equipment will be cleaned after completion of each sampling event. If appropriate, cleaning procedures will be monitored through the analysis of rinse blank samples as described in the project work plan or QAPP. **NOTE: If field activities involve per- and polyfluoroalkyl substances (PFASs) such as PFOS or PFOA, refer to the PFAS sampling SOP for additional measures which supersede this SOP.**

II. MATERIALS

The following materials will be available during equipment cleaning, as needed:

- ◆ Personal protection equipment (as required in the Health and Safety Plan);
- ◆ Distilled/de-ionized water;
- ◆ Non-phosphate detergent (Alconox, Liquinox, or equivalent);
- ◆ Tap water;
- ◆ Appropriate cleaning solvent (e.g., methanol, hexane, nitric acid);
- ◆ High-pressure hot water/steam cleaning unit;
- ◆ Wash basins;
- ◆ Brushes;
- ◆ Polyethylene sheeting;
- ◆ Aluminum foil;
- ◆ Plastic overpack drum, storage tub, or other suitable storage unit (for bladder or other pumps);
- ◆ Large heavy-duty garbage bags;
- ◆ Spray bottles (to hold tap water, distilled/de-ionized water, methanol, hexane, or nitric acid); and
- ◆ Disposable and/or heavy-duty reusable (PVC, latex or nitrile) gloves.

III. STORAGE OF EQUIPMENT

All cleaned sampling equipment will be stored in a clean environment and, where appropriate, the equipment will be covered/sealed with aluminum foil.

IV. SAFETY PROCEDURES DURING EQUIPMENT CLEANING

1. Personnel will wear the following personal protection equipment at a minimum, when cleaning sampling equipment (e.g., split-spoon sampler, trowels) and larger equipment (e.g., drill rig, augers):
 - ◆ Safety glasses, goggles, or a splash shield; and
 - ◆ PVC, latex, or nitrile outer gloves,
 - ◆ Coated Tyvek[®] or Saranex[®] disposable coveralls or rainsuit, optional for small equipment cleaning; and
 - ◆ Chemical resistant over boots, optional for small equipment cleaning.
2. All solvent rinsing if required, will be conducted in an adequately ventilated area.
3. All solvents transported into the field will be stored and packaged in

appropriate containers with care taken to avoid exposure to extreme heat.

4. Handling of solvents will be consistent with the manufacturer's Material Safety Data Sheets (MSDS).

V. FIELD CLEANING PROCEDURES

A. Cleaning Station

A designated field equipment cleaning station location will be established to conduct all cleaning at each work area of the Site. The field equipment cleaning station will be located away from the immediate work area to minimize adverse impacts from work activities on the cleaning procedures, but close enough so the sampling teams can minimize equipment handling and transport. All heavy equipment such as drill rigs and backhoes will receive an initial cleaning prior to use at the Site and will be cleaned again before leaving the site. The frequency of any additional cleaning will depend on the amount of use the heavy equipment receives and the extent of exposure to dirt and contaminants during the sampling event.

B. Cleaning of Smaller Sampling Equipment

Cleaning of smaller sampling equipment (e.g., split-spoon samplers, bailers, trowels) will be conducted according to the following sequential procedure:

- ◆ Non-phosphate detergent (Alconox, Liquinox, or equivalent) and tap water wash;
- ◆ Tap water rinse;
- ◆ Solvent rinse, if required (e.g., methanol or hexane for organic

constituent analysis, nitric acid for inorganic constituent analysis); and

- ◆ Triple distilled/de-ionized water rinse.

The first step in decontamination is physical removal, where gross contaminants such as dust, soils and sediments can be removed through physical means such as wiping, scraping, shaking, and in some cases steam cleaning. Non-phosphate detergent and tap water scrub is intended to remove all visible particulate matter, residual oil and grease, and most but not all contaminants. Surfactants or detergents accumulate at the water to gas, solid, and oils interface, break the adhesive forces between the contaminant and the surface being cleaned, making the contaminants more soluble, allowing the contaminants to be washed away. The tap water rinse is necessary to remove all soapy residues and wash away loosened contaminants. The need for a specific solvent used for the solvent rinse, if required in the work plan or QAPP, will depend upon what the sample will be analyzed for and what contaminants are expected to be present. Some contaminants such as PCBs adhere to surfaces so tightly that a methanol or hexane rinse is required to break the adhesive bonds and adequately decontaminate the sampling equipment. Caution should be used when using solvent rinses to make sure that the chosen solvent is compatible with the sampling equipment and any PPE it will be used upon. It should be noted that most PPE constructed of organic materials could be damaged or dissolved by organic solvents such as alcohols, ethers, ketones, aromatics, straight chain alkanes and common petroleum products. The final rinse of distilled/de-ionized water will be repeated three times. Rinsing removes any remaining contaminants through dilution,

physical attraction, and solubilization. The equipment will then be allowed to air dry.

C. Cleaning of Submersible Pumps

Submersible pumps may be used to evacuate stagnant groundwater from the well casing (e.g., air lift or turbine pumps) or to collect samples (e.g., bladder pump). The pumps will be cleaned and flushed between wells using an external detergent wash and tap water rinse. Steam cleaning may be substituted for pump casing, hose, and cables followed by a flushing with potable water through the pump and tubing or discharge hose. The cleaning process for development and purge pumps can be performed by pumping potable water from a clean plastic over-pack, drum or storage tub until a sufficient amount of water has been flushed through the system. The decontamination process for sampling pumps will consist of filling each of three clean suitable decontamination units sequentially with detergent water, tap water, and distilled/de-ionized water. Placing the sampling pump into each respective decontamination unit and pumping sufficient liquid from each unit through the sampling pump chamber and tubing if appropriate, to flush out any contaminants. It is recommended that disposable tubing be used whenever possible, thus reducing the amount of equipment and time needed for decontamination. In some cases the chosen sampling pump (e.g. QED Micro Purge bladder pump) can easily be disassembled, decontaminated as individual small parts, disposable parts such as bladders and grab plates replaced and them reassembled for use. Such a pump, if appropriate for your sampling situation, would save time when cleaning

and provide a more thorough decontamination, since all surfaces of the pump in which sample water has contact can be inspected, cleaned or replaced. If electric power pumps are used, care should be taken to avoid contact with the pump, well casing, pump reel and sample or purge water in direct contact with the pump, while the pump is running to avoid electric shock.

D. Cleaning of Heavy Equipment

Other equipment and materials, such as drill rigs, well casings, tools, and auger flights, associated with sampling events, will be cleaned prior to use. This equipment may retain chemical constituents from sources unrelated to the sampling site such as roadways, storage areas, or material from previous job sites that were not adequately removed. Heavy equipment will be thoroughly steam cleaned and/or manually scrubbed and rinsed upon arrival on site and when moved between sampling locations, as necessary. Drill rig items such as auger flights, wrenches, drill rods, and drill bits will also be cleaned before changing sample locations.

E. Collection and Disposal of used Solvents, Residuals and Rinse Solutions

All solvents, residuals, and rinse waters generated during the cleaning of equipment on-site will be collected, containerized, and stored on-site until arrangements can be made for proper disposal.

I. INTRODUCTION

Documentation of observations, conditions and generated data during field activities is an accepted scientific procedure and a critical component of any investigation. The rigorous documentation methods described in this SOP may be changed, as necessary, depending upon the needs of any particular investigation. Review the project work plans for any specific field documentation guidance. If changes are made to this SOP, document those changes in the field notes.

II. METHODOLOGY

1. Use a new bound logbook for each project.
2. Label logbook cover and binding with project name and code. Label inside cover with site information (name, address, contact(s), phone numbers, etc.). This will serve as a reference when performing fieldwork.
3. Number each page of the logbook sequentially.
4. All entries must be made in indelible ink (black is preferred because it copies well).
5. All corrections or changes should be initialized, dated and marked with a circled error code. Any mistakes should be drawn through with a single line. Commonly error codes that may be used include: RE Recording Error, CE Calculation Error, SE Spelling Error, CL Changed for Clarity, WO Write Over.
6. All entries should be accurate, factual, and unbiased. Never record an opinion.
7. Notes should be detailed but concise.
8. Notes should be written such that the days activities can be reconstructed at a later date.

9. Date the beginning of each day's notes.
10. Use the 24-hour time format throughout the notes.
11. Complete each day's notes with your signature.
12. Maximize use of each line, crossing out gaps and blank pages so notes cannot be altered.
13. Reference in the logbook when using other forms (e.g., boring logs, sampling forms, etc.).
14. Return logbook to project manager upon completion of fieldwork.

III. MATERIALS

The materials required for this SOP include the following:

- ◆ Bound field logbook(s).
- ◆ Field forms.
- ◆ Black waterproof/indelible ink pen(s).

IV. ITEMS TO INCLUDE IN A LOGBOOK

Field activities can vary widely. Entries in field logbooks will describe activities conducted and may include, but are not limited to, the following:

- ◆ Times of arrival and departure for ALL site personnel.
- ◆ Personnel on-site and affiliation (LTI and subcontractor, regulatory personnel, visitors/guests, and uninvited intruders).
- ◆ List of equipment used on-site (LTI and subcontractor).
- ◆ Detailed descriptions of daily activities.
- ◆ Locations of structures, features, utilities, etc.
- ◆ Conversations with client, contractor, regulatory agencies, office (changes to scope of work, health and safety

issues, and cost/payment issues are especially important).

- ◆ Weather conditions.
- ◆ Documentation of field instrument calibration.
- ◆ Documentation that photos were taken (include date/time of photo, photographer, site name/location, description of photo subject, compass direction taken, photo number).
- ◆ Sample collection and field measurement information, including: sample location, description, date/time, methodology, container types, preservatives, instrument type/serial number (reference applicable field form, if applicable).
- ◆ Wastes generated (containers, volumes, matrix, storage locations).
- ◆ Materials used (e.g., water sources, well materials, field reagents, construction materials).
- ◆ Deviations from intended scope of work.
- ◆ Deviations from SOPs if not already indicated in the work plan.

15. Keep notes legible so others can read the logbook.

A bound logbook is the legal documentation of fieldwork performed at a site. Always remember that your notes may be used in litigation.

I. SURFACE/SHALLOW SOIL SAMPLING

A. Introduction

Surface and shallow soil samples will be collected using a hand-driven split-spoon sampler or shelby tube, a stainless steel bucket auger, or a trowel and scoop as determined by the field supervisor depending on the subsurface material. Hand borings will be performed in areas where truck-mounted rigs are unable to gain access. Samples of subsurface material encountered during this operation will be collected at predetermined depth intervals for soils, sediments, and remnant deposit materials, if encountered and as specified in the work plan. **NOTE: If field activities involve per- and polyfluoroalkyl substances (PFASs) such as PFOS or PFOA, refer to the PFAS sampling SOP for additional measures which supersede this SOP.**

B. Materials

The following materials, as required, will be available during surface/shallow soil sampling:

- ◆ Personal protective equipment as required by the Health and Safety Plan;
- ◆ Cleaning equipment as required in Appendix B;
- ◆ Aluminum foil;
- ◆ Photo Ionization Detector (PID), if potential for volatile compounds exists;
- ◆ Field log;
- ◆ Appropriate sample containers and forms;
- ◆ Insulated coolers with cold packs or ice;
- ◆ Concrete saws, or coring devices;
- ◆ Sampling devices (e.g., split-spoon, shelby tube, stainless steel bucket auger, stainless steel scoop or trowel);

- ◆ Sampling device extension rods, handle, or hammer-driver;
- ◆ Stainless steel spatula, lab spoon, or equivalent (new wooden tongue depressors may also be used); and
- ◆ Liners for sampling devices (e.g., brass, stainless steel, Teflon, or butyrate plastic).



Photo 1:
Typical hand-driven soil sampling tube.

C. Procedures

The following procedures will be employed to collect surface/shallow samples:

1. Check for utilities in the work area.
When working in Michigan, call Miss Dig Utility Locating Service at (800) 482-7171, 48-hours prior to the start of work. Do not proceed until you are confident there is no danger of impacting buried utilities.
2. Don personal protective equipment as required by the Health and Safety Plan.
3. For surface/near surface soil sampling:
 - a. Carefully remove the top layer of soil to the specified depth, if required, using a precleaned stainless steel scoop or trowel.
 - b. Remove and discard a thin layer of soil from where the sample will be collected using a clean stainless steel scoop or trowel.

- c. Carefully remove the desired, representative sample with a precleaned stainless steel spatula, labspoon or equivalent.
 4. For shallow subsurface soil sampling:
 - a. Hand bore down to the specified depth using a precleaned bucket auger.
 - b. Carefully insert a precleaned stainless steel split spoon sampler, shelby tube, or bucket auger to the bottom of the borehole and drive into the soil in a straight and vertical manner to secure a reasonably representative sample.
 - c. Remove the sampler and place on a piece of aluminum foil to avoid contact with surrounding soils.
 - d. Remove all excess soil from the outside of the sampling device to avoid cross contamination over the sample depth.
 - e. Discard the upper 1"-2" of soil in the sampling device to avoid including borehole cave-in or carry down with the sample
 5. Place the sample in the appropriate sample container.
 6. Record all appropriate information in the field log.
 7. Label, handle, pack, and ship the samples consistent with the procedures in the Standard Operating Procedure for Shipping and Handling of Samples.
 8. Fill the sampling hole, as required by the work plan, with the discarded soils, bentonite chips, bentonite slurry, or bentonite/portland cement grout.



Photo 2: Typical bucket auger.

© Fondriest Environmental, Inc.

II. SOIL BORING SAMPLING

A. Introduction

Soil borings will be completed using the hollow-stem auger drilling method or the Geoprobe method (a hammer-driven hydraulic push probe) to a depth specified by the supervising geologist/engineer. In situations where physical site features limit the use of drill rigs, soil borings will be completed with a hand driven auger, a portable power auger, or a tripod and split-barrel sampler (split-spoon) depending on the required depth and subsurface material.

Samples of subsurface material encountered during the drilling of soil borings will be collected at regular intervals, not to exceed five feet, to the required depth of the boring, or as directed by the supervising geologist. The sampling method employed will be consistent with the American Society of Testing and Materials (ASTM) D1586 - Standard Method for Penetration Test and Split-Barrel Sampling of Soils or ASTM D4700 - Soil Sampling from the Vadose Zone. Relatively undisturbed samples will be collected for geotechnical evaluation, if required, using ASTM D1587 - Thin-walled Tube Sampling of Soils or ASTM D4700.

Upon completion of the boring, if a monitoring well is not to be installed, the

bore hole will be backfilled to the surface, as required by the work plan, with soil cuttings, bentonite chips, bentonite slurry, or bentonite/portland cement grout, and the ground surface will be restored.

B. Materials

The following materials shall be available during soil boring sampling:

- ◆ Personal protective equipment as required by the Health and Safety Plan;
- ◆ Cleaning materials as required in the Standard Operating Procedure for Cleaning Equipment;
- ◆ Pre-cleaned drill rig, drill rods, auger flights, probe tubing and samplers;
- ◆ Appropriate sample containers and forms;
- ◆ Liners for sampling devices, if required;
- ◆ Insulated coolers with cold packs or ice;
- ◆ D.O.T.-approved drums for the containerization of soil cuttings; and
- ◆ Field log.

C. Procedures

1. Check for overhead and underground utilities in the work area. When working in Michigan, call Miss Dig Utility Locating Service at (800) 482-7171, 48-hours prior to the start of work. Do not proceed until you are confident there is no danger of impacting buried utilities.
2. Soil samples will typically be collected at 4 or 5 foot intervals, or as required to provide a profile of the subsurface. A geologist or other qualified person will be on-site during the drilling operations to visually inspect and describe each soil sample and/or drill cuttings. The soil descriptions will be recorded on a standard subsurface log and will include the following information, as appropriate or as specified by the supervising geologist.
 - ◆ soil type;
 - ◆ color;
 - ◆ percent recovery;
 - ◆ relative moisture content;
 - ◆ texture;
 - ◆ grain size and shape;
 - ◆ consistency;
 - ◆ standard penetration blow counts, if applicable;
 - ◆ depth to water tables; and
 - ◆ any other noteworthy observations.
3. Upon retrieval of sampling device, representative portions of the sample will be placed in appropriate sample containers (taking care to exclude the top 1-2 inches which may consist of cave-in or carry-down material from shallower depths in the borehole).
4. If required, one representative portion of each sample will be placed in a clean jar, covered with aluminum foil, and let stand for several minutes. The head space will then be screened with a photoionization detector (PID) or equivalent field instrument and the relative concentration of total volatile organic compounds (VOCs) in the sample will be recorded on the boring log.
5. Sample containers will be labeled, temporarily stored on site, and transported to the appropriate testing laboratory at the end of the day, whenever possible. The samples will be handled, packed, and shipped in accordance with the procedures set forth in Appendix A.
6. The supervising geologist will be responsible for documenting drilling events in the field log.
7. The drilling contractor will be responsible for obtaining accurate and representative samples and informing the

supervising geologist of changes in drilling pressure and keeping a separate subsurface log of soils encountered, including blow counts [i.e., the number of blows from a soil sampling drive weight (140 pounds) required to drive the split-spoon sampler in 6-inch increments], where applicable.



Photo 3: Geoprobe liner cut open to reveal soil sample. Samples are extracted using clean utensils or gloves from core into appropriate sample containers.

III. METHANOL PRESERVATION FOR VOC SAMPLES

A. Introduction

The sampling and analysis of soils for volatile organic compounds (VOCs) presents unique challenges because exposure of the soil to the atmosphere facilitates volatilization and biodegradation of some compounds. Soil samples to be analyzed for VOCs shall be;

1. Preserved with methanol prior to transport to a lab.
2. Be sampled using an approved “Encore” sampler. Note that these samples have a shorter hold time and are not universally approved for use. Refer to

manufacturer’s instructions for sampling procedure.

Photo 4:
Encore
Sampler and
“T” handle.



B. Materials

The following materials shall be available during methanol preservation of soil samples:

- ◆ Personal protective equipment as required by the Health and Safety Plan;
- ◆ Pre-weighed, 40-ml vials containing methanol, (usually provided by laboratory conducting analysis);
- ◆ Empty sample containers for dry weight analysis (usually 4 oz. jars)
- ◆ Syringe sampler w/plunger or other sampling device which facilitates the measurement of a precise amount of soil, (usually provided by the laboratory conducting analysis);
- ◆ Digital scale able to measure grams to the hundredth (if necessary);
- ◆ Cooler with ice and packing materials
- ◆ Chain of custody forms

C. Procedures

Unless instructed otherwise, use an approximate one-to-one ratio of soil weight to methanol volume for proper preservation. A general guideline is 10 ml of methanol to 10 grams of soil.

Exact procedures for methanol preservation of soil samples will vary based on specific

laboratory requirements and/or instructions. Consult laboratory prior to collecting samples:

1. Obtain soil sample as described in previous section. Use a PID (photo ionization detector) to determine the layer (if multiple layers are present) most likely to contain VOCs. In lieu of data from the PID, refer to sampling guidance from the project manager.
2. Place empty syringe sampler on scale and tare so weight reads zero grams.
3. Push syringe sampler into soil and extract. Twisting may be necessary while extracting to keep soil inside syringe sampler.
4. Weigh syringe with soil inside, adding or subtracting soil and re-weighing to achieve 10 grams (or other lab-specified sample quantity).
5. Immediately add soil to sample vial containing methanol and seal tightly. Avoid over tightening, as this can cause methanol leakage. Swirl sample gently for 10 seconds.
6. Fill dry weight container with soil from sample area. Appropriately label, cushion, and place both containers in a Ziploc bag incase breakage occurs during shipment.



Photo 5: Typical methanol preservation kit.

D. Shipping Guidelines

The shipping of methanol is regulated by the U.S. Department of Transportation, Title 49 of the Code of Federal Regulations. The DOT number is UN 1230. The amount of methanol used for sample preservation falls under the exemption for small quantities. Requirements for shipment of samples by common carrier (such as FedEx) are as follows;

- ◆ maximum volume of methanol in a sample container cannot exceed 30 ml;
- ◆ the sample container cannot be full of methanol;
- ◆ sufficient absorbent material must be used to completely absorb sample content;
- ◆ each cooler shipped must have less than 500ml of methanol
- ◆ the cooler or package weight must not exceed 64 pounds

- ◆ each cooler must be identified as containing less than 500 ml methanol

IV. EQUIPMENT CLEANING

Equipment cleaning will be performed at the beginning of the sampling event and between each separate sampling location as described in Standard Operating Procedure for Cleaning Equipment.

V. DISPOSAL METHODS

Personal protective equipment, such as gloves, disposable clothing, and the disposable equipment resulting from personnel cleaning procedures and soil sampling and handling activities will be placed in plastic bags. These bags may be transferred into appropriately labeled 55-gallon drums for appropriate disposal as necessary.

